

LIGHT SKY 6800-T34 Light Source System Instruction Manual


[Home](#) » [LIGHT SKY](#) » LIGHT SKY 6800-T34 Light Source System Instruction Manual 

LIGHT SKY[®]

INSTRUCTION MANUAL

LED Profile

- 6800-T34
- 6800-D34



Please read this instruction manual carefully before use
FLY DRAGON LIGHTING EQUIPMENT CO., LTD

Contents

[1 CHANNEL FUNCTION](#)


[2 Documents /
Resources](#)

[3 Related Posts](#)

CHANNEL FUNCTION

CHANNEL	DMX VALUE	%	FUNCTION
1	0-255	0-100	Dimmer
2	0-255	0-100	Dimmer fine
3	Strobe		
	0-9	0-3.53	NO function
	10-49	3.92-19.22	Slow closing,fast opening,slow —* fast
	50-89	19.61-34.90	Fast closing,slow opening,slow —> fast
	90-119	35.29-46.67	Slow closing,slow open,slow —> fast
	120-179	47.06-70.20	Random strobe,slow—>fast
	180-249	70.59-97.65	Synchronous strobe,slow—>fast
	250-255	98.04-100	NO function

Documents / Resources

	LIGHT SKY 6800-T34 Light Source System [pdf] Instruction Manual 6800-T34, 6800-D34, Light Source System, Light Power System
---	--