



Home » LIGHTACCENTS » LIGHTACCENTS 6113 White Torchiere Floor Lamp User Manual

Contents [hide]

- 1 LIGHTACCENTS 6113 White Torchiere Floor Lamp
- 2 INTRODUCTION
- 3 SPECIFICATIONS
- 4 WHAT'S IN THE BOX
- **5 FEATURES**
- 6 SETUP GUIDE
- 7 CARE & MAINTENANCE
- 8 TROUBLESHOOTING
- 9 PROS & CONS
- 10 WARRANTY
- 11 FREQUENTLY ASKED QUESTIONS
- 12 VIDEO PRODUCT OVERVIEW
- 13 References



LIGHTACCENTS 6113 White Torchiere Floor Lamp



INTRODUCTION

Style, practicality, and price combine in the LIGHTACCENTS 6113 White Torchiere Floor Lamp to elegantly brighten your living areas. Decor Works has released this sleek, contemporary floor lamp for \$29.95. Its strong all-metal structure and white powder-coated finish make it ideal for modern décor. Standing at 70 inches, its opal white coneshaped shade softly diffuses light, giving a pleasant, ambient glow perfect for reading or lighting a space. Its stylish appearance and utility make this lamp ideal for living areas, bedrooms, and workplaces.

SPECIFICATIONS

Brand	LIGHTACCENTS
Model Name / Number	Torchiere Lamp / 6113-20

Lamp Type	Floor Lamp
Style / Theme	Contemporary, Modern
Dimensions	10"D x 10"W x 70"H
Height	70 inches
Finish Type	Powder Coated
Base Material	Metal
Shade Material	Plastic
Shade Color	White (Opal White Cone Shade)
Bulb Base	E26
Maximum Wattage	100 Watts
Number of Light Sources	1
Light Source Type	Incandescent
Special Features	3-Way, Energy Efficient



WHAT'S IN THE BOX


- Floor Lamp
- User Manual

FEATURES

• Durability: Built from all-metal materials, this lamp is designed to last long.



- Finish: It has a smooth, white powder-coated surface that looks modern and clean.
- **Shade:** The lamp features an opal white cone-shaped plastic shade that spreads light softly.



- **Lighting Quality:** It provides warm, gentle illumination that's easy on the eyes and perfect for reading.
- **Height:** Standing tall at 70 inches, it's ideal for placing beside furniture in any room.
- Base Size: The lamp is bases on a sturdy 10-inch diameter, giving it stable support.
- **Bulb Type:** Compatible with standard bulbs that fit an E26 socket.
- Max Wattage: Designed to work safely with bulbs up to 100 watts for bright lighting.
- **Switch:** Comes with a simple rotary switch to easily turn on/off and adjust the brightness.
- **Design Style:** Its contemporary look fits well with many home decorating styles.
- **Lighting Method:** The light is directed upwards, creating a cozy and comfortable atmosphere.



- Energy Efficiency: Includes a 3-way wattage setting to save energy and control brightness.
- **Bulb Compatibility:** Works with traditional incandescent bulbs as well as energy-saving alternatives.
- **Placement:** This floor lamp is freestanding, so no mounting or installation on walls is needed.
- Weight: Weighs just over 6 pounds, making it easy to move around your space.

SETUP GUIDE

- **Unpack Carefully:** Remove all packaging slowly so nothing breaks or scratches.
- **Identify Parts:** Make sure you have all the components, like the base, pole sections, shade, and screws.
- Attach Base and Pole: Securely connect the lamp's pole to the heavy base.
- Install Shade: Place the cone-shaped shade onto the bulb holder with care.

- Choose the Right Bulb: Use a bulb with an E26 base and no more than 100 watts (not included).
- Install Bulb: Screw the bulb in firmly, but don't overtighten to avoid damage.
- Plug In Cord: Connect the power cord securely to the lamp base.
- Place the Lamp: Set the lamp on a flat, steady surface to keep it from tipping.
- Check Surroundings: Keep it safely away from fabric or flammable items.
- Connect to Power: Plug it into a normal 120V wall outlet.
- Test Function: Use the rotary switch to check the on/off function and brightness levels.
- Adjust Position: Move the lamp near your bed, couch, or chair for best lighting.
- **Use 3-Way Setting:** Turn the switch to cycle through three levels of brightness to suit your mood.
- Avoid Overpowering: Never use bulbs stronger than 100 watts.
- Manage Cord Safely: Make sure the cord is positioned to prevent tripping or damage.

CARE & MAINTENANCE

- Power Off First: Always unplug the lamp before starting any cleaning.
- **Dust Often:** Use a soft cloth or duster to gently remove dust from the lamp.
- Clean Shade Gently: Wipe the plastic cone shade with a damp cloth or mild cleaner.
- No Harsh Products: Avoid abrasive or strong chemicals that can damage the finish.
- Replace Bulbs When Needed: Swap out flickering or dim bulbs promptly.
- Inspect Cord: Regularly check the power cord for any wear or damage.
- Tighten Parts: Periodically ensure all screws and fittings are secure.
- Keep Dry: Avoid exposing the lamp to moisture or liquids.
- Avoid Heat: Keep the lamp away from direct heat sources like heaters.
- Store Safely: If not in use, disassemble and keep the pieces dry and safe.
- Stick to Recommended Bulbs: Use bulbs within the specified wattage and base type.
- **Turn Off When Idle:** Switch off the lamp when you're not using it to prevent overheating.
- Cool Before Moving: Let the lamp cool down before moving it to avoid burns or damage.
- Child Safety: Place the lamp where it won't tip or be knocked over by children.

• **Professional Repairs:** If electrical issues arise, have a qualified technician handle the fixes.

TROUBLESHOOTING

Issue	Possible Cause	Suggested Solution	
The lamp does not turn on	The bulb is not screwe d in properly	Check and securely screw in the bulb	
	Power supply disconne cted	Ensure the lamp is plugged in and the outlet works.	
	Faulty bulb	Replace with a new, compatible bulb	
Light flickers or dims	Loose bulb or connecti on	Tighten the bulb and check the wir ing connections	
	Faulty socket or switch	Consult a technician for socket replacement	
The lamp produces a b uzzing noise	Bulb wattage too high	Use recommended wattage bulb (max 100W)	
	Loose components	Tighten all screws and fittings	
The rotary switch does not work	The switch mechanism jammed	Turn switch gently; replace if dama ged	
Shade rattles or is loos	Loose shade attachme nt	Secure the shade firmly to the fra	
The base is unsteady o	Assembly not tight	Tighten all screws on the base	
The lamp overheats aft er use	Bulb wattage too high	Switch to a lower-wattage bulb	

Issue	Possible Cause	Suggested Solution	
The cord or plug is damaged	Wear and tear or accid	Replace damaged or consult an el ectrician	

PROS & CONS

Pros

- Durable all-metal frame with sleek white powder coating.
- Stylish opal white cone shade reduces glare while softening light.
- The tall 70-inch height is perfect for reading and accent lighting.
- Energy-efficient 3-way rotary switch functionality.
- Inexpensive price point offering great value.

Cons

- Requires assembly out of the box.
- Bulb not included, which is an additional purchase.
- Not suitable for outdoor use—indoor only.
- Limited to 100-watt incandescent bulbs.
- No adjustable height or direction of light.

WARRANTY

The LIGHTACCENTS 6113 White Torchiere Floor Lamp comes with a limited 1-year manufacturer's warranty from Decor Works. This warranty covers defects in materials and workmanship under normal household use. It excludes issues caused by misuse, improper assembly, damage from accidents, or unauthorized repairs. For warranty support, customers should retain their proof of purchase and contact the manufacturer or authorized retailer.

FREQUENTLY ASKED QUESTIONS

What bulb type and wattage is compatible with the LIGHTACCENTS 6113 White Torchiere Floor Lamp?

The lamp uses an E26 bulb base and supports bulbs up to 100 watts. The bulb is not included.

What is the finish material on the LIGHTACCENTS 6113 White Torchiere Floor Lamp?

It features a durable all-metal construction with a sleek white powder-coated finish, adding a modern touch to any room.

Does the LIGHTACCENTS 6113 White Torchiere Floor Lamp have a dimming feature?

The lamp includes a 3-way rotary switch, allowing you to adjust the lighting intensity for energy efficiency and ambiance control.

How do I assemble the LIGHTACCENTS 6113 White Torchiere Floor Lamp?

Assembly is required; it involves attaching the base, pole sections, and shade. Follow the included instruction manual for step-by-step guidance.

Why is the LIGHTACCENTS 6113 White Torchiere Floor Lamp flickering?

Flickering may be caused by a loose bulb, incompatible bulb type, or electrical issues. Make sure the bulb is secure and compatible with the lamp's specifications.

Is the LIGHTACCENTS 6113 White Torchiere Floor Lamp cordless or does it require a power outlet?

This lamp is corded electric and requires connection to a power outlet; it is not cordless.

What materials are used in the shade of the LIGHTACCENTS 6113 White Torchiere Floor Lamp?

The shade is made of opal white plastic, designed to diffuse light evenly with minimal glare.

VIDEO – PRODUCT OVERVIEW

https://manuals.plus/wp-

content/uploads/2025/09/LIGHTACCENTS-6113-White-Torchiere-

Floor-Lamp-User-Manual.mp4

References

- User Manual
- **LIGHTACCENTS**

Email

• 6113, B08GTY39KB, LIGHTACCENTS, LIGHTACCENTS 6113, user manual, White Torchiere Floor Lamp

Leave a comment

Your email address will not be published. Required fields are marked*				
mment *				
me				

Website				
☐ Save my name, email, and website in this browser for the next time I comment.				
Post Comment				

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.