



Home » Support » Lightbiz C930-6 6PCS Motion Sensor Step Light User Manual 🏗

Contents [hide]

- 1 Lightbiz C930-6 6PCS Motion Sensor Step Light
- 2 INTRODUCTION
- 3 SPECIFICATIONS
- 4 WHAT'S IN THE BOX
- **5 FEATURES**
- 6 SETUP GUIDE
- 7 CARE & MAINTENANCE
- 8 TROUBLESHOOTING
- 9 PROS & CONS
- 10 WARRANTY
- 11 FREQUENTLY ASKED QUESTIONS
- 12 References



Lightbiz C930-6 6PCS Motion Sensor Step Light



INTRODUCTION

An inventive and practical lighting solution, the Lightbiz C930-6 Motion Sensor Step Light 6-pack is made for indoor use in a variety of areas, including bedrooms, kitchens, bathrooms, stairways, and closets. This package, which costs \$29, comes with a multidevice charging station, six rechargeable puck lights, and an easy-to-use remote control. With their motion sensors, which have a 120-degree detection angle and a 10-foot range, these lights provide hands-free illumination that shuts off after 30 seconds of inactivity. Users benefit from flexibility and convenience with two working modes: auto night sensor and always-on operated by remote. The lights include five levels of brightness adjustment and 13 color selections, including RGB modes with smooth, flash, and fade settings. Strong built-in magnets or 3M adhesive tape make installation easy and don't require any wiring or tools. In every interior environment, this energy-efficient, rechargeable lighting system improves convenience, safety, and ambience.

SPECIFICATIONS

Brand	Lightbiz
-------	----------

Model Name	C930-6PCS		
Quantity	6 Puck Lights + 1 Charging Station		
Light Fixture Form	Puck		
Material	Acrylonitrile Butadiene Styrene (ABS)		
Light Color	RGB (13 color options including White)		
Power Source	Rechargeable Battery		
Charging Method	USB Type-C via Charging Station		
Motion Sensor Range	10 ft / 120°		
Operating Modes	Motion Sensor (Auto), Always-On (Remote controlled)		
Brightness Levels	5 levels (20% – 100%)		
Remote Control Includ	Yes		
Dimensions (each light)	2.1" L x 0.7" W x 2.1" H		
Indoor/Outdoor Usage	Indoor Only		
Special Features	Timer (30 mins), Color Changing, Magnetic Mount, Adhesive Mount		
Style	Art Deco		

WHAT'S IN THE BOX

- 6 x Lightbiz Motion Sensor Step Lights (Puck Lights)
- 1 x Multi-device Charging Station
- 1 x Remote Control
- 1 x USB Type-C Charging Cable

FEATURES

- Wireless Rechargeable: Enjoy the freedom of cordless lighting with built-in rechargeable batteries, allowing you to place the lights anywhere without worrying about cords.
- Multi-Device Charging Station: Conveniently charge up to three lights at once, making it easy to keep all your lights powered and ready.
- Motion Sensor Detection: Lights automatically turn on when motion is detected within a 10-foot range and a 120-degree field of view, enhancing security and convenience.
- Dual Operating Modes: Choose between an automatic night sensor mode that
 activates lights when it's dark and motion is detected, or keep them on continuously
 with the always-on setting.
- **Remote Control Included:** Effortlessly control your lights from a distance—switch modes, pick colors, adjust brightness, and set timers with the handy remote.
- 13 Color Options: Select from a pure white light or 12 vibrant RGB colors to create the perfect mood or decorative effect for any room or occasion.
- RGB Color Modes: Enjoy dynamic lighting effects with smooth transitions, flashing, or fading colors that bring life to your space.
- Adjustable Brightness: Tailor the lighting intensity across five levels, ranging from a soft 20% glow to full brightness, to suit your environment perfectly.
- **Timer Function:** Save energy by setting the lights to automatically turn off after 30 minutes, ensuring lights aren't left on unnecessarily.
- **Strong Built-In Magnets:** Easily attach lights to any metal surface without tools, allowing for quick repositioning and flexible placement.
- **3M Adhesive Tape Included:** Mount lights securely on flat surfaces without drilling or screws, making installation simple and damage-free.
- Compact Size: The small, puck-shaped design fits discreetly in tight spaces like under cabinets or shelves without drawing attention.
- **Energy Efficient:** Utilizes LED technology that consumes minimal power, extending battery life and reducing the need for frequent charging.
- Non-Slip Charging Station: Designed to hold lights and cables securely on any

surface, preventing slips or disorganization.

• Safe Indoor Use: Perfect for indoor spaces such as closets, stairways, kitchens, and bedrooms, providing bright and reliable lighting where you need it most.



SETUP GUIDE

- **Unpack Components:** Begin by taking all parts out of the packaging and placing the charging station on a steady, level surface.
- **Connect Power:** Use the included USB Type-C cable to plug the charging station into a power source.
- Charge Lights: Place up to three lights on the station to start charging, and allow them to fully charge before first use for optimal battery health.
- Select Mounting Location: Decide whether you want to attach the lights to a metal surface using magnets or a flat, non-metal surface with adhesive tape.

- Attach Magnets: For metal surfaces, simply place the lights where desired the strong magnets hold them firmly and allow easy repositioning.
- **Use Adhesive Tape:** Peel the protective layer off the 3M tape on the back of each light and press firmly onto the chosen flat surface for secure mounting.
- **Test Motion Sensor:** Walk within 10 feet of the light to ensure the motion sensor activates the light as expected.
- Control via Remote: Use the remote control to pick your preferred color, brightness level, and switch between motion sensor or always-on modes.
- **Set Timer:** Program the lights to turn off automatically after 30 minutes using the timer feature on the remote to conserve battery.
- Adjust Brightness: Smoothly increase or decrease light intensity using the remote's brightness controls for the perfect lighting atmosphere.
- **Regular Charging:** Keep the lights topped up on the charging station regularly to maintain strong battery performance and readiness.

CARE & MAINTENANCE

- Clean Gently: Wipe the lights with a soft, dry cloth regularly to remove dust and maintain optimal brightness.
- Avoid Harsh Cleaners: Never use water or strong chemicals directly on the lights to prevent damage.
- Remove Carefully: When detaching lights from mounts, handle gently to protect the adhesive strips and magnetic components.
- Full Charges: Charge the lights fully each time to extend battery life and maintain performance.
- **Keep Charging Station Clean:** Dust the charging station often to prevent dirt from interfering with charging connections.
- Avoid Extreme Conditions: Protect the lights from extreme heat, cold, or moisture to avoid malfunction.
- **Safe Storage:** Store the lights and remote in a dry, safe place when not in use for extended periods.
- Replace Adhesive When Needed: If the tape loses its stickiness, replace it to ensure secure mounting.
- Keep Motion Sensor Clear: Make sure nothing blocks the sensor to guarantee

proper motion detection.

- Prevent Drops: Handle lights carefully to avoid internal damage from falls.
- Monitor Remote Batteries: Check remote batteries regularly and replace them as necessary for uninterrupted control.
- Maintain Charging Components: Keep the charging cable and port clean and free from damage to ensure safe and efficient charging.
- **Use Supplied Cable:** Always use the original charging cable provided to protect the device's battery and charging system.
- **Reset if Needed:** If the lights flicker or behave oddly, fully drain and recharge them to reset their function.
- Customer Support: Contact support for help if you experience ongoing issues or defects with your lights.

TROUBLESHOOTING

Problem	Possible Cause	Solution		
Light does not turn on	Battery low or not charged	Charge fully using charging st ation		
Motion sensor not activ ating	Sensor blocked or faulty	Clear sensor area, reposition li ght		
Light stays on continuo usly	Mode set to Always-On	Switch mode using remote to Auto		
Remote control unresp onsive	Remote battery low	Replace remote battery		
Light flickers or dims	Low battery or poor connection	Recharge and check mount st ability		
Light color does not ch ange	Remote not working or out of range	Bring remote closer, replace b attery		

Problem	Possible Cause	Solution		
Lights not charging	Faulty charging cable or po	Check cable, ensure proper c onnection		
Adhesive tape loses sti	Dirty or worn adhesive	Replace adhesive tape		
Magnet does not hold li	Surface not metal or uneve	Use adhesive tape or repositio		
Lights turn off too quick	Timer mode activated	Adjust timer or disable via rem ote		

PROS & CONS

Pros:

- Convenient wireless and rechargeable design.
- Multiple colors and dynamic RGB lighting modes.
- Easy, tool-free installation with magnets or adhesive tape.
- Motion sensor enhances energy savings and safety.
- Comes with remote and charging station for organized use.

Cons:

- Designed for indoor use only, not weatherproof.
- Adhesive tape may lose stickiness over time.
- Limited motion sensor range (10 feet).
- Remote battery may require periodic replacement.
- Brightness might be insufficient for very large spaces.

WARRANTY

Lightbiz provides a **Lifetime Warranty** for these motion sensor step lights, ensuring free replacement or support for missing parts such as USB cables or adhesive tapes and

resolving other product issues. Customers should contact Lightbiz via email with purchase details for warranty assistance, reflecting the brand's commitment to quality and customer satisfaction.

FREQUENTLY ASKED QUESTIONS

What is the Lightbiz C930-6 6PCS Motion Sensor Step Light?

The Lightbiz C930-6 is a pack of six wireless rechargeable puck lights with motion sensors, RGB color options, and remote control, designed for indoor use in places like closets, stairways, and kitchens.

How does the motion sensor work on the Lightbiz C930-6 6PCS Motion Sensor Step Light?

The motion sensor detects movement within 10 feet and a 120 degree angle in the dark, automatically turning the Lightbiz C930-6 lights on and off after about 30 seconds of no motion.

What color options does the Lightbiz C930-6 6PCS Motion Sensor Step Light offer?

This Lightbiz model features 13 color options including pure white and RGB with three color change modes Smooth, Flash, and Fade controllable via remote.

How long do the Lightbiz C930-6 lights stay on after motion is detected?

After motion stops, the Lightbiz C930-6 automatically turns off the lights after approximately 30 seconds in motion sensor mode.

How are the Lightbiz C930-6 motion sensor step lights powered?

They are battery powered and rechargeable via the included USB charging station

that can charge all six lights simultaneously or individually.

What are the installation options for the Lightbiz C930-6 6PCS Motion Sensor Step Light?

You can attach the lights using the built-in strong magnet on any iron surface or stick them on flat surfaces using the included 3M adhesive tape, requiring no screws.

How bright are the Lightbiz C930-6 puck lights?

Brightness on the Lightbiz C930-6 is adjustable across five levels from 20% to 100%, controlled via the remote.

References

- User Manual
 - 6PCS Motion Sensor Step Light, B0F5MW9G7F, C930-6, Lightbiz, Lightbiz C930-6, user
- Lightbiz manual

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *	
Name	

Email			
Website			

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.