



LIGHTHOUSE Step Units for Liner Swimming Pool Installation Guide

[Home](#) » [LIGHTHOUSE](#) » LIGHTHOUSE Step Units for Liner Swimming Pool Installation Guide



Contents [[hide](#)]

- [1 Step Units for Liner Swimming Pool](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)


Step Units for Liner Swimming Pool



Place the step unit flush with two edges of the pool wall in the corner that you wish to have access to the pool. Bead the wall edges of the step with the supplied CT1 to seal the gap between the edge of the step and the wall. The HeatForm steps are simply installed on the floor of the pool shell prior to installing the pool liner.




Suitable for installation in conjunction with both onsite lining and pre-tailored bag lining systems, the HeatForm steps are an easy and quick solution to adding a touch of elegance to any liner pool.



Please note: If there is any chance of ground water ingress into the pool shell it is recommended to install a vent kit through the wall. This is to allow any trapped air to be released and avoid any damage to the pool lining. See the example illustration of the vent system installation.


LIGHTHOUSE
 The Specialist Pool Distributor
 01752 253525
www.heatform.co.uk

	<p>Lighthouse Step Units for Liner Swimming Pool [pdf] Installation Guide Step Units for Liner Swimming Pool, Units for Liner Swimming Pool, Liner Swimming Pool</p>
--	--

References

- [HeatForm Insulated Panel Pool](#)