


LIMENTE MINI-2 Socket Part Instructions





[Home](#) » [LIMENTE](#) » LIMENTE MINI-2 Socket Part Instructions 

LIMENTE MINI-2 Socket Part




Contents

- [1 LIMENTE MINI-2, MINI-2C USB, MINI-3, LUNA-2, VER. 010/011](#)
- [2 Assembling instructions](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)


	LIMENTE Mini-2, S/S PNC: 630581/010 max. 16 A CE Snro: 2407102 LIMENTE Mini-2, white PNC: 630584/010 max. 16 A CE Snro: 2407108 LIMENTE Mini-2, black PNC: 630589/010 max. 16 A CE Snro: 2407122
	LIMENTE Mini-3, S/S PNC: 630681/010 max. 16 A CE Snro: 2407103 LIMENTE Mini-3, white PNC: 630684/010 max. 16 A CE Snro: 2407109 LIMENTE Mini-3, black PNC: 630689/010 max. 16 A CE Snro: 2407123
	LIMENTE Luna-2, S/S PNC: 631581/011 max. 16 A/3A CE Snro: 2407104 LIMENTE Luna-2, white PNC: 631584/011 max. 16 A/3A CE Snro: 2407111 LIMENTE Luna-2, black PNC: 631589/011 max. 16 A/3A CE Snro: 2407124
	LIMENTE Mini-2C USB, S/S PNC: 631201/010 max. 16 A/3A CE Snro: 2407127 LIMENTE Mini-2C USB, white PNC: 631204/010 max. 16 A/3A CE Snro: 2407128 LIMENTE Mini-2C USB, black PNC: 631209/010 max. 16 A/3A CE Snro: 2407129

Assembling instructions


Before installation assure online at www.limente.com that you are using the latest assembling instruction. Installation must always be done by an authorized person following valid local regulations.




INPUT
240 V
Max 16 A




OUTPUT
240 V
Max 16 A




INPUT
240 V
Max 16 A




OUTPUT
240 V
Max 16 A



②




③




LIMENTE MINI-2C USB

②




③




LIMENTE MINI-3

②




③




LIMENTE LUNA-2


②






③



⑤



6



www.limonte.com



LIMENTE
- H E L S I N K I -

Documents / Resources

