

Lindab GD Injection Nozzle Instruction Manual

[Home](#) » [Lindab](#) » Lindab GD Injection Nozzle Instruction Manual 

Contents

- [1 Lindab GD Injection Nozzle Instruction Manual](#)
- [2 Mounting](#)
- [3 Mounting](#)
- [4 Support](#)
- [5 Read More About This Manual & Download PDF:](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Lindab GD Injection Nozzle Instruction Manual



Mounting



Measure/weight
Mål/vægt
Mått/vikt
Mitta/paino
Abmessungen/Gewicht
Misure/peso

mm	kg
Ø 77	-



Parts list
Stykliste
Stycklista
Osaluettelo
Einzelteile
Lista componenti

1 x



The diffuser can be demounted and vacuum cleaned by using a smooth nozzle brush or wiped off by using a sponge or soft cotton cloth firmly wrung in pure water.




Maintenance
Vedligeholdelse
Underhåll
Huolto
Wartung
Manutenzione



Mounting

1. - GD


$\varnothing \geq 250 \text{ mm}$



2. - GD



$\varnothing \geq 250 \text{ mm}$



$H \geq 100 \text{ mm}$


Support



Here you can find product updates/mounting instructions and support telephone number/mail. www.lindab.com
Right to alterations reserved.

Read More About This Manual & Download PDF:

Documents / Resources



References

- [© Lindab | For a better climate - Lindab](#)
- [© lindab.de](#)
- [© Lindab i Danmark for Ventilation og Profil](#)
- [© Laadukasta sisäilmaa](#)
- [© Lindab italia](#)
- [© Lindab | Kvalitetsprodukter inom ventilation, plåt och bygg](#)

Manuals+,