

Lindab LCC-P Circular Air Diffuser Instruction Manual

Home » Lindab » Lindab LCC-P Circular Air Diffuser Instruction Manual

Contents

- 1 Lindab LCC-P Circular Air Diffuser
- **2 Installation Instruction**
- 3 Measure/weight
- 4 Optional accessories
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**



Lindab LCC-P Circular Air Diffuser




Installation Instruction

Overview Ceiling diffusers suitable for Pascal



Symbols






Presence sensor




Temperature sensor

Measure/weight




Ød mm	ØU mm	kg
125	525	2.8
160	525	2.7
200	525	2.7
250	525	2.6
315	525	2.5

Ceiling grid opening



Order code



Optional accessories


•

MBZ



Extension piece


Order code




Example: MBV 160-250-CN + MBZ + LCC250



Installation of diffuser in MB





Most of us spend the majority of our time indoors. Indoor climate is crucial to how we feel, how productive we are and if we stay healthy. We at Lindab have therefore made it our most important objective to contribute to an indoor climate that improves people's lives. We do this by developing energy-efficient ventilation solutions and durable building products. We also aim to contribute to a better climate for our planet by working in a way that is sustainable for both people and the environment.

www.lindab.com

Documents / Resources



<u>Lindab LCC-P Circular Air Diffuser</u> [pdf] Instruction Manual LCC-P, Circular Air Diffuser, LCC-P Circular Air Diffuser, Diffuser, Diffuser

References

• © Lindab | For a better climate - Lindab

