


linear
GATE OPENERS
**CSI724 Gate
Hinges**



Linear Gate Openers CSI724 Gate Hinges Installation Guide

[Home](#) » [Linear Gate Openers](#) » Linear Gate Openers CSI724 Gate Hinges Installation Guide 

Contents

- [1 Linear Gate Openers CSI724 Gate Hinges](#)
- [2 Product Usage Instructions](#)
- [3 INSTALLATION:](#)
- [4 FAQs](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

linear
GATE OPENERS

Linear Gate Openers CSI724 Gate Hinges



Specifications

- Product Name: GUARDIAN Gate Hinges Weld On

- Mounting: Yoke welded to gate, channel welded to post
- Maintenance: Grease zerk for lubrication
- Manufacturer: Guardian Gate Hardware

Product Usage Instructions

Installation


1. Mount the yoke (FIG. 1) to the gate by welding.
2. Weld the channel to the post.
3. Ensure hinge pins are in a straight line during installation.
4. Do not weld the top and bottom of the hinges.
5. For hinge capacities, refer to sales literature or contact Guardian Gate Hardware for technical support.

Maintenance

A regular maintenance schedule is crucial for the effectiveness and longevity of the gate system:

- Use a high-quality, multi-purpose grease for lubrication.
- Apply one pump of grease through the grease zerk (FIG 3) every 3 months under normal conditions.
- For severe operating conditions, increase the frequency of maintenance.
- Avoid over-lubrication as it can cause issues.

INSTALLATION:



- GUARDIAN gate hinges are to be mounted with the yoke (FIG. 1) welded to the gate and the channel welded to the post.
- The hinges must be installed with the hinge pins in a straight line.
- Reference sales literature for hinge capacities or contact Guardian Gate Hardware for technical support.
- Weld only on the vertical portions of the yoke and plate.
- DO NOT weld the top and bottom of the hinges. Bolt on versions of this hinge are available.

MAINTENANCE:

- A regular maintenance schedule is important for the efficacy and durability of any gate system. This GUARDIAN gate hinge is equipped with a grease zerk (FIG 3) for easy lubrication. One pump of a high quality, multi purpose grease every 3 months should be sufficient under normal operating conditions. More frequent maintenance is necessary under severe operating conditions. Do not over lubricate.
- www.LinearGateOpeners.com | [800-878-7829](tel:800-878-7829) | Sales@LinearGateOpeners.com

FAQs

Q: How often should I lubricate the GUARDIAN gate hinge?

A: For normal operating conditions, apply one pump of grease every 3 months. Increase frequency for severe conditions.

Q: Can I weld the top and bottom of the hinges during installation?

A: No, only weld on the vertical portions of the yoke and plate. Avoid welding the top and bottom of the hinges.

Documents / Resources

	Linear Gate Openers CSI724 Gate Hinges [pdf] Installation Guide CSI724 Gate Hinges, CSI724, Gate Hinges, Hinges
------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------

References

-  [Index of /](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.