

LIORQUE 3160 Digital Clock with Date and Day for Elderly Calendar Digital Clock Memory Loss Day Clock User Manual

LIORQUE 3160 Digital Clock with Date and Day for Elderly Calendar Digital Clock Memory Loss Day Clock



Contents

- [1 Diagram](#)
- [2 Power On](#)
- [3 Time/Date Setting & 12/24 Hour Switch](#)
- [4 DST Setting](#)
- [5 Alarm & Volume Setting](#)
- [6 Weekend Mode Setting](#)
- [7 Brightness Adjustment](#)
- [8 °C/°F Conversion](#)
- [9 Factory Reset](#)
- [10 Package](#)
- [11 FCC Statement](#)
- [12 Customer Support](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)


Diagram

1. Time Display
2. Alarm 1 Display
3. Alarm 2 Display

4. DST
5. Weekend Mode Display
6. Temperature Display (°C °F)
7. Date Display
8. Week Display
9. Set up
10. +
11. -
12. Alarm 1
13. Alarm 2
14. Weekend Mode
15. Dimmer
16. Micro Charging

Port(To charge the product, plug one end of the cable into it, and the other end into the adapter)

17. Speaker
18. Hanging Hole
19. Reset
20. Temperature Sensor
21. Bracket



Power On

Plug one end of the Cable into the Micro Charging Port of the clock and connect the other end to the adapter (included). Then plug the adapter into the power, the clock starts to serve.

Time/Date Setting & 12/24 Hour Switch

1. 12/24 Hour Switch

In standard mode, short press "⚙️" to switch 12/24 hour display. When "7 2Hr" flashes, means 12 Hour clock; When "24Hr" flashes, means 24 Hour clock.




2. Time/Date Setting

- In standard mode, press and hold ⚙️ to enter into time setting and the Hour digit on the screen start to flash. Short press or ▲ to ▼ increase/decrease by 1; press and hold the button to adjust rapidly.
- After the Hour is set, short press "0 11 and Minute digit on the screen start to flash. Short press ▲ or ▼ to increase/decrease by 1; press and hold the button to adjust rapidly.
- After the Minute is set, short press to set YEAR-MONTH-DATE(2000-2099).
- After the Date is set, short press to enter into Multi-language week day selection, short press or to choose the relative language, press again(or wait for 5 seconds) to confirm the settings.

Attention: After the date is set, the day of the week is updated automatically. You don't need to select the day of the week manually, just select the language. You can choose English (ENG) – German (DEU) – French (FRE) – Spanish (ESP) – Italian (ITA).

DST Setting

1. In standard mode, long press "▼" button to enable DST mode with "DST" icon on.




2. When DST mode is enabled, long press ▼ button to disable DST with "DST" icon off.



Long Press

Alarm & Volume Setting




1. Short press "  1 " button to activate or cancel Alarm 1.

Light Up  1



Press



2. Long press "  1 " button to enter Alarm 1 setting with Hour digit flashing. Press "  "or"  " button to increase or decrease by one digit, and long press to quickly adjust.



Long Press





Press




Press

Flash



3. Short press "  1 " button again, and Minute begins to flash.



4. Short press “ 1” BI or SON start to flash, press “ “or” ” to choose regular ringtones or chord tone for your alarm clock.

Regular ringtones



Chord tone



5. Short press “ 1” button again, and “L01” begins to flash. Press “ “or” ” button to adjust the volume among L01, L02, L03



6. Short press 1 button to save the setting of Alarm 1.




Press


Note: Set the Alarm 2 as the procedures of the Alarm 1. When the alarm bell rings, you can cancel the alarm by pressing any button .

Weekend Mode Setting

Press “W” button to enable or disable Weekend mode. When ” WEEKEND” icon flashes, Weekend mode is activated. Then, the alarm will only be activated from Monday to Friday, and it will be cancelled on Saturday or Sunday.




Brightness Adjustment

In standard mode, press  button to adjust the brightness of the LED display.

Note: This could be done only when the alarm is turned off.



°C/°F Conversion


In standard mode, press  button to convert between degree Celsius and degree Fahrenheit.



Press


Factory Reset

Reset the clock by pressing the Reset button inside the back hole .




Package


- Clock *1




- Micro USB Cable *1



- Adapter *1



- User Manual *1



Notes

1. Do not expose the unit to extreme temperatures, direct sunlight, dust or humidity.
2. A cloth or other protective material should be placed between the clock and the furniture.
3. Cut off the power before clean the clock with a soft cloth moistened only with mild soap and water.
4. You must use the original adapter.
5. Do not disassemble the clock or touch any components.

FCC Statement

Operation is subject to the following three conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Customer Support

Service Email: support@liorque.net



EU Importer: Lucky Transport Euro Kft REP EC

Address: 1085 Budapest, Jozsef Central Street 69. Ground Floor, 1, Hungary


Email: Lsphche@outlook.com

UK Importer: HISOA CO., LTD.

Address: 19a Chorley Old Road, Bolton, Greater Manchester, England, BL 1 3AD

Web: www.hisoa.co.uk

Documents / Resources

	<p>LIORQUE 3160 Digital Clock with Date and Day for Elderly Calendar Digital Clock Memory Loss Day Clock [pdf] User Manual</p> <p>3160 Digital Clock with Date and Day for Elderly Calendar Digital Clock Memory Loss Day Clock, 3160, Digital Clock with Date and Day for Elderly Calendar Digital Clock Memory Loss Day Clock, Elderly Calendar Digital Clock Memory Loss Day Clock, Digital Clock Memory Loss Day Clock, Memory Loss Day Clock</p>
--	---

References

- [User Manual](#)