

**Contents** [ [hide](#) ]

[1 LIORQUE TM027 Visual Timer](#)

[2 Product Usage Instructions](#)

[3 Alarm Modes](#)

[4 Setting](#)

[5 FCC STATEMENT](#)

[6 Documents / Resources](#)

[6.1 References](#)

# LIORQUE


## LIORQUE TM027 Visual Timer



## Product Usage Instructions

## Diagram


1. Center knob
2. LED indicator
3. Visual dial
4. Wall mounting hole
5. 3-level alarm volume (in sound mode)
6. 3 kinds of alarm modes (sound/light/vibration)
7. Battery compartment
8. Bracket
9. Magnet



## Tips

1. Before using this timer, please open the battery cover, remove the insulating sheet, and check whether the battery is installed in place.
2. Before using this timer, please adjust the alarm modes you need.

## Alarm Modes



### 1. Sound Mode

In sound mode, you can switch the alarm to mute, low volume, or high volume, and the alarm will sound when time is up.

#### • Attention

- If you choose mute, there will be no reminder when time is up.

- Alarm volume adjustment is only valid in sound mode.

## 2. **Light Mode**

In light mode, the timer will flash a red light to remind you when time is up.

## 3. **Vibration Mode**

In vibration mode, the timer will vibrate to remind you when time is up.

## **Setting**

1. Turn the knob clockwise to your desired countdown time, the green light will appear, which means the timer starts working, and the green light will keep on during the countdown process.
2. If the desired countdown time is less than 3 minutes, please turn the knob to 5 minutes first, and then back to your desired time, otherwise the timer will not work.
3. Countdown range: 0-60 minutes
4. When time is up, all alarm modes will last for 1 minute, if you want to end the alarm earlier, please refer to the QR code below for the steps to end the alarm.



## **Low Battery Alerts**

1. In standby mode, when the battery is low, the timer will flash a red light every 2 seconds.
2. When the battery is low, the timer will not work properly. Please replace the battery immediately.
3. Please use replaceable 2 x AA 1.5V batteries.

## **Hour Customer Service**

If you have any questions about our products, please contact us via [support@liorque.net](mailto:support@liorque.net)

## **FCC STATEMENT**

Operation is subject to the following three conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Correct Disposal of this product**

This marking indicates that this product should not be disposed of with other household waste throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

## **Documents / Resources**

	<a href="#">LIORQUE TM027 Visual Timer [pdf]</a> User Manual 006642, TM027 Visual Timer, TM027, Visual Timer, Timer
---	--

## References

- [User Manual](#)

■ LIORQUE    ♦ 006642, LIORQUE, Timer, TM027, TM027 Visual Timer, Visual Timer

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of

these marks on this website does not imply any affiliation with or endorsement.