



Home » Support » LITBLOOM Battery Operated Yellow-Maple Lights User Manual 172

## Contents [ hide ]

- 1 LITBLOOM Battery Operated Yellow-Maple Lights
- 2 INTRODUCTION
- 3 SPECIFICATIONS
- 4 WHAT'S IN THE BOX
- **5 FEATURES**
- 6 SETUP GUIDE
- 7 CARE & MAINTENANCE
- 8 TROUBLESHOOTING
- 9 PROS & CONS
- 10 WARRANTY
- 11 FREQUENTLY ASKED QUESTIONS
- 12 References



**LITBLOOM Battery Operated Yellow-Maple Lights** 



# INTRODUCTION

The LITBLOOM Battery Operated Yellow-Maple Lights are a beautifully handcrafted 6-foot garland that is designed to infuse warmth and elegance into your seasonal décor, allowing you to celebrate the cozy charm of autumn. This vibrant maple leaf vine, priced at \$24.99, illuminates 24 gentle, warm white LEDs and is an ideal decorative addition to mantles, fireplaces, tables, and stair banisters. Craftsmanship and functionality are the hallmarks of this product, which was introduced by the reputable home décor brand LITBLOOM. Its flexible branches and imperceptible wiring provide a natural appearance, allowing for customization as a standalone garland or fall wreath centerpiece. It is suitable for both indoor and outdoor use due to the built-in timer function, which guarantees a hassle-free illumination cycle (6 hours on, 18 hours off). Crafted from premium faux maple materials and powered by three AA batteries (not included), this garland combines practical design with festive flare, evoking a magical autumn glow in your home.

#### **SPECIFICATIONS**

Product Na me	LITBLOOM Battery Operated Yellow-Maple Lights			
Price	\$24.99			
Brand	LITBLOOM			
Color	Yellow Maple			
Material	Artificial Maple Leaves			
Length	6 Feet (72 Inches)			
Plant Type	Maple Leaf Vine			
Light Count	24 soft warm white LEDs			
Design Feat ures	Textured, detailed leaves; invisible wire for a natural look			
Lighting Co	On/off switch and 24-hour timer (6 hours on / 18 hours off)			
Branches	Flexible and sturdy; shapeable for wreath or DIY arrangement			
Power Sour	3 AA batteries (not included)			
Waterproof	IP44-rated – suitable for indoor and covered outdoor use			
Decor Uses	Uses Fireplace, mantel, wall, kitchen, table, stairs, patio, garden, walkway, T hanksgiving, Halloween			
Safety Note	Keep away from water, heat, children, and pets. Dispose of batteries properly			
Light Type	Built-in warm white LEDs with timer functionality			

# WHAT'S IN THE BOX

- Yellow-Maple Lights
- User Manual

# **FEATURES**

- 6 Foot Long Garland: The 6 foot long garland, which measures 72 inches, is perfect for adorning mantles, fireplaces, stair banisters, and tables.
- 24 Warm White LED Lights: A soft, comforting glow that is ideal for the autumn and holiday season.
- Handcrafted Maple Leaves: Yellow maple leaves that are detailed and textured, providing an elegant autumnal appearance.
- **Invisible Wiring:** Wires are concealed to achieve a natural and seamless appearance.
- Internal Timer Function: A 24-hour timer that operates on a six-hour on and 18-hour off cycle, thereby reducing energy consumption and providing convenience.
- Manual Control Option for Effortless Operation: On/Off Switch.
- Flexible Branches: The branches are both robust and bendable, enabling you to customize the garland to your liking.
- Battery Operated: This device is powered by three AA batteries (not included), providing cordless convenience.
- Waterproof Design: Suitable for both interior and outdoor applications, such as doorframes, gardens, and patios.
- **Lightweight:** Simple to install and transport.
- Versatile Decoration: Suitable for everyday décor, Halloween, Christmas, Thanksgiving, and autumn.
- Yellow Maple Leaves: Contribute seasonal warmth and appeal to the natural color palette.
- Energy Efficient LEDs: Long-lasting bulbs with low power consumption.
- Material of Durability: Constructed from premium maple to ensure longevity.



# **SETUP GUIDE**

- Garland Unpacking: Extract the battery cell and garland from the packaging.
- **Insert Batteries:** Properly insert three AA batteries by opening the battery compartment.
- Battery Compartment Closure: Firmly fasten the battery cover.
- **Select a Location:** Choose a location, such as a mantle, fireplace, table, wall, or stair balustrade.
- **Garland Designation:** Bend and arrange the flexible branches to achieve the desired shape.
- Light the Garland: Utilize the on/off switch to activate the lights.
- Activate the Built-in Timer: Establish automatic 6-hour on and 18-hour off cycles, if desired.
- Garland Security: Utilize hooks, ties, or tape to secure the garland in position.
- To Prevent Injury: Refrain from stretching the garland beyond its intended length.
- Stay Away from Water: To prevent water exposure, use sheltered outdoor areas or indoors.
- Battery Pack Position: Subtly conceal the battery supply to achieve a tidy

appearance.

- Test Lights: Confirm that all LEDs are functioning appropriately.
- Batteries Must Be Replaced When Required: Monitor battery life and replace them promptly.
- Combine with Other Decorations: For an improved look, pair with other fall or fairy lights.



#### **CARE & MAINTENANCE**

- Before Adjusting or Cleansing: Ensure that the lights are turned off.
- Battery Removal When Not In Use: To prevent battery leakage during extended storage, batteries should be removed.
- Dust Consistently: Utilize a soft cloth or duster to eliminate leaves and lighting.
- **Prevent Water Exposure:** Do not immerse or spray water on the battery pack or lighting.
- Inspect the Battery Compartment: Check for corrosion or damage on a regular basis.
- Store in a Dry Location: When not in use, ensure that the garland is kept dry.

- Handle Wires with Care: Refrain from tugging or twisting them.
- Substitute Batteries with High-Quality Brands: Invest in high-quality batteries to extend their lifespan.
- To Prevent Overheating: Refrain from covering the battery pack or garland.
- **Inspect for Loose Connections:** Guarantee that the battery contacts and conductors are securely fastened.
- Maintain Distance from Heat Sources: Prevent placement in close proximity to flames or radiators.
- Prevent Damage by Gently Shaping: Avoid sharp bends.
- Proper Storage: Store in the original packaging or a package and coil loosely.
- For Indoor or Sheltered Outdoor Use Only: Shield from torrential precipitation or snowfall.

# **TROUBLESHOOTING**

Issue	Possible Cause	Solution	
Lights not turning on	Batteries not installed or pl aced incorrectly	Reinsert batteries and ensure proper polarity	
Lights dim or fadin g quickly	Batteries are low or expire	Replace with new AA batteries	
Timer not functioni	Switch not set to TIMER mode	Turn switch to TIMER and observe cycle	
Only part of the ga	Loose internal wire or LED issue	Check for bends or pressure points; gently adjust branches	
Branches lose sha	Over-flexing or incorrect s haping	Gently reposition and avoid over-be nding wires	
Flickering lights	Weak battery connection o r depleted batteries	Adjust battery position or replace wi th fresh ones	

Issue	Possible Cause	Solution	
Battery box overh eating	Poor-quality batteries or lo	Replace batteries; do not run contin uously for extended hours	
Wire visible in som e areas	Poor branch adjustment	Reposition leaves to cover exposed wires	
Lights shut off une xpectedly	Timer function active	Confirm if timer is cycling; switch to ON to override	
Battery compartm ent won't close	Misplaced battery or debri s inside	Realign batteries and ensure comp artment is clean	

## **PROS & CONS**

#### **PROS**

- Realistic yellow maple leaves enhance fall decor
- Includes a timer function for set-it-and-forget-it convenience
- 6FT length provides great coverage for mantels or tables
- Soft warm white lighting adds cozy ambiance
- Battery-operated design offers cordless flexibility

#### **CONS**

- · Batteries not included
- Not suitable for use near water or heat sources
- Only one light color available
- Limited brightness for large outdoor spaces
- Not intended for permanent outdoor installation

#### WARRANTY

The LITBLOOM Yellow-Maple Lighted Garland includes a **1-year limited warranty**, covering manufacturing defects and faulty craftsmanship under normal usage. The

warranty does not cover damage due to misuse, water exposure, incorrect battery handling, or alterations. LITBLOOM provides responsive customer support and promises a resolution within 24 hours for any reported issue during the warranty period. A valid proof of purchase is required for all claims.

## FREQUENTLY ASKED QUESTIONS

What is the LITBLOOM 6FT Lighted Fall Maple Garland?

The LITBLOOM 6FT Lighted Fall Maple Garland is a handcrafted vine of textured yellow maple leaves dotted with 24 warm white LED lights for seasonal indoor/outdoor décor.

How is the LITBLOOM Maple Garland powered?

This LITBLOOM Yellow Maple Garland runs on 3 AA batteries (not included) and offers an on/off switch plus a 24-hour timer that cycles 6 hours on, 18 hours off.

Is the LITBLOOM Maple Garland suitable for outdoor use?

The LITBLOOM Garland is waterproof and can be used on patios, porches, and doorframes—though the battery pack should remain sheltered from direct rain.

How long will the lights stay on when I use the timer function?

Once activated, the LITBLOOM Garland's timer will keep the lights on for 6 hours and then off for 18 hours, repeating daily until manually switched off.

What should I do if the lights on my LITBLOOM Garland wont turn on?

First verify the 3 AA batteries are fresh and correctly installed. Ensure the switch is in the on or timer position and that the battery box is fully closed.

Why are my LITBLOOM Garland LEDs flickering or dimming?

Flickering or dim lights usually indicate low battery power. Replace all three batteries with quality alkaline or rechargeable AAs.

How do I reset the timer on the LITBLOOM Yellow Maple Garland?

Turn the garland off, wait one minute, then switch back to timer mode. This restarts the 6-hour on/18-hour off cycle from that point.

#### References

- User Manual
  - ▶ B09BL5GPG6, Battery Operated Yellow-Maple Lights, LITBLOOM, user
- LITBLOOM manual

# Leave a comment

Comment *	
Name	
Email	
Website	

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment** 

## Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.