

LITETRONICS®

LITETRONICS
HOPT2 LED High
Ceiling Panel



LITETRONICS HOPT2 LED High Ceiling Panel Instruction Manual

[Home](#) » [Litetronics](#) » LITETRONICS HOPT2 LED High Ceiling Panel Instruction Manual 

Contents

- [1 LITETRONICS HOPT2 LED High Ceiling Panel](#)
- [2 WHAT COMES IN THE BOX](#)
- [3 SAFETY INSTRUCTIONS AND WARNINGS](#)
- [4 INSTALLATION PROCEDURE](#)
- [5 WATTAGE SLIDE SWITCH SETTINGS](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

LITETRONICS®

LITETRONICS HOPT2 LED High Ceiling Panel




LED High Ceiling Panel Installation instructions


Selectable Output Series | 2' x 2', & 2' x 4'

WHAT COMES IN THE BOX

- (a) LED High Ceiling Panel
- (b) Driver box
- (c) Wire Nut (xS)
- (d) Installation Instructions
- (e) Screw (x2)



a



b



c



d

TOOLS NEEDED

- Wire Stripper
- Wire Cutter
- Phillips Screwdriver

SAFETY INSTRUCTIONS AND WARNINGS

- WHEN USING ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE OBSERVED.
- READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
- Litetronics fixtures must be wired in accordance with the National Electrical Code and all applicable local codes.
- Risk of fire or electric shock. High Ceiling Panel installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.
- Be certain electrical power is OFF before and during installation and maintenance.
- High Ceiling Panel must be connected to a wiring system with an equipment-grounding conductor.
- Make sure the supply voltage is the same as the rated luminaire voltage.
- Only the open holes indicated in the photographs and/or drawings may be made or altered as a result of this kit installation. Do not leave any other open holes in an enclosure of wiring or electrical components.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects.
- No user serviceable parts inside of High Ceiling Panel.
- Suitable for damp locations.
- Suitable for 9/16" or 15/16" FlatTee Grid in both insulated ceilings and non-insulated ceilings. Access above ceiling required.
- Vapor barrier must be suitable for 90° C.
- Fixture to be independently supported to building structure.

INSTALLATION PROCEDURE

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Connect the driver to panel with quick plug connector on desk or floor.
2. Push the driver into the slot position and tighten the screws.
3. Turn off power at the electrical panel.
4. Remove the ceiling tile or existing fixture from the grid ceiling space.
5. Before installing, locate the grid clips on your panel; bend them up and out so they can rest on top of the grid.
6. Unscrew and remove the driver cover to access the input ports, ground and dimming wires.
7. Locate the adjustable wattage slide switch on the side of the driver and set to the desired wattage. See slide switch settings below.
8. Tilt and raise the panel up into the empty grid space, then lower until the grid clips catch on the tee-grid bar.
Attach the panel to the building with support wires (not included) using the hole in the grid clip.
9. Remove one conduit knock-out from the driver, then run branch power wire from the conduit to the driver.
10. Make wiring connections using wire nuts.

- Connect the live power (black) line to ACL(Black)
- Connect the neutral(white) line to ACN(White)
- Connect the green ground line to GND(Green)
- If 0-10V dimming is required, connect incoming dimming lines to the DIM+ (Purple) and DIM- (Gray/Pink) wires. Follow dimmer manufacturers instruction

11. Close the driver cover and secure it with the screw.

WATTAGE SLIDE SWITCH SETTINGS

2'X2'

WATTAGE					
80	100	120	150	170	215

Note: Watts default setting set to 21 SW.

2'X4'

WATTAGE					
105	145	180	260	290	325

Note: Watts default setting set to 325W.


CCT SLIDE SWITCH SETTINGS

5000K	4000K
-------	-------


Note: CCT default setting set to 5000K.

DRIVER BOX ASSEMBLING

1. Connect the driver to the panel with quick plug connector.
2. Push the driver into the slot position.



3. Lock the driver box on the bracket by screws.



Thank you for choosing

6969 W. 73rd Street

Bedford Park, IL 60638

WWW.LITETRONICS.COM


CustomerService@Litetronics.com or 1-800-860-3392



The information and product specifications contained in these instructions are based upon data believed to be accurate at the time of printing. This information is subject to change without notice and without incurring liability. If you have questions regarding specific product details, please contact us at [800-860-3392](tel:800-860-3392) or via email at customerservice@litetronics.com.

To check for an updated version of these instructions, please visit www.litetronics.com.

Documents / Resources

	<p>LITETRONICS HOPT2 LED High Ceiling Panel [pdf] Instruction Manual HOPT2 LED High Ceiling Panel, HOPT2, LED High Ceiling Panel, High Ceiling Panel, Ceiling Panel, Panel</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.