

LIVARNO
home
LIVARNO home
14173702L LED Table
Lamp with Touch
Function



LIVARNO home 14173702L LED Table Lamp with Touch Function Instruction Manual

[Home](#) » [LIVARNO home](#) » LIVARNO home 14173702L LED Table Lamp with Touch Function Instruction Manual



Contents

- 1 [LIVARNO home 14173702L LED Table Lamp with Touch Function](#)
- 2 [Explanation of the pictograms used](#)
- 3 [Introduction](#)
- 4 [Technical data](#)
- 5 [Safety](#)
- 6 [Disposal](#)
- 7 [Warranty and service](#)
- 8 [Documents / Resources](#)
 - 8.1 [References](#)
- 9 [Related Posts](#)



LIVARNO home 14173702L LED Table Lamp with Touch Function



LED Table Lamp with Touch Function

Introduction

Congratulations on your new product. You have selected a high-quality product. Please be sure to carefully read the complete operating instructions. These instructions are part of the product and contain important information on setup and handling. Always follow all safety instructions. Before using this product for the first time verify the correct voltage and that all parts are properly installed. Should you have any questions or you are unsure about operating the product, please contact the dealer or service centre. Please keep these instructions in a safe place and pass them on to third parties as applicable.

Intended Use

This lamp is exclusively designed for use in dry indoor rooms. This product is intended for private household use only. This product is intended for normal operation.

Scope of Delivery

- 1 LED Table Lamp with Touch Function
- 1 Lamp glass
- 1 Lamp stand
- 1 LED illuminant (dimmable in 3 stages)
- 1 Installation and user manual

Parts Description

1. Lamp glass
2. Illuminant
3. Lamp fixture
4. Clamp
5. Power plug
6. Lamp stand

Technical Data

Model No.	14162202L / 14173702L
Operating Voltage	230-240 V~, 50 Hz
Protection Class	II
IP Rating	IP20
Rated Power	max. 5 W
Illuminant	LED E14, 1 x 4.9 W, dimmable in 3 stages

Safety

Safety Notes

Damage due to failure to comply with these operating instructions will invalidate the guarantee! We assume no liability for consequential damage! We assume no liability for material damage or personal injury due to improper handling or failure to comply with the safety instructions!

Warning

Risk of fatal injury and accident hazard for toddlers and small children! Never leave children unsupervised with the packaging materials. The packaging material poses a suffocation hazard. Children frequently underestimate the dangers. Please always keep the product out of the reach of children.

Risk of Injury

Do not leave the lamp or the packaging material lying around. Plastic foils, bags, parts, etc. can become dangerous toys in the hands of children.

Start-up

Mounting the Lamp

Note: Remove all packaging material from the product. Use a clean, lint-free, dry cloth to insert the illuminant. Screw the illuminant clockwise into the lamp fixture. Place the lamp glass slightly askew on the lamp stand and carefully slide the first clamp into the lamp glass. Carefully push the lamp glass to the side until you can insert the second clamp into the lamp glass. Now slide the lamp glass as far as possible towards the third clamp. Carefully press the last clamp into the lamp glass by slightly lifting it. Slide the lamp glass into the correct position. Make sure that it is positioned correctly. Plug the power plug into a properly installed socket. Your lamp is now ready to use.

Switching On/Off the Light Fixture

Switch the lamp on and off by touching the lamp stand.

Dimming the Lamp

Note: The lamp can only be dimmed with the supplied illuminant. To dim the illuminant, briefly touch the lamp stand several times. With each touch of the dimmer, the lamp briefly turns off. The lamp switches to the next dimming stage.

Changing the Light Bulb

Switch the lamp off. **Warning! Risk of Electric Shock!** Pull the power plug out of the socket. **Caution! Danger of Burns Due to Hot Surfaces!** Allow the light to cool completely. Carefully pull the lamp glass off the lamp stand. Make sure that the clamps slide slowly out of the lamp glass. Use a clean, lint-free, dry cloth to change the illuminant. Unscrew the defective illuminant counter-clockwise from the lamp fixture. Screw a new illuminant that is compliant with the technical data clockwise into the lamp fixture. Carefully push the lamp glass over the clamps.

Make sure that all clamps are located on the inside of the lamp glass. Proceed as described in section Mounting the Lamp. Let the lamp glass carefully slide onto the lamp stand. Make sure that it is positioned correctly. Plug the power plug into a properly installed socket. Your lamp is now ready to use.

Maintenance and Cleaning

Switch the lamp off.

Warning! Risk of Electric Shock! Pull the power plug out of the socket.

Caution! Danger of Burns Due to Hot Surfaces! Allow the light to cool completely.

Warning! Risk of Electric Shock! For electrical safety, never clean the light with water or other liquids, or immerse it in water. Do not use solvents, benzene or similar substances. They could damage the light. Only use a dry, lint-free cloth for cleaning. Plug the power plug into a properly installed socket.

Disposal

The product including accessories and packaging materials can be recycled and are subject to an extended obligation of the manufacturer. Dispose of these separately in accordance with the depicted info-tri (sorting information) for better waste management. The Triman logo is only valid in France. To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.

Warranty and Service

Warranty

You receive a 36-month warranty on this product, valid from the date of purchase. The appliance has been carefully produced under strict quality control. Within the warranty period, we shall rectify without charge all material and manufacturing defects. In the event that a defect arises during the warranty period, please send the device to the listed service centre address, quoting the following model number: 14162202L / 14173702L. Wear parts (such as bulbs) and damage caused by improper handling, non-observance of the operating instructions or unauthorised interference are excluded from the warranty. The performance of services under the warranty does not extend or renew the warranty period.

Service Address

- Briloner Leuchten GmbH & Co. KG
- Am Steinbach 14
- 59872 Meschede
- GERMANY
- Tel.: +49 29 1 / 95 29 93-650
- Fax: +49 29 1 / 95 29 93-109
- E-mail: kundenservice@briloner.com www.briloner.com

Free service number: Tel.: 00800 / 27456637

Manufacturer

- Briloner Leuchten GmbH & Co. KG
- Am Steinbach 14
- 59872 Meschede

- GERMANY

Declaration of Conformity

This product fulfils the requirements of the applicable European and national directives. Conformity has been demonstrated. The relevant declarations and documents are held by the manufacturer.

FAQ

1. How do I dim the lamp?

To dim the lamp, briefly touch the lamp stand several times. The lamp will switch to the next dimming stage with each touch.

2. What should I do if the lamp doesn't turn on?

Ensure that the power plug is properly connected to a socket and that the illuminant is correctly installed. Check for any damage to the power cable or lamp fixture.























3. Can I use a different type of bulb?

Only use the type of illuminant stated in the technical data section. Using a different type may cause damage or malfunction.

4. How do I clean the lamp?

Switch off the lamp and unplug it. Use a dry, lint-free cloth for cleaning. Do not use water or other liquids.

Explanation of the pictograms used

	Read the instructions!		Risk of electric shock! Danger of death!
	This lamp is exclusively designed for use in dry indoor rooms.	IP20	The luminaire has protection class "IP20" and is intended exclusively for indoor use in private households. No protection against the ingress of water.
	Proper handling		Lumen
V	Volt		Caution! Risk of burns due to hot surfaces!
Hz	Hertz (frequency)		Illuminant - use only in a dry environment.
W	Watt (active power)		Not suited for use with external dimmers or electronic switches.
	Protection class II		Brightness of the illuminant can be adjusted in 3 stages
h	Service life		Dispose of the packaging and device in an environmentally friendly manner!
	The packaging is made of 100% recycled paper.		Observe warning notices and safety instructions!
	Colour temperature in Kelvin		Risk of death and accidents for toddlers and children!
	AC voltage (power and voltage type)		Illuminant can be exchanged by customer
Ra CRI	Colour rendering index		Polyethylene (low density)
	Corrugated cardboard		Cardboard
	Paper		Polyethylene terephthalate

LED Table Lamp With Touch Function

Introduction

Congratulations on your new product. You have selected a high quality product. Please be sure to carefully read the complete operating instructions. Fold out the page with the illustrations. These instructions are part of the product and contain important information on setup and handling. Always follow all safety instructions. Before using this product for the first time verify the correct voltage and that all parts are properly installed. Should you have any questions or you are unsure about operating the product, please contact the dealer or service centre. Please keep these instructions in a safe place and pass them on third parties as applicable.

Intended use

This lamp is exclusively designed for use in dry indoor rooms. This product is intended for private household use only. This product is intended for normal operation.

Scope of delivery


Check immediately after unpacking that the parts are complete and that the product is in proper condition.

- 1 LED Table Lamp With Touch Function 14162202L /
- 14173702L 1 Lamp glass
- 1 Lamp stand

- 1 LED illuminant (dimmable in 3 stages)
- 1 Installation and user manual

Parts description

1. Lamp glass
2. Illuminant
3. Lamp fixture
4. Clamp
5. Power plug
6. Lamp stand



Technical data

- Operating voltage 230–240 V~, 50 Hz
- Protection class: II/
- IP rating: IP20
- Rated power: max. 5 W
- Illuminant: LED E14, 1 x 4.9 W, dimmable in 3 stages
- Fixture: E14

This product contains illuminants of energy efficiency category “F”.

Safety

Safety notes

Damage due to failure to comply with these operating instructions will invalidate the guarantee! We assume no liability for consequential damage! We assume no liability for material damage or personal injury due to improper handling or failure to comply with the safety instructions!

WARNING! RISK OF FATAL INJURY AND ACCIDENT HAZARD FOR

TODDLERS AND SMALL CHILDREN!Never leave children unsupervised with the packaging materials. The packaging material poses a suffocation hazard. Children frequently underestimate the dangers. Please always

keep the product out of the reach of children.

- This device may be used by children aged 8 years and up, as well as by persons with reduced physical, sensory or mental capacities, or lacking experience and / or knowledge, so long as they are supervised or instructed in the safe use of the device and understand the associated risks. Do not allow children to play with the device. Cleaning and user maintenance must not be performed by children without supervision.

RISK OF INJURY!

- Do not leave the lamp or the packaging material lying around. Plastic foils, bags, parts, etc. can become dangerous toys in the hands of children.

Avoid the risk of fatal injury from electric shock

- Always check the light, power supply, and mains cable for damage before plugging it in. Never use the light if it shows any signs of damage.
- A damaged mains cable indicates a life-threatening danger due to electric shock. In the event of damage, repairs or other problems with the light please contact the service centre or a qualified electrician.
- Ensure that the light does not come into contact with water or other liquids under any circumstances.
- Never open any of the components of the electrical equipment or insert any objects into the same components. This will pose a risk of fatal injury from electric shock.
- Only hold the insulated section of the power plug when connecting to or disconnecting from the mains current!
- To avoid hazards, a damaged external flexible cable of this lamp may only be replaced by the manufacturer, their service representative or a comparable specialist.
- Before use, make sure that the available mains voltage matches the required operating voltage of the lamp (see "Technical data").
- Always pull the power cable out of the socket before assembling, dismantling or cleaning the lamp or if you are not going to use the lamp for a while.
- Do not place the lamp on a damp or conductive surface.



- Lamp – use only in a dry environment.



- Not suitable for external dimmers or electronic switches.
- In the event of strong mains-borne disturbances through high-frequency fields, the touch switch might fail briefly.
- If the lamp is equipped with a 3-stage dimmable illuminant, faulty activation may occur, which can impair the brightness of the illuminant.

Safe working

- Place the lamp in a location where it is protected from moisture and dirt.
- Always be attentive! Always pay attention to what you are doing and use common sense. Never install the light if you are having difficulty concentrating or do not feel well.
- Do not cover the lamp with objects. Excess heat development can lead to a fire.

- The power cable is not a carrier handle.
- Do not look into the illuminant at a close distance during operation.
- Do not look at the LED with an optical instrument (e.g. magnifying glass).
- Remove the power plug from the socket to disconnect the lamp from the power supply.
- Only use the type of illuminant stated in the “Technical data” section.

CAUTION! FRAGILE!

Light fixture is made of real glass!

Start-up

Mounting the lamp

- Note: Remove all packaging material from the product.
- Use a clean, lint-free, dry cloth to insert the illuminant 2.
- Screw the illuminant 2 clockwise into the lamp fixture 3.
- Place the lamp glass 1 slightly askew on the lamp stand 6 and carefully slide the first clamp 4 into the lamp glass 1.
- Carefully push the lamp glass 1 to the side until you can insert the second clamp 4 into the lamp glass 1.
- Now slide the lamp glass 1 as far as possible towards the third clamp 4.
- Carefully press the last clamp 4 into the lamp glass 1 by slightly lifting it.
- Slide the lamp glass 1 into the correct position.
- Make sure that it is positioned correctly.
- Plug the power plug 5 into a properly installed socket.
- Your lamp is now ready to use.

Switching on/switching off the light fixture

Switch the lamp on and off by touching the lamp stand 6 .

Dimming the lamp

Note: The lamp can only be dimmed with the supplied illuminant 2 .

To dim the illuminant 2 , briefly touch the lamp stand 6 several times. With each touch of the dimmer, the lamp briefly turns off. The lamp switches to the next dimming stage.

Changing the light bulb

Switch the lamp off.

WARNING! RISK OF ELECTRIC SHOCK!

Pull the power plug 5 out of the socket.

CAUTION! DANGER OF BURNS DUE TO HOT SURFACES!

Allow the light to cool completely.

- Carefully pull the lamp glass 1 off the lamp stand 6 .

- Make sure that the clamps 4 slide slowly out of the lamp glass 1 .
- Use a clean, lint-free, dry cloth to change the illuminant 2 .
- Unscrew the defective illuminant 2 counter-clockwise from the lamp fixture 3 .
- Screw a new illuminant that is compliant with the technical data clockwise into the lamp fixture 3 .
- Carefully push the lamp glass 1 over the clamps 4 . Make sure that all clamps 4 are located on the inside of the lamp glass 1 . Proceed as described in section “Mounting the lamp”.
- Let the lamp glass 1 carefully slide onto the lamp stand 6 .
- Make sure that it is positioned correctly.
- Plug the power plug 5 into a properly installed socket.

Your lamp is now ready to use.

Switch the lamp off.

WARNING! RISK OF ELECTRIC SHOCK!

Pull the power plug 5 out of the socket.

CAUTION! DANGER OF BURNS DUE TO HOT SURFACES!

Allow the light to cool completely.

WARNING! RISK OF ELECTRIC SHOCK!

For electrical safety, never clean the light with water or other liquids, or immerse it in water.

- Do not use solvents, benzene or similar substances. They could damage the light.
- Only use a dry, lint-free cloth for cleaning.
- Plug the power plug 5 into a properly installed socket.

Disposal



The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities. Observe the marking of the packaging materials for waste separation, which are marked with abbreviations (a) and numbers (b) with following meaning: 1–7: plastics / 20–22: paper and fibreboard / 80–98: composite materials.



The product including accessories and packaging materials can be recycled and are subject to an extended obligation of the manufacturer. Dispose of these separately in accordance with the depicted info-tri (sorting information) for better waste management. The Triman logo is only valid in France.



To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.

Warranty and service

Warranty

You receive a 36 month warranty on this product, valid from the date of purchase. The appliance has been carefully produced under strict quality control. Within the warranty period we shall rectify without charge all material and manufacturing defects. In the event that a defect arises during the warranty period, please send the device to the listed service centre address, quoting the following model number: 14162202L / 14173702L. Wear parts (such as bulbs) and damage caused by improper handling, non-observance of the operating instructions or unauthorised interference are excluded from the warranty. The performance of services under the warranty does not extend or renew the warranty period.

Service address

Briloner Leuchten GmbH & Co. KG Am Steinbach 14
59872 Meschede

GERMANY

Tel.: +49 29 1 / 95 29 93-650 Fax: +49 29 1 / 95 29 93-109 E-mail: kundenservice@briloner.com
www.briloner.com

Free service number:

Tel.: 00800 / 27456637

IAN 452551_2310

Please have your receipt and the article number (e.g. IAN 452551_2310) ready as your proof of purchase when enquiring about your product.

Declaration of conformity

This product fulfils the requirements of the applicable European and national directives. Conformity has been demonstrated. The relevant declarations and documents are held by the manufacturer.

BRILONER LEUCHTEN GMBH & CO. KG

Am Steinbach 14
59872 Meschede
GERMANY



Documents / Resources



[LIVARNO home 14173702L LED Table Lamp with Touch Function](#) [pdf] Instruction Manual 14173702L, 14173702L LED Table Lamp with Touch Function, LED Table Lamp with Touch Function, Table Lamp with Touch Function, Lamp with Touch Function, Touch Function

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.