



LIVING basics LVB-6618-6L Smart Induction Automatic Sensor Trash Can Intelligent Garbage Bin Instruction Manual

[Home](#) » [LIVING basics](#) » LIVING basics LVB-6618-6L Smart Induction Automatic Sensor Trash Can Intelligent Garbage Bin Instruction Manual 

Contents

- [1 LIVING basics LVB-6618-6L Smart Induction Automatic Sensor Trash Can Intelligent Garbage Bin Instruction Manual](#)
- [2 1. Installation and Changement of Batteries](#)
- [3 Matters need attention](#)
- [4 Read More About This Manual & Download PDF:](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)


LIVING basics LVB-6618-6L Smart Induction Automatic Sensor Trash Can Intelligent Garbage Bin Instruction Manual




1. Installation and Changement of Batteries



Before use, please tear off the insulation of the positive and negative poles of the battery and mount the battery on the positive and negative poles.



2. Infrared Induction Status indicator Manual button Induction device



- The lid will open automatically when your hands or something else enter the inductive area 20-30cm on the top of the trash can and “5” will be displayed on the status indicator.

- The lid will be closed in 5 seconds after your hands left.
- The lid will remain opening when your hands or something else keeps stay and the “5” will keep on displaying

1. Knocking mode

- When an object kicks or lightly touches any part of the sensing bin, the cover will be automatically opened, with the panel counting down: “5-4-3-2-1-0” , and closed after the timing is over.


2. Manual Control

- The lid will open when you press the manual button for 0.5-1 seconds and “H” will be displayed on the status indicator.
- The lid will close when you press the button again or it will close automatically 30 seconds later.

3. Pause Function

When the bin required to be unused for a long period, please remove the batteries from the battery box, or you can press the manual button for 5 seconds or more, it will stop working and the display “P” will be displayed on the status indicator.

4. Batteries The power of batteries will be displayed every 20 seconds: “=” For 100%, “.”=”



Matters need attention

- Proposal to place 50cm away from the other household appliances to avoid mutual interference.
- Prohibit the use of detergent or corrosive chemical cleaning agent. The body can be cleaned by water. The lid must be cleaned by a soft cloth to avoid the damage of electronic components.
- Don't try to use your hands or something else to close it when it is opening.
- Please change new batteries when it will not open after induction.

Read More About This Manual & Download PDF:

Documents / Resources

