

LIVING SPACES 2.0 USB Wireless Charger User Guide

Home » LIVING SPACES » LIVING SPACES 2.0 USB Wireless Charger User Guide 1



Contents

- 1 LIVING SPACES 2.0 USB Wireless Charger
- **2 Product Information**
- 3 Parts that make up our USB & wireless charging system
- **4 Installation Instructions**
- **5 Product Usage Instructions**
- 6 How to use the wireless charger
- 7 Documents / Resources



LIVING SPACES 2.0 USB Wireless Charger




Part	Description
Wireless charger	The wireless charger is installed beneath a wood panel with a thickness of 1~3mm. It has a diameter of 60mm and is used for wireless charging.
USB Port	The USB Port is assembled beneath the wood panel or embedded in the wood panel. It should be connected to the cables of the wireless charger and the adaptor.
Power supply	The power supply is an adapter that needs to be plugged into a wall outlet. It provides power to the USB and wireless charging system.

Parts that make up our USB & wireless charging system



- 1. Wireless charger-The wireless charger is installed beneath 1~3mm thick wood panel with diameter 60mm hole.
- 2. USB Port- The USB Port should be connected to the cables of wireless charger and the adaptor. The USB port is assembled beneath the wood panel or embedded in the wood panel.
- 3. Power supply-The power supply is an adapter plugged into wall or outlet.

Installation Instructions




- 1. The wireless charger is suitable for wood panel thickness within 18-25mm.
- 2. Drill a 60mm blind hole beneath the wood panel and keep it 1~3mm thick on top.
- 3. Embed the wireless charger in the blind hole and assemble it with screws.
- 4. Assemble the USB port under the panel.
- 5. Connect all wiring ports of the product and connect the adapter to AC 220V/110V.



Product Usage Instructions

- 1. Check all connections:
 - Ensure that the power supply is plugged into a wall outlet.
 - Insert the USB cable into the USB device and a phone.



2. Make sure your phone is compatible with wireless charging pad.

Compatible phone models include:

• Apple: iPhone 8 to iPhone 14 series

• Samsung: S7 to S22 series, Fold 4, Flip 4

• Google: Pixel 4 to above

Sony: Xperia XZ2 to above

• Huawei: Mate 20 to above series

- · LG: G3 to above series
- 3. Place your phone in the center of the charging surface.



4. Check the indicator light condition (applies to the wireless charger):

Indicator Light	Description
Blue LED	Indicates that the charger is connected to power.
Light on for 5 seconds and then off	Indicates that the charger is powered on.
Light Off	Indicates standby mode.
Light Constant On	Indicates that wireless charging is in progress.
Light Off	Indicates that charging is completed.
Light Blinking Constantly	Indicates an abnormal state.
Light Blinking Constantly	Indicates foreign object detection. Check for any metal substance between the phone and the furniture top.

- 5. If the indicator light is on when there is no phone on the wireless charger, you may need to replace the wireless charger.
- 6. If the indicator light is blinking constantly when the phone is wirelessly charging, check for any metal substance between the phone and the furniture top. Alternatively, try moving the phone around to ensure it is correctly positioned over the wireless charger. If the issue persists, remove the phone for about half a minute and then place it back on the charger.
- 7. Check the USB individually by plugging in the USB cable.

How to use the wireless charger

Connect micro power adapter to electrical outlet and check if the USB port can work smoothly.



Place the phone with wireless charging enabled on the center of the charging pad.







*Not all phone cases allow for wireless charging.

Trouble shooting guide to USB & Wireless Charger installed on Upholstery Units.



Documents / Resources



<u>LIVING SPACES 2.0 USB Wireless Charger</u> [pdf] User Guide 2.0, 2.0 USB Wireless Charger, USB Wireless Charger, Wireless Charger

Manuals+,