



Lixel L2 PRO XGRIDS 16 Channel Real Time 3D Scanner User Manual

[Home](#) » [Lixel](#) » Lixel L2 PRO XGRIDS 16 Channel Real Time 3D Scanner User Manual 



**Lixel L2 PRO
User Manual**




Contents

- 1 Product Overview
- 2 Operation
- 3 Tripod Installation
- 4 Function Button
- 5 Indicator Light Description
- 6 Data Copy Description
- 7 Battery
- 8 Maintenance
- 9 Matters needing attention
- 10 Appendix
- 11 CE Maintenance
- 12 FCC Warning
- 13 Documents / Resources
 - 13.1 References

Product Overview

Lixel L2 PRO, a highly integrated and lightweight handheld 3D reconstruction device. With the 3D real-time reconstruction algorithm, Lixel L2 PRO can directly obtain the true color point cloud. The results are calculated in real time and can be viewed and used immediately.

About Lixel L2 PRO




Operation

Battery installation

1. Open the lever.
2. Insert the battery into the bottom of the device along the guide dovetail slot. Ensure that the battery is inserted

into the correct position.


3. Press the lever back and lock the battery tightly.



Note: An unsecured battery may cause the device to slip.

Tripod Installation

The bottom of the battery has threaded holes. Screw the tripod in and place the device in a flat position.



Function Button

Function	Operation	State
Open	Long press 4 seconds	The indicator light turns from slow blinking blue light to steady green light;
Close	Long press 4 seconds	Indicator light off;
Start Scanning	Double Click	When the device is in standby state, double-click the indicator. The indicator status changes from steady green to blinking green at short intervals and then to blinking green at long intervals. And the lidar starts to rotate, that is, the scan is started successfully.
Stop Scanning	Double Click	When scanning, double click the button, the indicator state will change from green slow flashing to green quick flashing and then to steady green. Meanwhile, the lidar will stop rotating and the scanning will be stopped successfully.

Note:

1. Please put the device on the flat table before starting the scan. After starting the scan, the device can be moved for scanning only after the lidar rotates.
2. It takes about 10 seconds to start scanning.
3. During the scanning stop, if the indicator blinks green quickly, scanned files are being stored. If the power is off at this time, files may be lost or saved incompletely.
4. After the scan is stopped, the waiting time for stored files may be long, it's depending on the size of the scene being scanned.

Indicator Light Description

Indicator blinking status	Significance
None	The device is not started.
The blue light blinking slowly	The device is starting up.
Blue light normally on	USB disk mode
Green light normally on	The device is in standby state
The green light blinking fast	The scan is being started/stopped
The green light blinking slowly	Scanning
Yellow light normally on	The device is not activated
Red light normally on	Serious device failure


Data Copy Description

Use the USB cable that matches the device. Connect the device to the computer in standby mode and turn on the USB mode in the App. After identifying the device, the data can be copied.

Note:

1. The USB mode is automatically disabled after a restart.
2. After turning on the USB mode, you need to manually turn off the USB mode if you want to continue scanning without shutting down or power off.
3. Using a non-standard USB cable may cause slow data copy. Or may cause forward insertion can be used, reverse insertion can not be used.

Battery




Use the standard charging cable and connect the charging adapter to the battery to charge the battery. Charging time: about 2 hours. During the charging process, the indicator light will show the current electric quantity. Please refer to the following table for details.

Indicator blinking status	electricity
Only one green light on	0-24%
Two green lights on	25%-49%
Three green lights on	50%-74%
Four green lights on	75%-99%

Maintenance

The storage status of the device is as shown in the figure below. After use, remove the battery and put it back into the storage box according to the figure.

Note: It is a precision device, not storing as required may cause damage to the device.



Matters needing attention

1. Lixel L2 PRO is a precision device. Falling or being hit by external forces may damage the equipment and result in abnormal or inaccurate accuracy.
2. When using a tripod, ensure that the tripod and the device are tightened to prevent the device from falling.
3. Ensure that after Lixel L2 PRO is turned on, lidar rotation is not blocked by external forces.
4. Lixel L2 PRO waterproof grade is IP54, do not use in the environment beyond this protection grade. Use a soft dry cloth or standard cleaning cloth to clean the device. Keep the lidar and the camera clean, do not touch it directly.
5. The device will generate heat during use. Please do not touch the fuselage to avoid burns.
6. Do not cover or touch the heat sink during use. The device may automatically shut down when the temperature is too high.

Appendix

Specification

Parameter	XGRIDS
In put	14.4V
Power	<30W
Size	138mm*90mm*381mm
weight	About 1.9kg
Data socket	USB 3.1 Gen2
Internal storage	1T SSD
Wireless module	Wifi, Bluetooth 802.11a/b/g/n/ac, 2.4~2.4835Ghz or 5.15~5.85Ghz
Operating Temp Range	-20°C~50°C
IP level	IP54
Shell material	aviation aluminum
Power supply	Removable integrated battery
Single usage duration	1.5h
Battery capacity	46.8wh
Camera Quantity	3
Visually assisted positioning	Support
APP WIFI distance	20 M without interference
The laser line number	16
Laser level	Class 1 / 905nm
Relative accuracy	<2cm
Repeat accuracy	<1cm
Scan effective distance	120m
FOV	360°×270°
Scanning mode	Mobile
Point cloud frequency	320000 points /s
Environmental requirements	Indoor/Outdoor
Single working duration	60mins
Resume breakpoint	Support

CE Maintenance

1. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
2. The product shall only be connected to a USB interface of version USB3.0.

- 3. EUT Operating temperature range: -20° C to 50° C .
- 4. Adapter

The plug considered as disconnect device of adapter Input: AC 100240V, 50/60Hz,1.5A
Output: 16.8V 2A

Declaration of Conformity

SHENZHEN XGRIDS-INNOVATION CO., LTD hereby declares that this Lixel L2 PRO is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. This product is allowed to be used in all EU member states.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Product after-sales information

Please check the XGRIDS website www.xgrids.cn for the latest after-sales information.

Documents / Resources

	Lixel L2 PRO XGRIDS 16 Channel Real Time 3D Scanner [pdf] User Manual L2 PRO, L2 PRO XGRIDS 16 Channel Real Time 3D Scanner, XGRIDS 16 Channel Real Time 3D Scanner, 16 Channel Real Time 3D Scanner, Real Time 3D Scanner, Time 3D Scanner, 3D Scanner, Scanner
---	---

References

- [XGRIDS - Lixel L1- - - SLAM- -](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.