

Loa AVA Plus Go Z09 Bluetooth Speaker



Loa AVA Plus Go Z09 Bluetooth Speaker User Manual

[Home](#) » [Loa](#) » Loa AVA Plus Go Z09 Bluetooth Speaker User Manual 

Contents

- [1 Loa AVA Plus Go Z09 Bluetooth Speaker](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Packing list](#)
- [5 Key function direction](#)
- [6 Telephone function](#)
- [7 Bluetooth Connection](#)
- [8 Mode button](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

Loa

Loa AVA Plus Go Z09 Bluetooth Speaker



Product Specifications

- **Weight:** 80g
- **Dimensions:** 75x75mm

Product Usage Instructions

Power On/Off

- To power on the speaker, long press the power button for 3 seconds in the shutdown state.
- The speaker will emit a ting, ting sound and the RGB light will flash.
- To power off, long press the power button for 3 seconds in the boot state.
- The speaker will again sound ting, ting.

Telephone Function

- **Short press:** Answer
- **Double-click:** Turn off sound
- **Long press:** Refuse call
- **Short press (after connecting):** Hang up call

Type-C Charging

1. Use a DC5V~1A USB power adapter
2. The red light turns off when fully charged

Bluetooth Connection

1. Press and hold the power key for 3 seconds to enter pairing mode
2. Search for Bluetooth code name AVA+ Go Z09 on your phone and click to pair
3. Upon successful pairing, you will hear a prompt tone and see connected' on your phone
4. Subsequent use will automatically connect if Bluetooth is on

Mode Button

- Bluetooth
- FM mode
- TF card

TWS Function

1. Open two devices without connecting in Bluetooth mode
2. Double press the Pause/play button on either speaker for successful pairing and connection
3. Search for Bluetooth code name AVA+ Go Z09 on your phone and click to use this function

Frequently Asked Questions (FAQ):


Q: How do I clean the product?

- **A:** Do not use abrasive cleaners to clean the product. Use a soft, damp cloth for cleaning.


Q: Can I use the speaker near a heat source?

- **A:** Do not allow the product to be heated or placed close to a fire source to prevent damage.
- Thank you for purchasing Bluetooth Speaker AVA+ Go Z09 Please carefully read the user guide properly and keep this for further reference.

Packing list



1 pc speaker




1 pc Type-C charging cable



1 pc user manual

Key function direction



1. Power Button
2. Play/Pause
3. Previous track/Volume down
4. Mode Button
5. Next track/Volume up


Power On/Off

- **Power On:** Long press the power button for 3 seconds in the shutdown state; when the speaker starts up, the speaker will sound “ting, ting” and the RGB light will flash.
- **Power off:** Long press the power button for 3 seconds in the boot state to shut down the speaker. The speaker will say “ting, ting”.
- Short press the “⏮” button when playing music, and the player will play the last track;
- Long press “⏮” to decrease the volume continuously

- Short press the "⏮" button when playing music, and the player will play the next track;
- Long press "⏮" to increase the volume continuously

Telephone function

- When calling on the phone, short press "📞" to answer, double-click to turn off the sound, long press to refuse, and short press to hang up the call after connecting.



Type C charging

1. Charging with a DC5V~1A USB power adapter
2. When the speaker is fully charged, the red light will turn off.

Bluetooth Connection

1. Press and hold the power key for 3s to start the machine, there is a prompt tone, and Bluetooth enters the pairing mode.
2. Turn on the mobile phone, turn on Bluetooth, search for the Bluetooth code name "AVA+ Go Z09 " and click; after a few seconds, you will hear the prompt tone of successful pairing and connection, and the mobile phone displays connected.
3. In subsequent use, as long as the device's bluetooth is turned on, it can be automatically connected.
 - **Note:** If you want to connect to another device, need to disconnect the bluetooth on the current device which is connecting bluetooth to the speaker



Mode button

Click on the **M** bluetooth, FM mode, and TF card;

Playing MP3 files from Micro SD:

1. Insert Micro SD card into TF Slot.
2. Play, pause, or skip a selected track using the controls on the speaker.

FM mode:

- Press the M button into FM mode, short press the pause/play button to search the station automatically, and press again to stop searching. Then, short press “+”, and “-” to choose the FM station.
- **Note:** In the FM mode, there needs in charging cable to increase the FM radio signal

TWS function

- While at the same time open two devices and connect in the bluetooth mode, double press the Pause/play button of either of the speakers, and then, you will hear the prompt tone of successful pairing and connection.
- You search for the Bluetooth code name “AVA+ Go Z09 ” and click to use this function.

Attention:

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated, close to a fire source, or in direct sunlight for a long time. It will easy to burn and damage the electronic components.
3. Do not attempt to disassemble this product to make any modifications.
4. Do not use this product in the rain.
5. If you do not plan to use this product for a long time, please store it in a dry environment and charge the speaker at least once a month to prolong its life and avoid extreme temperatures and dust.
6. If you see smoke coming out of the machine or other improper phenomenon, please contact the retailer to solve the issue immediately.
7. Do not throw the machine.

Note!

- To improve product performance, our products are constantly updated.
- It is no additional notice about technical issues and this manual is for reference only, please forgive.
- Thank you for your purchase.

Documents / Resources



[Loa AVA Plus Go Z09 Bluetooth Speaker](#) [pdf] User Manual
AVA Plus Go Z09 Bluetooth Speaker, AVA Plus Go Z09, Bluetooth Speaker

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.