



Lock Lock HPL825 Classic Rectangular Food Container Instructions

[Home](#) » [Lock Lock](#) » Lock Lock HPL825 Classic Rectangular Food Container Instructions 

Contents

- [1 Lock Lock HPL825 Classic Rectangular Food Container](#)
- [2 Use And Specification](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

LOCK&LOCK


Lock Lock HPL825 Classic Rectangular Food Container



Use And Specification

- Wash thoroughly before first use.
- Freezer, microwave, and dishwasher (top rack recommended) safe.
- Leave the lid loose in the microwave.
- Use only for reheating purposes, not for cooking.
- Use caution when reheating foods with high sugar, fat, tomato or curry-based content may cause staining.
- Heat food in small time increments of no longer than 2 minutes and stir well for ideal results.
- Leave frozen containers at room temperature for a while to avoid any breakage.
- Do not use in direct contact with naked flame.
- **Material:**
 - Body, Lid – Polypropylene (-200C ~ 100C),
 - Packing – Silicone (-400C ~ 2000C)

Documents / Resources

	<p>Lock Lock HPL825 Classic Rectangular Food Container [pdf] Instructions HPL825 Classic Rectangular Food Container, HPL825, Classic Rectangular Food Container, Rectangular Food Container, Food Container, Container</p>
---	--

References

- [User Manual](#)

