

# LOCKER DOWN LD2042/LD2042EX Down Exxtreme Console Loacker Installation Guide

Home » LOCKER DOWN » LOCKER DOWN LD2042/LD2042EX Down Exxtreme Console Loacker Installation Guide ™

#### **Contents**

- 1 LOCKER DOWN LD2042/LD2042EX Down Exxtreme Console Loacker
- **2 INSTALLATION INSTRUCTIONS**
- **3 Tools Needed**
- 4 Contents Included
- **5 Documents / Resources**
- **6 Related Posts**



LOCKER DOWN LD2042/LD2042EX Down Exxtreme Console Loacker



## **INSTALLATION INSTRUCTIONS**

- For any combination style lock, it is a good idea to set the combination before installing the safe. We
  recommend that the combination be set with the DOOR OPEN in order to test thelock combination effectively
  without locking yourself out.
- 2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
- 3. Remove the 2 plastic file holders on either side of the console compartment.
  - These are removed by pulling outward on the center of the tab, then forward towards the front of the console.
- 4. Remove the 2 10mm bolts at the bottom of the console compartment.
- 5. Remove the padding from the bottom of the inside of the safe.
- 6. Set the safe into the center console.
  - To ensure that the console is set in properly, make sure that the factory cut holes at the BOTTOM of the safe line up with the bolt holes from STEP 5.
- 7. Using your 10mm fastening device, insert the LOCK'ER DOWN PROVIDED 10MM BOLTS into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
- 8. Tighten the bolts, DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.
- 9. Re-insert the padding that was removed from the safe before installation.
- 10. Re-insert the 2 file holders that were removed in STEP 3.
- 11. Enjoy your purchase!

### **Tools Needed**

• IMPACT DRILL or SOCKET WRENCH

• 10mm Socket bit

## **Contents Included**

• 2 10mm Bolts.

## **Documents / Resources**



LOCKER DOWN LD2042/LD2042EX Down Exxtreme Console Loacker [pdf] Installation Gui de

LD2042 LD2042EX Down Exxtreme Console Loacker, LD2042, LD2042EX, LD2042 Down Exxtreme Console Loacker, LD2042EX Down Exxtreme Console Loacker, Down Exxtreme Console Loacker, Down Exxtreme Loacker, Console Loacker, Loacker

Manuals+,