



LOGICOOL Complete Standard Range U-PZ3 Instruction Manual

[Home](#) » [LOGICOOL](#) » LOGICOOL Complete Standard Range U-PZ3 Instruction Manual 

LOGICOOL Complete Standard Range U-PZ3 Instruction Manual





Contents



- [1 Overview](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)



Overview

1	Mounting Hole (4-R6.5), anchor bolt:M10
2	Refrigerant tubing (liquid tube), flared connection (06.35)
3	Refrigerant tubing (gas tube), flared connection (012.7)




1	Mounting hole (4-R6.5), anchor bolt : M10
2	Refrigerant tubing (liquid tube). flared connection (0 6.35)
3	Refrigerant tubing (gas tube), flared connection U-60PZ3E5 (012.7) U-71PZ3E5 (015.88)









1	Mounting hole (4-R6.5), anchor bolt : M10
2	Refrigerant tubing (liquid tube) flared connection (09.52)
3	Refrigerant tubing (gas) flared connection (15.88)
4	Refrigerant tubing port
5	Electrical wiring port (013)
6	Electrical wiring port (022)
7	Electrical wiring port (027)
8	Electrical wiring port (035)




When using a drain pipe, install the drain socket (field supply) on to the drain hole. Seal the other drain hole with the rubber cap.



A VIEW





[LOGICOOL Complete Standard Range U-PZ3](#) [pdf] Instruction Manual

LOGICOOL, Complete, Standard, Range, U-PZ3