



logitech 2SMX Master Wireless Mouse User Manual

[Home](#) » [Logitech](#) » logitech 2SMX Master Wireless Mouse User Manual 

Contents

- [1 logitech 2SMX Master Wireless Mouse](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 GETTING STARTED](#)
- [5 Product Overview](#)
- [6 Features](#)
- [7 Gesture button](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

logitech®

logitech 2SMX Master Wireless Mouse



Product Information

The MX MASTER 2S is a high-performance mouse designed to enhance your productivity and provide a seamless user experience. It offers various features and customization options to cater to your specific needs.

Features:

- **Speed adaptive scroll-wheel:** The scroll wheel automatically shifts between two scrolling modes based on your touch, providing precise control over scrolling through web pages.
- **Easy-Switch™ button:** Allows you to connect the mouse with up to three different computers and switch between them effortlessly.
- **Bluetooth and Unifying receiver compatibility:** Choose to pair the mouse with your computer using either Bluetooth or the provided Unifying receiver.
- **Thumb wheel:** Enables effortless side-to-side scrolling with a stroke of your thumb.
- **Gesture button:** Streamline navigation and desktop management by enabling gestures for media control, panning, zooming, rotation, and custom tasks.
- **Back/Forward buttons:** Located conveniently at your thumb, these buttons enhance navigation and simplify tasks.
- **Battery life:** With a minimum of 3 minutes of charging, the mouse can provide a full day of use. A full charge can last up to 70 days, depending on usage.

Product Usage Instructions

1. **Step 1:** Download Logitech Options software from logitech.com/options. This software unlocks the full potential of the MX MASTER 2S.
2. **Step 2:** Turn on the mouse.
3. **Step 3:** The mouse allows you to connect it with up to three different computers. Use the Easy-Switch™ button to change the channel and select the desired channel for connection.
4. **Step 4:** To connect your mouse to your computer, press the Easy-Switch™ button for 3 seconds. The mouse will enter discoverable mode, indicated by fast blinking.
5. **Step 5:** Choose whether to pair the mouse with Bluetooth or the provided Unifying receiver, based on your preference.
6. **For advanced customization and features:**
 - – **Enable SmartShift™:** Go to the Point and scroll tab in Logitech Options software, select “Enable” from the SmartShift pull-down menu.
 - – **Turn off SmartShift™:** Select “Disable” from the SmartShift pull-down menu. This allows manual switching between scrolling modes.
 - – **Set a fixed scroll wheel mode:** In the Point and scroll tab, select either “Ratchet” or “Freewheel” from the Fixed scroll wheel mode pull-down menu. This locks the scroll wheel to a specific mode.
 - **Note:** Fixed scroll wheel mode can only be activated if SmartShift™ is disabled and mode shift is not assigned to any MX Master button.
7. **For gesture controls:**
 - – Install Logitech Options software to enable gestures for media control, panning, zooming, rotation, and custom tasks.

- – Assign up to five different actions to the Gesture button.
Alternatively, map gestures to other MX Master buttons.
- – On Mac, enabling back/forward buttons requires installation of Logitech Options software. It also offers additional customization options for these buttons.

For more information and troubleshooting, refer to the MX Master 2S FAQ page.

Please note that the mentioned features and instructions are based on the provided user manual. Always refer to the official documentation for the most accurate and up-to-date information.

GETTING STARTED

Questions about your MX MASTER 2S? We've got the answers, videos, downloads and information you need. Search for articles or select a topic below to get started.

- **Step-1**



Download Logitech Options to use all the possibilities this mouse has to offer. To download and learn more about the possibilities go to logitech.com/options.

- **Step-2**



Turn your mouse on.

- **Step-3**



This mouse allows you to use it with up to three different computers. Just use the Easy-Switch™ button to change the channel. Select the channel you want and go to the next step.

- **Step-4**



To connect your mouse to your computer press the Easy-Switch™ button for 3 seconds. When it blinks fast it means it's in discoverable mode.

- **Step-5**



Choose if you want to pair with Bluetooth or with the provided Unifying receiver.

Product Overview

MX MASTER 2S AT A GLANCE



1. Speed-adaptive scroll wheel
2. Manual shift button
3. Gesture button
4. Micro USB port
5. On/Off button
6. Darkfield high precision sensor
7. Easy-Switch & connect button
8. Battery status LED
9. Thumb wheel
10. Back/forward buttons

Features


Speed adaptive scroll-wheel If SmartShift™ is enabled, the speed-adaptive scroll wheel shifts between two scrolling modes automatically, in response to your touch.

- Click-to-click (ratchet) mode — ideal for precise navigation of items and lists.
- Hyper-fast (freewheel) mode — near-frictionless spinning, letting you fly through long documents and web pages.



Enable SmartShift

Select Enable from the SmartShift pull-down menu on the Point and scroll tab.



Turn off SmartShift by selecting Disable from the SmartShift pull-down menu. When SmartShift is disabled, spinning or braking the scroll wheel has no effect on the current scrolling mode.


Switch modes manually

Whether SmartShift is enabled or disabled, you can manually switch between modes by pressing the mode shift button. By default, mode shift is assigned to the button on top of the mouse. (Check current button assignments on the Mouse tab.)



Set a fixed scroll wheel mode

If you prefer to use just one mode, you can fix the scroll wheel to either click-to-click (ratchet) or hyper-fast (freespun) mode. On the Point and scroll tab, select Ratchet or Freespun from the Fixed scroll wheel mode pull-down menu.



IMPORTANT!

You can fix the scroll wheel mode only if SmartShift is disabled and mode shift is not assigned to any MX Master button.


To activate fixed scroll wheel mode:

- Select Disable from the SmartShift pull-down menu.
- On the Mouse tab, click the highlighted mode shift button and select an action other than mode shift.

For more help, see the MX Master 2S FAQ page

Thumb wheel

Scroll side to side effortlessly with a stroke of your thumb.



To scroll horizontally:

- Spin the thumb wheel up (to scroll right) or down (to scroll left)

Install Logitech Options software to extend thumb wheel capabilities:

- Invert scrolling direction
- Reproduce touch-based gestures
- Adjust scrolling speed and resolution
- Navigate tabbed content
- Switch apps
- Swipe between full-screen apps (Mac only)
- Switch between full-screen apps (Windows 8 only)
- Zoom in and out
- Adjust volume

- Control screen brightness
- Display notifications (Mac only)

Gesture button

GESTURES STREAMLINE NAVIGATION AND DESKTOP MANAGEMENT

Install Logitech Options software to enable gestures for managing media, panning, zoom, and rotation, plus custom tasks.

Assign up to five different actions to the Gesture button. Or map gestures to other MX Master buttons, including the middle button or manual shift button.



To perform a gesture:

- Hold down the Gesture button while moving the mouse left, right, up, or down.

The figure below shows the gestures for managing windows in Windows 8 and in Mac OS X.



Back/Forward buttons

Conveniently located at your thumb, the back and forward buttons enhance navigation and simplify tasks.



To move back and forward:

- Press the back or forward button to navigate web or document pages, depending on the location of the mouse pointer.

NOTE: On the Mac, enabling of the back/forward buttons requires installation of Logitech Options software. Install Logitech Options software to unlock new capabilities for the back/forward buttons. In addition to enabling the buttons for use with Macs, Logitech Options software lets you map other useful functions to the buttons, including OS navigation, zoom, dictionary lookup, and more.

Battery



1 – Charging cable

RECHARGE MX MASTER 2S

- Connect one end of the provided charging cable to the Micro-USB port on the mouse and the other end to a USB power source.
- A minimum of 3 minutes charging gives you enough power for a full day of use. Depending on how you use the mouse, a full charge can last up to 70 days*.
- * Based on eight hours of daily use. Battery life may vary depending on user and operating conditions.

CHECK BATTERY STATUS


Three LED lights on the side of the mouse indicate battery status.







Install Logitech Options software to receive battery status notifications, including low-charge warnings.

LEDs Lit	Color	Indications
3	Green	100% Charge
2	Green	66% Charge
1	Green	33% Charge
1	Red	10% Charge Recharge now!

Documents / Resources

	logitech 2SMX Master Wireless Mouse [pdf] User Manual 2SMX Master Wireless Mouse, 2SMX, Master Wireless Mouse, Wireless Mouse, Mouse
---	---

References

-  [Download Logitech Options Customization Software](#)
-  [Logitech Support + Download](#)
-  [Connect your Logitech Bluetooth device – Logitech Support + Download](#)
-  [Connect your device to a Logitech USB receiver – Logitech Support + Download](#)
- [User Manual](#)