

logitech

5099206098862_n_0 MX
Keys Mini Wireless
Keyboard



Logitech 5099206098862_n_0 MX Keys Mini Wireless Keyboard User Guide

[Home](#) » [Logitech](#) » Logitech 5099206098862_n_0 MX Keys Mini Wireless Keyboard User Guide 

Contents

- 1 [Logitech 5099206098862_n_0 MX Keys Mini Wireless Keyboard](#)
- 2 [Specifications](#)
- 3 [Product Overview](#)
- 4 [Product Usage Instructions](#)
- 5 [DETAILED SETUP](#)
- 6 [Product Overview](#)
- 7 [FAQS](#)
- 8 [Documents / Resources](#)
 - 8.1 [References](#)

logitech

Logitech 5099206098862_n_0 MX Keys Mini Wireless Keyboard



Specifications

- **Compatibility:** Windows 10 or later, macOS 10.15 or later, iOS 13.4 or later, iPad 14 or later, Linux, ChromeOS, Android 5 or later
- **Colors:** Rose, Pale Gray, Graphite
- **Backlight Levels:** 8 levels
- **Connectivity:** Bluetooth
- **Charging:** USB-C cable

Product Overview

Your MX Keys Mini keyboard is designed to offer a seamless typing experience across multiple devices and operating systems. It features new F-row keys for dictation, emojis, and microphone controls. The keyboard comes in three stylish colors and offers compatibility with various operating systems.

Product Usage Instructions

• Turning On the Keyboard

To ensure the keyboard is turned on, check if the LED on the Easy-Switch button is rapidly blinking. If not, perform a long press for three seconds.

• Connecting via Bluetooth

Connect your device to the keyboard via Bluetooth. If you encounter any issues, refer to the Bluetooth troubleshooting guide.

• Installing Logitech Options Software

Download Logitech Options software from logitech.com/options to unlock all the features of your keyboard. The software is compatible with both Windows and Mac operating systems.

• Battery Status and Charging

Your keyboard features an LED near the On/Off switch to indicate battery status. Green indicates 100% to 11%, while red indicates 10% and below. To charge, use the USB-C cable at the top right corner of the keyboard. You can continue typing while it charges.

• Smart Backlighting

The keyboard's ambient light sensor adjusts backlighting based on room brightness. You can change the backlight level, with exceptions when the battery is low or certain software notifications are active.

DETAILED SETUP

1. Make sure the keyboard is turned on.

The LED on the Easy-Switch button should rapidly blink. If not, perform a long press for three seconds.



2. Connect your device via Bluetooth:

- Open the Bluetooth settings on your computer to complete the pairing.
- Click here for more details on how to do this on your computer. If you experience issues with Bluetooth, click here for Bluetooth troubleshooting.

3. Install Logitech Options Software.

Download Logitech Options to use all the possibilities this keyboard has to offer. To download and learn more,

go to logitech.com/options.

PAIR TO A SECOND COMPUTER WITH EASY-SWITCH

Your keyboard can be paired with up to three different computers using the Easy-Switch button to change the channel.

1. Select the channel you want using the Easy-Switch button — press and hold the same button for three seconds. This will put the keyboard in discoverable mode so that it can be seen by your computer. The LED will start blinking quickly.
2. Open the Bluetooth settings on your computer to complete the pairing. You can read more details [here](#).
3. Once paired, a short press on the Easy-Switch button lets you switch channels.


INSTALL SOFTWARE

- Download Logitech Options to use all the possibilities this keyboard has to offer. To download and learn more, go to logitech.com/options.
- The software is compatible with Windows and Mac.



New F-row keys

1. Dictation
2. Emoji
3. Mute/unmute microphone



Dictation




The dictation key lets you convert speech-to-text in active text fields (notes, email, and so on). Simply press and start speaking.

Emoji



You can quickly access emojis by pressing the emoji key.

Mute/unmute microphone



You can mute and unmute your microphone with a simple press during video conferencing calls. To enable the key, download Logi Options here.

Product Overview


1. PC layout
2. Mac layout
3. Easy-Switch keys
4. ON/OFF switch
5. Battery status LED and ambient light sensor
6. Dictation
7. Emoji
8. Mute/unmute microphone




Multi-OS keyboard

Your keyboard is compatible with multiple operating systems (OS): Windows 10 or later, macOS 10.15 or later, iOS 13.4 or later, iPadOS 14 or later, Linux, ChromeOS, and Android 5 or later.

If you are a Windows, Linux, or Android user, your special characters will be on the right side of the key:



If you are a macOS or iOS user, your characters and special keys will be on the left side of the key:



Battery Status Notification

Your keyboard has an LED near the On/Off switch to let you know the battery status. The LED will be green from 100% to 11% and turn red from 10% and below. Turn off the backlighting to continue typing for more than 500 hours when the battery is low.



To charge, plug in the USB-C cable at the top right corner of your keyboard. You can continue typing while it is charging.

Smart backlighting

Your keyboard has an embedded ambient light sensor that reads and adapts the level of backlighting accordingly.

Room brightness	Backlight level
Low light – under 100 lux	L4 – 50%
High light – over 100 lux	L0 – no backlight* *Backlight is turned OFF.

There are eight total backlight levels. You can change the backlight level at any time with two exceptions: the backlight cannot be turned ON when:

- the room brightness is high, over 100 lux
- the keyboard battery is low

Software notifications

Install Logitech Options software to get the most out of your keyboard. You can find more information [here](#).

- **Backlight level notifications**



- You can see the backlight level changes in real -time.

- **Backlighting disabled**

- There are two factors that will disable backlighting:




- When your keyboard has only 10% of battery left, this message will appear when you try to enable backlighting. If you want the backlight back, plug in your keyboard to charge it.



- When the environment around you is too bright, your keyboard will automatically disable backlighting to avoid using it when not needed. This will also allow you to use it longer with backlight in low light conditions. You will see this notification when you try to turn backlighting ON.


- **Low battery**



- When your keyboard reaches 10% of battery left, backlighting turns OFF and you get a battery notification on the screen.

- **F-Keys switch**

- When you press Fn + Esc you can swap between the Media keys and F-Keys. We've added a notification so you know when you've swapped the keys.



NOTE:

By default, the keyboard has direct access to Media Keys.

Logitech Flow

- You can work on multiple computers with your MX Keys Mini. With a Flow-enabled Logitech mouse, such as MX Anywhere 3, you can also work and type on multiple computers with the same mouse and keyboard using Logitech Flow technology.
- You can use the mouse cursor to move from one computer to the next. MX Keys Mini keyboard will follow the mouse and switch computers at the same time.
- You can even copy and paste between computers. You will need to install Logitech Options software on both computers and then follow these instructions.
- Click [here](#) for a list of our Flow-enabled mice.



FAQS

- **Q: Can I use the MX Keys Mini with multiple devices?**

A: Yes, the keyboard is compatible with multiple operating systems and devices. You can seamlessly switch between them using the Easy-Switch keys.


- **Q: How do I access dictation and emoji functions?**

A: Use the dedicated F-row keys for dictation and emojis. Press the corresponding key to activate these functions on your device.

- **Q: How can I mute/unmute my microphone during video calls?**

A: Simply press the designated key on the keyboard to mute or unmute your microphone during video conferencing calls.

Documents / Resources

	Logitech 5099206098862_n_0 MX Keys Mini Wireless Keyboard [pdf] User Guide 5099206098862_n_0, 5099206098862_n_0, MX Keys Mini Wireless Keyboard, Mini Wireless Keyboard, Wireless Keyboard, Keyboard
---	--

References

- [logi Download Logitech Options Customization Software](#)
- [logi Download Logitech Options Customization Software](#)
- [logi Set up and enable Logitech Flow for use with a mouse – Logitech Support + Download](#)
- [logi Bluetooth troubleshooting for Logitech Bluetooth Mice, Keyboards and Presentation remotes – Logitech Support + Download](#)
- [logi Connect your Logitech Bluetooth device – Logitech Support + Download](#)
- [logi Download Logitech Options Customization Software](#)
- [logi Logitech Flow Multi-Device Control and Easy File Sharing](#)
- [logi Logitech Support + Download](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.