logitech BOBTNY72VD Wave Keys For Business





logitech B0BTNY72VD Wave Keys For Business User Guide

Home » Logitech » logitech B0BTNY72VD Wave Keys For Business User Guide 🖫

Contents

- 1 logitech B0BTNY72VD Wave Keys For Business
- 2 Specifications
- **3 Product Usage Instructions**
- 4 FAQ
- **5 KNOW YOUR PRODUCT**
- **6 GETTING STARTED**
- **7 INSTALLATION INSTRUCTION**
- **8 KEYBOARD FUNCTIONS**
- 9 MULTI-OS KEYBOARD
- **10 BATTERY STATUS NOTIFICATION**
- 11 Documents / Resources
 - 11.1 References



logitech B0BTNY72VD Wave Keys For Business



Specifications

• Connection: Logi Bolt receiver or Bluetooth

• Operating Systems: Windows, macOS, ChromeOS

• Power Source: Batteries (AA x2)

Product Usage Instructions

Connection Setup

To pair through Logi Bolt receiver:

- 1. Take the Logi Bolt receiver from the packaging tray that was holding your keyboard.
- 2. Insert the receiver into any available USB port on your desktop or laptop.
- 3. Remove the pull tabs from the keyboard to turn it on.
- 4. Ensure a successful connection by checking the white LED on the connection key.

Keyboard Layout Setup

Set the right keyboard layout for your operating system:

- 1. If using Windows, no additional steps are needed.
- 2. For macOS or ChromeOS, follow the on-screen instructions to input a passcode and complete pairing.

Dongle Compartment

If not using the Logi Bolt USB receiver:

- 1. Remove the battery door from the bottom side of your keyboard.
- 2. Locate the dongle compartment next to the batteries.
- 3. Place the Logi Bolt receiver in the compartment and secure it tight.

Keyboard Functions


Utilize the various functions on your keyboard:

- F1-F12 keys have primary and secondary functions for different operating systems.
- Additional keys like Task View, Dictation, Emoji, Mute Mic, Volume Control, etc., provide enhanced productivity.
- Note specific key functions that may require Logi Options+ App installation for full compatibility.

FAQ

- Q: How do I know if my keyboard is successfully connected?
- A: Check for a steady white LED on the connection key to confirm a successful connection.
- Q: Which keys may require additional software installation for full functionality?
- A: Keys like Dictation, Emoji, Mute Microphone, and Screen Lock may need Logi Options+ App installation for certain OS or language support.

KNOW YOUR PRODUCT



- 1. Easy-Switch keys /Connection key
- 2. Battery status LED & ON/OFF switch (side of the keyboard)
- 3. Windows layout
- 4. MacOS layout
- 5. Batteries + dongle compartment (keyboard bottom side)

GETTING STARTED

Connect your keyboard and mouse to your device

Choose how you want to pair your keyboard to your device. You have 2 options:


- Option 1: Through our Logi Bolt receiver
- Option 2: Through direct Bluetooth®Low Energy (BLE) connection

INSTALLATION INSTRUCTION

To pair through Logi Bolt receiver:

• STEP 1:

Take the Logi Bolt receiver from the packaging tray that was holding your keyboard.**IMPORTANT:** Don't remove the pull-tabs from your keyboard yet.




• STEP 2:

Insert the receiver into any available USB port on your desktop or laptop.




• STEP 3:

Now you can remove the pull-tabs from the keyboard and it will automatically turn on. The receiver should be successfully connected to your device when the white LED on the connection key stops blinking.



• STEP 4:

Set the right keyboard layout for your computer operating system: Long press for 3 seconds the following shortcuts to set it up for Windows, macOS or ChromeOS.




Windows: Fn + PmacOS: Fn + OChromeOS: Fn + C

IMPORTANT: Windows is the default OS layout. If you are using a Windows computer you can skip this step. Your keyboard is now ready to use.

To pair through Bluetooth®:


• STEP 1:

Remove the pull tab from the keyboard and it will automatically turn on. The white LED on the keyboard connect key starts blinking.




• STEP 2:

Open the Bluetooth® settings on your device. Add a new peripheral by selecting your keyboard (Wave Keys) from your list of devices. Your keyboard will be paired once the LED stops blinking.



• STEP 3:

Your computer will require you to input a random set of numbers, please type them all and press the "Enter" key on your keyboard. Your keyboard is now ready to use.




DONGLE COMPARTMENT

If you are not using your Logi Bolt USB receiver, you can safely store it inside your keyboard:


• STEP 1:

Remove the battery door from the bottom side of your keyboard.




• STEP 2:

The dongle compartment is located next to the batteries.



• STEP 3:

Place your Logi Bolt receiver in the compartment and slide it to the bottom side of the compartment to secure it tight



KEYBOARD FUNCTIONS

You have a full range of useful productive tools on your keyboard that will help you save time and work faster

					F	-Rows Keys						
		esc	0	<u>−Q</u> s F1		2 <u>- 1</u> 2	3 <u>- 0</u>		O		Q)) F5	⊕ _{F6}
Main function	Windows	- Escape	Device connect key #1		Device connect key #2		Device connect key #3		Task viev	w Dictation*		Emoji*²
	macOS	Lscape							Mission control		Dictation	Emoji
Secondar	Secondary function		F1		F2		F3		F4		F5	F6
		5 1		⊕ ×	o B	MI F9	■ × F10		1(1) F11		○ ••••• ••••• •••••	del
Main function	Windows	Snip & sketch		Mute mic* ³		Play/ Pause	Mute sound		Volume down		Volume up	Delete
	macOS	Screen capture					304114	251111		- SP		
Secondary	econdary function F7 F8 F		F9	F10		F11		F12	Screen lock*4			

Hot Keys											
		home â	end	pg up	pg dn						
Main function	Windows	Home	End	Page up	Page down						
Tunction	macOS										
Secondary	y function	Scroll lock	Contextual menu	Insert							

Most of these keys work without the need to install the software (Logi Options+), except for:

• Mute Microphone key: Install Logi Options+ App for it to work on Windows and macOS; works out of the box on

ChromeOS


- Close the browser tab key, Settings key and Calculator key: Install Logi Options+ App for it to work on macOS;
 works out of the box on Windows and ChromeOS
- For Windows: The dictation key needs Logi Options+ App installed to work on Korean. For macOS: The dictation key needs Logi Options+ installed to work on Macbook Air M1 and 2022 Macbook Pro (M1 Pro and M1 Max chip).
- 2. For Windows: The Emoji key needs the Logi Options+ App installed for France, Turkey, and Belgium keyboard layouts.
- 3. Free Logi Options+ App is required to enable the function.
- 4. For macOS: The screen lock key needs Logi Options+ App installed for France keyboard layouts

MULTI-OS KEYBOARD

Your keyboard is designed to work with multiple operating systems (OS): Windows, macOS, ChromeOS


For Windows and macOS keyboard layout

- If you are a Windows user, the special characters and keys will be on the top side of the keys.
- If you are a macOS user, the special characters will be on the bottom side of the keys.




For ChromeOS keyboard layout

• If you are a Chrome user, you will find one dedicated Chrome function, the Launcher key, on top of the start key. Make sure you have selected the ChromeOS layout (FN+C) when you connect your keyboard.




BATTERY STATUS NOTIFICATION

When the battery level is between 6% to 100%, the LED colour will stay green



• When the battery level is below 6% (from 5% and below), the LED will turn red. You can continue using your device for up to 1 month when the battery is low.

Note: Battery life may vary based on user and computing conditions.



www.logitech.com/prosupport/wave-keys-for-business

2023 Logitech, Logi, Logi Bolt, Logi Options+ and Logitech logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. App Store is a service mark of Apple Inc. MacBook, MacBook Pro, MacBook Air and macOS are trademarks of Apple Inc. Android, Chrome are trademarks of Google LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. Windows is a trademark of the Microsoft group of companies. All other 3rd party trademarks are the properties of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

Documents / Resources



logitech B0BTNY72VD Wave Keys For Business [pdf] User Guide

B0BTNY72VD Wave Keys For Business, B0BTNY72VD, Wave Keys For Business, Keys For Business, Business

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.