

logitech CLASS 1 Laser Clicker



logitech CLASS 1 Laser Clicker User Manual

[Home](#) » [Logitech](#) » logitech CLASS 1 Laser Clicker User Manual 

Contents

- 1 logitech CLASS 1 Laser Clicker
- 2 Specifications
- 3 Product Usage Instructions
- 4 FAQ
- 5 Logitech Compliance
- 6 FCC Statement
- 7 Warranty
- 8 CONTACT
- 9 Documents / Resources
 - 9.1 References

logitech®

logitech CLASS 1 Laser Clicker



Specifications

- **Compliance:** RoHS, WEEE
- **FCC Compliance:** Part 15
- **IC Statement:** CAN ICES-3 (B) / NMB-3 (B)
- **Warranty:** Refer to the product package for details
- **Address:** Logitech, Inc., 3930 North First Street, San Jose, CA 95134, USA

Product Usage Instructions

- Before using the product, ensure you have read the manual for safe and proper use.

Disposal and Recycling

- Do not dispose of packaging, batteries, electronic equipment, or accessories with household waste. Segregate them and take them to a recycling point to avoid environmental impact.
- Your Logitech hardware product is covered by a warranty for defects in materials and workmanship. Refer to the support.logitech.com website for specific warranty details and procedures.
- If you have any product or warranty-related questions, contact Customer Care at www.logitech.com/contact. For Asia Pacific Consumers, reach out to Logitech Asia Pacific Limited.

FAQ

- **Q:** Where can I find specific warranty information for my product?
- **A:** Refer to the product package for the length of warranty coverage from the date of purchase. Detailed

warranty information is available on support.logitech.com.

- **Q:** What should I do with the packaging and batteries when disposing of the product?
- **A:** Do not dispose of them with household waste. Take them to an appropriate collection point for recycling to prevent environmental impact.

Read the Manual Before Product Use



BATTERY WARNING! Improperly replaced batteries may present a risk of leak or explosion and personal injury. Risk of fire or explosion if the battery is replaced by an incorrect type. Ensure batteries are installed correctly by following the instructions provided. Mistreated rechargeable batteries may present a risk of fire or chemical burns. Do not disassemble or expose to conducting materials, moisture, liquid, or heat above 54° C (130° F). A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Do not use or charge the battery if it appears to be leaking, discoloured, deformed, or in any way abnormal. Do not leave your battery discharged or unused for extended periods. Do not short circuit. Your device may contain an internal, rechargeable battery that is not replaceable. Battery life varies with usage. Non-operational batteries should be discarded according to local laws. If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep batteries away from children.

Class 1 Laser product: This product complies with International Standards IEC/EN 60825-1: 2014, Class 1 Laser Product, and also complies with 21 CFR 1040.10 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019. Maximum power of 716 microwatts CW, Emitted wavelength is 832-865 nm; Operating temperature between 0° C and 40° C.

CLASS 1 LASER PRODUCT INVISIBLE LASER RADIATION

WARNING! Use of controls, adjustments or performance of procedures beyond those specified herein may result in hazardous radiation exposure.

WARNING! Avoid prolonged direct eye and/or skin contact with the laser aperture. May result in potential burn injury.

The product contains Class 1 LED. Operating temperature between 0° C and 40° C.

Use Guidelines: Safe & Proper Use of Your Product

- Do not open or modify the product except for battery removal and replacement.
- Do not disassemble or attempt to service this product because there is a risk of radiation exposure, which could injure you.
- Do not direct the infrared/laser beam at anyone's eye or a reflective object.
- Do not immerse the product in any liquid or expose to heat or moisture.
- If the product is exposed to out-of-range temperature environments, power off the device until the temperature has stabilized within the specified operating temperature range.
- Use only Logitech-provided power supply devices with this product. Do not modify the power supply. Do not charge your product during an electrical storm.
- Use the product with listed/certified ITE computers and accessories.
- This is not a Children's Product and is not intended for use by children under 14 years old.
- Long periods of repetitive motion using the product may be associated with nerve, tendon or muscle injury in your hands, wrists, arms, shoulders, neck or back. See a qualified health professional for pain, numbness,

weakness, swelling, burning, cramping, or stiffness. Also, read the guidelines at www.logitech.com/comfort.

- This product is safe under normal and reasonably foreseeable misuse operating conditions. If the product is operating improperly, contact Logitech support. The product must be returned to Logitech for any service or repair.
- Any changes or modifications to the product that are not expressly approved by Logitech may void the user's authority to operate the equipment and your warranty.
- Refer to the product Quick Start Guide for use instructions.

Logitech Compliance

The product complies with all applicable requirements for the Restriction of Hazardous Substances (RoHS) and Waste Electronic and Electrical Equipment (WEEE). For Product Safety, EMC, RF, Energy, RoHS and WEEE information, go to www.logitech.com/compliance. Maintenance is not required for product compliance.

Packaging, batteries, electronic and electrical equipment and their accessories should not be disposed of with household waste. Wherever possible, they should be segregated and brought to an appropriate collection point to enable recycling and avoid potential impacts on the environment and human health. For more information, contact your local authorities or place of purchase, or visit www.logitech.com/recycling.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. And, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Where shielded interface cables or accessories have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used to ensure compliance with FCC. Changes or modifications to a product not expressly approved by Logitech, Inc. could void your right to use or operate your product by the FCC.

IC statement : CAN ICES-3 (B) / NMB-3 (B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure Statement

This wireless product complies with the FCC and Industry Canada RF exposure limit for portable devices.

Warranty

Logitech Limited Hardware Product Warranty – A Summary

Logitech warrants that its hardware product shall be free from defects in materials and workmanship for the length of time identified on your product package beginning from the date of the original retail purchase. See support.logitech.com for specific warranty information about your product and procedures to act on a warranty claim.

Logitech's entire liability and your exclusive remedy for any breach of warranty shall be, at Logitech's option, to repair or replace a functional equivalent of the product, or to refund the price paid, if the hardware is returned to the point of purchase or such other place as Logitech may direct along with a receipt. Warranty protections are in addition to rights provided under local consumer laws and may vary among countries. See full warranty information to know your consumer rights and the additional protections provided by this product warranty.

- Logitech Address: Logitech, Inc., 3930 North First Street, San Jose, CA 95134, USA.
- Full Warranty Information: support.logitech.com

For Australia/New Zealand Consumers Only

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is provided by Logitech International SA, EPFL – Innovation Park, Daniel Borel Innovation Center, 1015 Lausanne, Switzerland.

CONTACT

- Contact information for Australia/New Zealand Consumers Only:
- The Woolstores Alexandria, Shed 72, Suite 2.01A, 4F Huntley Street, Alexandria, Sydney, NSW Australia 2015. Telephone: 1 800-025-544. For any product /warranty-related questions, please contact Customer Care (www.logitech.com/contact).
- Contact information for Asia Pacific Consumers: Logitech Asia Pacific Limited, Unit 1003, Tower One, Cheung Sha Wan Plaza, 833 Cheung Sha Wan Road, Kowloon, Hong Kong.

© 2023 Logitech, Logi and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

Documents / Resources



[logitech CLASS 1 Laser Clicker](#) [pdf] User Manual
MR0109, JNZMR0109, mr0109, CLASS 1 Laser, CLASS 1, Laser, CLASS 1 Laser Clicker, CLASS 1 Laser Clicker, Laser Clicker, CLASS 1 Clicker, Clicker

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.