Manuals+ — User Manuals Simplified.

# logitech Cloud Gaming Handheld Controller User Guide

Contents

**logitech Cloud Gaming Handheld Controller**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10 mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

## WHAT IN THE BOX

DEVICE DESCRIPTION

COMPONENT NAMES

1. Left Function Button
2. Left Joystick/L3 ButtonD-Pad
3. G Button
4. Touch Screen
5. Right Function Button
6. A/B/X/Y Buttons
7. Right Joystick/R3 Button
8. Home Button
9. Left Bumper/Trigger (L1, L2)
10. Volume Button
11. Power Switch
12. TF Card Slot
13. Right Bumper/Trigger (R1, R2)
14. 3.5 mm Jack
15. USB Type-C/Charging port
16. Dual Speaker
17. Dual Mic

SETUP INSTRUCTIONS

- **Power on**

- Slide and hold the power switch to power on the device.

- **First-time setup**

- Follow the on-screen setup wizard to complete the first-time setup of the device.

- **Charging**

- Connect the USB cable Type-C end into the USB Type-C port on the bottom of the device, connect the USB cable Type-A end to the power adapter, and then connect the power adapter into the socket to charge the device.

QUESTIONS?

logitechG.com/support/cloud

Documents / Resources

	logitech Cloud Gaming Handheld Controller [pdf] User Guide GR0006, JNZGR0006, Cloud Gaming Handheld Controller, Gaming Handheld Controller, Handheld Controller, Controller

References

- **Logitech Support + Download**