



## logitech Crayon Faqs Troubleshooting Instructions

[Home](#) » [Logitech](#) » logitech Crayon Faqs Troubleshooting Instructions



### Contents [ [hide](#) ]

- [1 logitech Crayon Faqs Troubleshooting Instructions](#)
- [2 TURNING CRAYON ON/OFF](#)
- [3 BATTERY AND CHARGING](#)
- [4 PROTECTION](#)
- [5 COMPATIBILITY](#)
- [6 UPDATING FIRMWARE](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

**logitech Crayon Faqs Troubleshooting Instructions**



Make sure iPad iOS is updated to version 11.4 or above

## TURNING CRAYON ON/OFF

### How do I turn Logitech Crayon on/off?

- Press the power button for 1s until the LED light turns on / fades away.



### How does Crayon connect to the iPad? Do I need to pair it with the iPad?

Simply power Crayon on and you are ready to go, no pairing with iPad required.

### I tried to turn on Crayon but it doesn't work when I use it on the iPad.

- If you have been using Apple Pencil with the iPad, you will have to disconnect the pencil prior to using Logitech Crayon. To disconnect Apple Pencil go to Settings -> Bluetooth. Find Apple Pencil in the device menu and select "Forget This Device"
- Press the power button for 1 sec to ensure that Crayon is on and has sufficient battery level:
  - Green light means the battery is sufficient and above 10%.

- Red light means the battery is less than 10%.
- Blinking red light means the battery life is critically low, charge Crayon immediately.
- Check that the Crayon tip is screwed tightly on.
- Crayon only works with iPad 6th generation (model numbers on the back of iPad A1893 or A1954). Crayon does not work with any other tablets or iPad models.
- Make sure iPad is on and is updated with the newest iOS.

## **BATTERY AND CHARGING**

### **How do I know how much battery is left?**

- Short press the power button to check the battery level.
  - Green means the battery is sufficient and above 10%.
  - Red means the battery is less than 10%.
- Blinking red without a battery check means the battery life is critical, it needs charging immediately.



### **How do I charge Crayon?**

- Use a standard Lightning cable that you would use to charge iPad to charge Crayon.

### **How often should I charge Crayon?**

- We recommend Crayon to be charged daily at the end of the school day. A full charge can support 7 hours of non-stop writing.

### **Can I use crayon while charging?**

- No, Crayon will not function while charging with a Lightning cable.

### **How long does it take to charge?**

- It takes 50 mins to fully charge Crayon from 0 to 100%.

## **PROTECTION**

### **My students dropped Crayon, will it still work?**

- Crayon has gone through rigorous testing and passes drop testing from up to 4 ft. If the tip of Crayon becomes damaged, new tips can be purchased as a spare part.

### **The tip became damaged, how do I replace or repair it?**

- You can purchase spare tips from Logitech.  
<https://www.logitech.com/en-us>
- When you receive the replacement tips, the package will contain 10 tips, a removal tool and instructions on how to replace the tip.

### **Is Crayon waterproof?**

- No, it's not waterproof.

### **Will Crayon scratch or damage the iPad screen?**

- No, it will not damage the iPad screen.

## **COMPATIBILITY**

### **Can Crayon be used on other tablets (non-iPad)? What about other iPads (besides 6th Gen)?**

- Logitech Crayon only works with iPad 6th gen (model numbers on the back of iPad A1893 or A1954). Logitech Crayon will not work with non-iPad tablets, other iPad models or phones.

### **Are there certain apps or programs that Crayon works with?**

- Logitech Crayon works with apps that support Apple Pencil.
- Logitech Crayon doesn't require installation of any additional apps to work with iPad.

### **Can I use multiple Crayons with one iPad?**

- Yes, you can use multiple Crayons on one iPad, but not simultaneously.

### **Can I use one Crayon with multiple iPads?**

- Yes, you can move Crayon from one iPad (6th gen) to another. There is no need to pair with individual iPads, just make sure both Crayon and iPads are on.

### **Can I use Crayon and Apple Pencil with the same iPad?**

- Yes, but turn off the Bluetooth to disable Apple Pencil if you want to use Crayon.


UPDATING FIRMWARE

How do I update firmware on Logitech Crayon?

- To update firmware, follow instructions here

Read More About This Manual & Download PDF:

Documents / Resources

	<a href="#">logitech Crayon Faqs Troubleshooting</a> [pdf] Instructions Crayon Faqs Troubleshooting
--	--

References

-  [Logitech: Wireless Mouse, Keyboards, Headsets & Video Conferencing](#)