

logitech G Cloud Gaming Handheld Console User Guide

Home » Logitech » logitech G Cloud Gaming Handheld Console User Guide






Contents [hide


- 1 G Cloud Gaming Handheld
- Console
- **2 DEVICE DESCRIPTION**
- **3 SETUP INSTRUCTIONS**
- 4 Documents / Resources
 - **4.1 References**
- **5 Related Posts**

G Cloud Gaming Handheld Console



DEVICE DESCRIPTION

COMPONENT NAMES




1 Left Function Button	10 Left Bumper/Trigger (L1, L2)
2 Left Joystick/L3 Button	11 Volume Button
3 D-Pad	12 Power Switch
4 G Button	13 TF Card Slot
5 Touch Screen	14 Right Bumper/Trigger (R1, R2)
6 Right Function Button	15 3.5 mm Jack
7 A/B/X/Y Buttons	16 USB Type-C/Charging port
8 Right Joystick/R3 Button	17 Dual Speaker
9 Home Button	18 Dual Mic

SETUP INSTRUCTIONS


- Power on:

Slide and hold the power switch to power on the device




- First-time setup:

Follow the on-screen setup wizard to complete the first-time setup of the device



- Charging:

Connect the USB cable Type-C end into the USB Type-C port on the bottom of the device, connect the USB cable Type-A end to the power adapter, and then connect the power adapter into the socket to charge the device



QUESTIONS?

logitechG.com/support/cloud



© 2022 Logitech Logitech, Logitech G and the Logitech and Logitech G logos are trademarks or registered trademarks of Logitech Europe S A and/or its affiliates in the U S and other countries All other trademarks are the property of their respective owners Logitech assumes no responsibility for any errors that may appear in this manual Information contained herein is subject to change without notice WEB-621-002200 002

Documents / Resources



logitech G Cloud Gaming Handheld Console [pdf] User Guide

G Cloud, Gaming Handheld Console, G Cloud Gaming Handheld Console, Cloud Gaming Handheld Console, Handheld Console, Console

References

• (1 Logitech Support + Download

Manuals+, home privacy