


# logitech Headset with in-line controller and USB-C connector Installation Guide

[Home](#) » [Logitech](#) » logitech Headset with in-line controller and USB-C connector Installation Guide 

## Contents

- 1 Logitech Zone 750 Setup Guide**
  - 1.1 KNOW YOUR PRODUCT**
  - 1.2 IN-LINE CONTROLLER**
  - 1.3 WHAT'S IN THE BOX**
  - 1.4 CONNECTING THE HEADSET**
  - 1.5 HEADSET FIT**
  - 1.6 ADJUSTING THE MICROPHONE BOOM**
  - 1.7 HEADSET IN-LINE CONTROLS AND INDICATOR LIGHT**
  - 1.8 LOGI TUNE (PC COMPANION APP)**
  - 1.9 ADJUSTING SIDETONE**
  - 1.10 UPDATE YOUR HEADSET**
  - 1.11 DIMENSION**
  - 1.12 SYSTEM REQUIREMENTS**
  - 1.13 TECHNICAL SPECIFICATIONS**
- 2 Documents / Resources**
  - 2.1 References**
- 3 Related Posts**

## Logitech Zone 750 Setup Guide




logitech®


## KNOW YOUR PRODUCT



## IN-LINE CONTROLLER



## WHAT'S IN THE BOX




1. Headset with in-line controller and USB-C connector
2. USB-A adapter
3. Travel bag
4. User documentation

## CONNECTING THE HEADSET

### Connect via USB-C


1. Plug the USB-C connector into your computer USB-C port.



### Connect via USB-A


1. Plug the USB-C connector into the USB-A adapter.
2. Plug the USB-A connector into your computer USB-A port.

**Note:** Only use the USB-A adapter with the provided headset.




## HEADSET FIT

Adjust headset by sliding headband open or closed on both sides.






## ADJUSTING THE MICROPHONE BOOM


1. Microphone boom rotates 270 degrees. Wear it on either left or right side. To activate audio channel switching, download Logi Tune at: [www.logitech.com/tune](http://www.logitech.com/tune)
2. Adjust flexible microphone boom location to capture voice better.



## HEADSET IN-LINE CONTROLS AND INDICATOR LIGHT

Button	Usage		Indicator Light	Action
	<b>Mute</b>	Mute on	Solid RED	Short press to mute / unmute
		Mute off	No light	
	<b>Call Controls</b>	Incoming calls	Flashing WHITE	Short press to answer calls
		Ongoing calls	Solid WHITE	2 seconds press to reject calls
	<b>Voice Assistant</b>		No light	Short press to end calls
	<b>Media Controls</b>		No light	2 seconds press to trigger voice assistant*
				Short press to play / pause
				Double press to track forward
+	<b>Volume</b>		No light	Triple press to track backward
				Short press to volume up
-				Short press to volume down

\* Voice assistant functionality may depend on device models.



## LOGI TUNE (PC COMPANION APP)

Logi Tune helps boost your headset performance with periodic software and firmware updates, helps you adjust what you hear with 5 band EQ customization, and helps you control how you are heard with mic gain, sidetone controls, and more. The distraction-free mini-app allows you to make audio adjustments while in an active video call.

Learn more & download Logi Tune at:  
[www.logitech.com/tune](https://www.logitech.com/tune)

## ADJUSTING SIDETONE

Sidetone lets you hear your own voice during conversations so you are aware of how loud you are talking. In Logi Tune, select the sidetone feature, and adjust the dial accordingly.

- A higher number means you hear more external sound.
- A lower number means you hear less external sound.

## UPDATE YOUR HEADSET

It is recommended to update your headset. To do so, download Logi Tune from [www.logitech.com/tune](https://www.logitech.com/tune)

## DIMENSION

### Headset:

Height x Width x Depth: 165.93 mm x 179.73 mm x 66.77 mm  
Weight: 0.211 Kg

### Ear pad dimensions:

Height x Width x Depth: 65.84 mm x 65.84 mm x 18.75 mm

### Adapter:

Height x Width x Depth: 21.5 mm x 15.4 mm x 7.9 mm

## SYSTEM REQUIREMENTS

Windows, Mac or Chrome™ based computer with available USB-C or USB-A port. USB-C compatibility with mobile devices depends on device models.

## TECHNICAL SPECIFICATIONS

Input Impedance: 32 Ohms

Sensitivity (headphone): 99 dB SPL/1 mW/1K Hz (driver level)

Sensitivity (microphone): Main mic: -48 dBV/Pa, Secondary mic: -40 dBV/Pa

Frequency response (Headset): 20-16 kHz


Frequency response (Microphone): 100-16 kHz (mic component level)

Cable length: 1.9 m

[www.logitech.com/support/zone750](https://www.logitech.com/support/zone750)

© 2021 Logitech, Logi and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

**Documents / Resources**

	<a href="#">logitech Headset with in-line controller and USB-C connector</a> [pdf] Installation Guide Headset with in-line controller and USB-C connector
---	--

**References**

- [logi Logi Tune - Software App for Webcams, Headsets & Logi Dock](#)