

Logitech K290 Comfort Keyboard User Guide

Home » Logitech » Logitech K290 Comfort Keyboard User Guide 🖫



Contents


- 1 Logitech K290 Comfort
- **Keyboard**
- 2 IN THE BOX
- 3 Set up your product
- **4 Visit Product Central**
- **5 Function keys**
- 6 Corded Keyboard K280e
- 7 Comfort Keyboard K290
- 8 Windows 8 feature
- 9 Troubleshooting
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts




Logitech K290 Comfort Keyboard



IN THE BOX



Set up your product



- 1. Turn on your computer.
- 2. Connect the keyboard to a USB port.

Visit Product Central

There's more information and support online for your product. Take a moment to visit Product Central to learn more about your new keyboard.

Browse online articles for setup help, usage tips, or information about additional features. If your keyboard have optional software, learn about its benefits and how it can help you customize your product. Connect with other users in our Community Forums to get advice, ask questions, and share solutions. At Product Central, you'll find a wide selection of content:

- Tutorials
- Troubleshooting
- · Support community
- Software downloads
- Online documentation
- Warranty information
- Spare parts (when available) Go to www.logitech.com/support/k280e <a href="https://www.logitech.com/support/k280e <a href="https://www.logitech.com/support/water/water/k280e <a href="https://www.logitech.com/support/wat

Function keys

The function keys available depend on which keyboard you have. To identify your keyboard, look at the label fixed to the bottom.

Corded Keyboard K280e



To select a function key such as F1, just press the F-key. To select a feature, press and hold the blue FN key on the bottom row of the keyboard, then press the F-key. The following features are available:

- Fn + F1 = Home
- Fn + F2 = Launch Email
- Fn + F3 = Search
- Fn + F4 = Calculator
- Fn + F5 = Launch Media Player
- Fn + F6 = Previous Track
- Fn + F7 = Play/Pause
- Fn + F8 = Next Track
- Fn + F9 = Mute
- Fn + F10 = Volume down
- Fn + F11 = Volume up
- Fn + F12 = PC Sleep

Comfort Keyboard K290



To select a function key such as F1, press and hold the blue FN key on the bottom row of the keyboard, and then press the F-key.

To select a feature, just press the F-key. The following features are available:

- F1 = Search
- F2 = Share
- F3 = Devices
- F4 = Settings
- F5 = Switch applications
- F6 = Previous Track
- F7 = Play/Pause
- F8 = Next Track
- F9 = Mute
- F10 = Volume down
- F11 = Volume up
- F12 = PC Sleep

Windows 8 feature

Use the Logitech SetPoint software to map these keys to other functions. You can download SetPoint from

Troubleshooting

Keyboard does not work

- Check the USB cable connection.
- Use another USB port.
- Connect directly to the computer and don't use a USB hub.
- If the keyboard still doesn't work, please restart your computer.

What do you think?

Please take a minute to tell us. Thank you for purchasing our product. www.logitech.com/ithink

Documents / Resources



Logitech K290 Comfort Keyboard [pdf] User Guide K290 Comfort Keyboard, K290, Comfort Keyboard, Keyboard

References

• Iogitech Support + Download

Manuals+,