


logitech Logi Dock All-In-One Docking Station Installation Guide

Home » Logitech » logitech Logi Dock All-In-One Docking Station Installation Guide Ta









TEAMS VERSION TEAMS

Contents

- 1 KNOW YOUR PRODUCT
- **2 WHAT'S IN THE BOX**
- **3 CONNECTING TO POWER**
- **4 CALENDAR INTEGRATION**
- **5 MEETING CONTROLS AND INDICATOR LIGHT**
- **6 TECHNICAL SPECIFICATIONS**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**


KNOW YOUR PRODUCT





WHAT'S IN THE BOX


- 1. Logi Dock
- 2. Power supply (1 6 m)
- 3. AC power cord (1 7 m)
- 4. USB-C to USB-C cable (1 m)
- 5. User documentation



CONNECTING TO POWER


1. Connect one end of the AC power cord to the power supply, and connect another end to an outlet

2. Connect the power supply to the AC power poron the docking station




CONNECTING VIA USB-C CABLE

Connect one end of the USB-C cable to the USB-C upstream port on Logi Dock,and connect another end to the USB-C poron your computer



LOGI TUNE APP

Download and install Logi Tune from www.logitech.com/tune for calendar integration with Google Calendar and Office 365, and one-touch meeting controls



CALENDAR INTEGRATION

- 1. Open Logi Tune app on your computer
- 2. Link your preferred calendar and authenticate with your calendar provider Then follow the steps in the app
- 3. Your agenda will show up in the dashboard upon successful link

ONE-TOUCH MEETING CONTROLS


- 1. Link your calendar with Logi Tune
- 2. Make sure Tune is running in the background You can see the app in the taskbar if Tune is active
- 3. One-touch-to-join will be activated by default
- 4. To deactivate, visit device settings in the Tune app

MEETING CONTROLS AND INDICATOR LIGHT

UC version							
Button	Usage		Indicator light	Action			
Q	Mute	Mute on	Solid RED	Short press			
		Mute off	Solid WHITE				
0	Call Controls	Idle state	-	Short press to invok e/close Tune			
		Time of meeting	Flashing PURPLE	_			
		Incoming call	Flashing WHITE	Short press to answ er call			
				2 seconds press to r eject call			
		Active call	Solid WHITE	Short press to end c			
+	Volume	Volume up	_	Short press			
_		Volume down					
	Video	Video on	Solid WHITE	Short press			
		Video off	Solid RED				

Note:


- When the Zone Wireless (Plus) headset or Zone True Wireless earbuds are connected to Logi Dock, both speakerphone and headset status will be in sync
- Mute indicator light is available when Logi Dock, Zone Wireless (Plus) headset or Zone True Wireless earbuds are the audio source Video indicator light is available for UC or Teams-certified devices only



TEAMS version						
Button	Usage		Indicator light	Action		
Q	Mute	Mute on	Solid RED	- Short press		
		Mute off	Solid WHITE			
	Call Controls	Incoming call	Flashing WHITE	Short press to answer call		
				2 seconds press to reje ct call		
		Active call	Solid WHITE	Short press to end call		
	Teams Activities	Idle state	Solid PURPLE	Short press to invoke T eams		
		Active call		Short press to transfer audio from other active device*		
				2 seconds press to inv oke Teams feature**		
		Teams notification	Flashing PURPL E	Short press to clear not ification event		
+	Volume	Volume up	. –	Short press		
_		Volume down				
_ 0	Video	Video on	Solid WHITE	Short press		
		Video off	Solid RED			

Note:

- Teams activities are only functional when Teams is running on an unlocked PC or Mac
- When the Zone Wireless (Plus) headset or Zone True Wireless earbuds are connected to Logi Dock, both speakerphone and headset status will be in sync
- Mute indicator light is available when Logi Dock, Zone Wireless (Plus) headset or Zone True Wireless earbuds
 are the audio source Video indicator light is available for UC or Teams-certified devices only
- *If Zone Wireless (Plus) headset or Zone True Wireless earbuds are connected directly to Logi Dock and you are in an active call, a single press on Logi Dock will end the call instead of transferring an active call
- **Refer to www.logitech.com/support/Logi-Dock-compatibility for the latest Teams feature updates



AMBIENT LIGHT

UC version/TEAMS version							
		7111					
	Left	Middle	Right				
Calendar entry							
Time of the meeting			-				
Incoming call							
On call							
Mute on							
Mute off	0						
Video on			0				
Video off							
Bluetooth® pairing							
Pairing mode		5 sec.					
Paired							

Note:

• Ambient light (for mute) is available when Logi Dock, Zone Wireless (Plus) headset or Zone True Wireless earbuds are the audio source Ambient light (for video) is available for UC or Teams-certified devices only


Tip:

Ambient light customization available on Logi Tune

CONNECTING USB DEVICES


- Logi Dock has 5 USB ports: 2 USB-A and 2 USB-C ports on the back panel; 1 USB-C port on the side
- Simply connect your external USB devices such as a keyboard and mice with the USB-A or C ports

Note: Please charge your iOS device via USB-A or C ports with charging port icon (**) only when the Logi Dock is disconnected from the laptop



CONNECTING BLUETOOTH® -ENABLED MOBILE DEVICES


- 1. Press the Bluetooth® pairing button at the back panel for 3 seconds The ambient light in front will blink blue
- 2. Open Bluetooth® settings on your mobile device
- 3. Select Logi Dock in discoverable devices
- 4. Once successfully paired, the ambient light will turn solid blue for 5 seconds with sonification



CONNECTING A DISPLAY PORT DEVICE

To connect your DisplayPort video device (such as monitor, projector) to Logi Dock, insert the DisplayPort cable* to DisplayPort on the back panel


* DisplayPort cable is not included



CONNECTING A HDMI DEVICE

To connect your HDMI video device (such as monitor, projector) to Logi Dock, insert the HDMI cable* to HDMI port on the back panel


* HDMI cable is not included



USING A KENSINGTON LOCK

To secure Logi Dock with a Kensington lock:

- Wrap one end of the security cable around secured object
- Insert the key into the cable lock
- Insert the cable lock into the Kensington security slot at the back panel Turn and remove the key
- * Kensington lock and keys are not included



DIMENSIONS

Height x Width x Depth: 84 8 mm x 160 0 mm x 131 5 mm

Weight: 0 942 kg

SYSTEM REQUIREMENTS

Works with common calling applications across almost all platforms and operating systems Works with Windows, macOS, or Chrome based computer via USB-C with Alt Mode and iOS or Android based mobile devices via Bluetooth®

TECHNICAL SPECIFICATIONS

Microphone type: Six beamforming mics with advanced algorithms

Frequency response (Speaker): 60 Hz – 20 kHz Frequency response (Microphone): 65 Hz – 8 kHz

Wireless range: Up to 30 m / 100 ft (open field line of sight)


Wireless range may vary depending on operating environment and setup

Power to system: Up to 100 watt charging Cable length (USB-C to C cable): 3 3 ft (1 m) Cable length (AC power cord): 5 6 ft (1 7 m) Cable length (Powers supply): 5 2 ft (1 6 m)

© 2022 Logitech Logitech, Logi and their logos are trademarks or registered trademarks of Logitech Europe S A and/or its affiliates in the U S and other countries The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc and any use of such marks by Logitech is under license Windows, macOS, iOS, Chrome, Android, USB-C and all other 3rd party trademarks are the property of their respective owners



Documents / Resources



References

- Logitech Support + Download
- logi Tune Software App for Webcams, Headsets & Logi Dock

Manuals+,