

logitech C922 Pro Stream Webcam User Manual

Home » Logitech » logitech C922 Pro Stream Webcam User Manual



Contents

- 1 logitech C922 Pro Stream Webcam User Manual
- **2 C922 PRO STREAM WEBCAM DESIGNED FOR SERIOUS STREAMERS**
- 3 WHAT'S IN THE BOX
- **4 WEBCAM FEATURES**
- **5 QUICK SETUP**
- 6 HOW TO STREAM WITH C922 XSPLIT BROADCASTER 6.1 HOW TO STREAM WITH A CUSTOM BACKGROUND -XSPLIT **BROADCASTER**
 - 6.2 HOW TO STREAM WITHOUT BACKGROUND- XSPLIT BROADCASTER
- 7 TIPS/ADVICE
- 8 Questions about your Manual? Post in the comments!
 - **8.1 Related Posts**

logitech C922 Pro Stream Webcam User Manual



C922 PRO STREAM WEBCAM DESIGNED FOR SERIOUS STREAMERS

Designed for serious streamers only, the Logitech® C922 Pro Stream Webcam comes fully equipped to let you broadcast your talent to the world: full HD 1080p at 30fps or 720p at 60fps streaming and customizable background replacement.



WHAT'S IN THE BOX


- 1. C922 Pro Stream Webcam
- 2. User documentation
- 3. Tripod*
- 4. 3-Month XSplit License*


*Tripod and 3-month XSplit license only supplied with some packages.




WEBCAM FEATURES

- 1. Full HD glass lens with autofocus
- 2. Dual Microphone
- 3. Activity light
- 4. Flexible clip/base
- 5. Tripod attachment





QUICK SETUP



To use your C922 Pro Stream Webcam, simply plug it into your computer, using the USB cable, and run your favorite app:

- XSplit or OBS to stream online
- Microsoft Camera App (Windows) or QuickTime Player (Mac) to record photos or video
- Skype, Facetime® for Mac or Google HangoutsTM for video call

To update your camera settings, such as exposure or focus, please go to www.logitech.com/support/c922. Download the ChromaCam by Personify for C922 app to use the background replacement technology in your live streams:

HOW TO STREAM WITH C922 - XSPLIT BROADCASTER

To stream with Logitech C922, complete the following steps:

- · Launch XSplit Broadcaster.
- Go to Add > Webcam...> Logitech C922 Pro Stream Webcam.
- Use Logitech recommended settings or adjust them manually to you liking.

Refer to the XSplit Documentation at http://xsplit.com for more information.




HOW TO STREAM WITH A CUSTOM BACKGROUND -XSPLIT BROADCASTER

To stream with Logitech C922 and a custom background, complete the following steps:

- 1. Install ChromaCam by Personify for C922 from www.logitech.com/support.
- 2. Launch XSplit Broadcaster.
- 3. Go to Add > Webcam...> ChromaCam by Personify for C922. The ChromaCam app will launch automatically.
- 4. Select the required background or add your own in ChromaCam.

Refer to the XSplit Documentation at http://xsplit.com for more information.



HOW TO STREAM WITHOUT BACKGROUND- XSPLIT BROADCASTER


To stream with Logitech C922 without background, complete the following steps:

• Install ChromaCam by Personify for C922 from www.logitech.com/support.

- · Launch XSplit Broadcaster.
- Go to Add > Webcam...> ChromaCam by Personify for C922. The ChromaCam app will launch automatically.
- Select the default virtual green screen background in ChromaCam.
- In XSplit Broadcaster, right-click your webcam capture to go into Camera Settings.
- · Navigate to the "Color" tab.
- Select "ChromaKey" option, and make sure green is selected to remove the virtual green screen.

Refer to the XSplit Documentation at http://xsplit.com for more information.





TIPS/ADVICE

To achieve the best results when streaming, the following points should be followed:

- Avoid wearing green outfits when using the virtual green screen.
- Make sure that you are well-lit to appear at your best during streaming.
 To achieve a constant 720p/60fps stream:
- Ensure that any lighting comes from behind the webcam
- Use a "keylight", a main light source to light up your face.
- Use a softer "fill light" to reduce shadows on your face from the keylight.
- · Keep lighting behind you to a minimum.
- Use natural lighting or bright white lights to provide neutral colors.
- Try to use lighting that you can control the brightness on.

© 2016 Logitech. Logitech, Logi and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

Read More About This User Manuals...

<u>logitech-C922-Pro-Stream-Webcam-Manual-Optimized.pdf</u>

logitech-C922-Pro-Stream-Webcam-Manual-Orginal.pdf

Questions about your Manual? Post in the comments!

Manuals+, home privacy