



Logitech G733 Headphones User Manual

Home » Logitech » Logitech G733 Headphones User Manual

SETUP GUIDE







English		.3	Ceskb vects 93
Deutsch	ì	,n	Sloventino
Frençais		15	Мрапсиа
haltene	Ť	21	See
Exportal		27	Latviski
Pringuls		30	Lensey
Nederlands		50	бытарови
Svenska,		45	Hwanki
Donek	į	91	Sepsitr
Norsk	ï	97	Soverstine
Suomi	į	63	Romand
D0ged	i	60	Tongs
По-рессии	÷	75	165 Lag.
Po polsku		61	III may
Mograr	į	67	

SETUP INSTRUCTIONS

1. Insert the mic boom completely into the headset.



2. Insert receiver into the USB port of your PC.



3. Short press to turn ON



4. (Optional) Download Logitech G HUB software to access advanced features. Download atlogitechG.com/ghub



SIZE ADJUSTMENT

1. The earcups can be adjusted up and down.



2. The length of the headband can be adjusted.




FEATURES

- 1. Size-adjustable earcups
- 2. Removable and replaceable mic
- 3. USB-C port for charging
- 4. ON/OFF button
- 5. Reversible and replaceable headband strap
- 6. Headband strap adjusting feature
- 7. Removable and replaceable earpads
- 8. Mute/unmute button
- 9. Volume roller

UNDERSTAND

- 1. When battery life is below 10%, the audio will beep every 15 min.
- 2. When battery life is below 2%, the lights will flash red and the audio will beep every 15 min.
- 3. When plugging the charging cable, the lights will breath green 5 times and revert to its previous state.
- 4. When muting the mic, the lights will flash red and the audio will beep twice.
- 5. When unmuting the mic, the lights will flash green and the audio will beep three times.
- 6. When using G HUB software, pressing the ON/OFF button once when the headset is ON will let you know the battery life remaining.





- Enable/disable DTS Headset: X 2.0 Surround Sound
- Enable/disable Blue VO!CE mic enhancement
- · Adjust EQ settings



- Sidetone
- Lighting
- · Mute button assignment

SPARE PARTS


You can find replacement parts at logitechG.com in selected regions, including:

- Headband strap
- Earpads
- Mic
- Cable
- Receiver

RECYCLING

We encourage you to resell or donate working products. Otherwise, batteries, electronic and electrical equipment should not be disposed of with household waste. Wherever possible, they should be segregated and brought to an appropriate collection point to enable recycling and avoid potential impacts on the environment and human health. For more information, contact your local authorities or place of purchase, or visit www.logitech.com/recycling

BATTERY REMOVAL FOR RECYCLING



QUESTIONS?

logitechG.com/support/g733 www.logitech.com/recycling

Logitech Headphones Manual Optimized

Logitech Headphones Manual Original