



Logitech Harmony Smart Keyboard Add-on User Manual

[Home](#) » [Logitech](#) » Logitech Harmony Smart Keyboard Add-on User Manual 

Contents

- 1 Logitech Harmony Smart Keyboard Add-on User Manual
- 2 Package contents
- 3 How it works
- 4 Connecting to a PC or Mac
- 5 What the buttons do
- 6 Troubleshooting
- 7 Frequently asked questions
- 8 References
- 9 Related Posts




Logitech Harmony Smart Keyboard Add-on User Manual



Package contents

1




2



1

2

3



1. Harmony Smart Keyboard

Enables text entry, navigation of computers and control of home entertainment devices.

2. Two USB receivers

Enables text entry and navigation on compatible USB devices (see Connecting sections).

3. USB extender

Helps to plug the USB receiver into hard-to-reach USB slots. Usage is optional depending on setup.

How it works




Smart Keyboard

Harmony Hub required. Harmony Hub and remotes are sold separately. For more information on text entry-enabled devices, please visit support.myharmony.com/smart-keyboard-add-on

Smart Keyboard



Harmony App



Harmony Hub*

PC or Mac


TV

Cable box

A/V tuner

Game console

Media streamer



Harmony remote

Let's get started

For more detailed instructions, please visit support.myharmony.com/smart-keyboard-add-on

STEP 1

Launch the Harmony app

1. If not already done, install the Harmony App from the Apple Store or Google Play.
2. Launch the Harmony app from your smartphone or tablet.

STEP 2

Navigate to Settings

1. Tap Menu and open Settings.
2. Select Add Smart Keyboard.
3. Follow the instructions to pair the keyboard and USB receivers.

STEP 3

Connect the keyboard to Activities

1. Activities marked with contain a device that accepts text entry. Tap to enable text entry for this Activity.
2. Repeat for each marked Activity.

Connecting to a PC or Mac

If your computer is Bluetooth® compatible

- Select 'Bluetooth' for your computer connection method during setup using the Harmony App.
- Start the Bluetooth pairing process on your computer to pair Harmony Hub with your computer.

Connecting to other devicesAppleTV

- Power on your AppleTV
- Select 'Bluetooth connection' for your AppleTV during setup.
- Start the Bluetooth pairing process on your AppleTV to pair the hub with your AppleTV. Xbox 360
- Power on your Xbox.
- Plug in one of the two included USB receivers when instructed to do so.
- Select the connected USB receiver for your Xbox during setup.


Confirm the connection on the Harmony App

- If your computer has an available USB port
- Follow the onscreen instructions during setup.
- Power on your computer.
- Plug in one of the two included USB receivers when instructed to do so.
- Confirm the connection on the Harmony App.

Roku

- Ensure Roku is powered on and connected to your home network.
- Select 'Wi-Fi connection' for your Roku during setup.
- The hub will scan your network for Roku and automatically connect to it once found.PlayStation 3
- PlayStation 3 requires a Bluetooth connection to power on and off and a USB connection for text entry and navigation.
- Power on your PlayStation.
- Follow the instructions to connect via Bluetooth.
- Follow the USB receiver connection instructions on the Harmony App.

What the buttons do



1. Functions as a left mouse click.
2. Harmony Activity buttons provide one-touch access to computer-connected TV, Watch TV, and Watch Movie Activities.
3. Off will turn off all devices used in the current Activity.
4. The on/off switch turns the keyboard on or off.
5. Cable/satellite box functions are used to access program guides, DVR recordings, etc.
6. The Windows key also functions as the 'Menu' button on devices such as PS3 and Xbox and as the Command key on Mac computers.
7. When used in combination with the Fn key, the colour keys can be used to navigate PS3, Xbox, and some cable/satellite box and DVR menus.
8. Computer Page Up/Down or set-top box Channel Up/Down when used in combination with Fn key.

Troubleshooting

- My keyboard does not work.
- Make sure Harmony Hub is powered on at all times.
- Make sure the power switch on the keyboard is in the 'On' position and ensure fresh batteries are inserted in the keyboard.
- Keyboard compatibility varies with specific devices, visit support.myharmony.com/smart-keyboard-add-on for more information.
- The USB receiver was not detected during setup.
- Make sure the device you are setting up is powered on.
- Harmony Hub cannot connect to Wi-Fi, or Harmony App cannot discover the hub.
- Ensure the hub is within range of your router.
- Ensure your phone and hub are connected to the same Wi-Fi network.
- Restart your hub by disconnecting and reconnecting its power supply.
- It will take 30 seconds to restart.
- Visit support.myharmony.com/smart-keyboard-add-on for additional help.

Get support

For more detailed information, please visit

support.myharmony.com/smart-keyboard-add-on

Finding answers to questions

Visit our knowledgebase at support.myharmony.com/smart-keyboard-add-on

Getting help with a mobile setup

Many screens and pages presented to you during setup contain 'Learn more' links designed to provide additional information or assistance with various features.

Logitech's Harmony Remote user forums

Visit the Harmony User Forums located at forums.logitech.com

Frequently asked questions

Why does the PlayStation require two connections?

The PlayStation requires a Bluetooth connection to power it on and off while the USB receiver is used for text entry and navigation.

Are additional USB receivers available?

The keyboard and Harmony Hub can pair with a maximum of two USB receivers. To maximize the number of devices you can control, use Bluetooth pairing whenever possible.

Can I move the USB receiver to another device?

Yes, but if you move the USB receiver to another device, don't forget to return to the Harmony App to update your account with this change to keep the solution synchronized and working.

2014 Logitech, Logitech, the Logitech logo, Harmony, the Harmony logo and other Logitech marks are owned by Logitech and may be registered. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG Inc. and any use of such marks by Logitech is under license. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained here is subject to change without notice.

Download PDF: [Logitech Harmony Smart Keyboard Add-on User Manual](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.