



# Logitech K520 Wireless Keyboard User Manual

[Home](#) » [Logitech](#) » Logitech K520 Wireless Keyboard User Manual 

## Contents

- [1 Logitech K520 Wireless Keyboard User Manual](#)
- [2 WHATS IN BOX?INSTALLATION INSTRUCTION](#)
- [3 Keyboard features](#)
- [4 Mouse features](#)
- [5 Battery management](#)
- [6 Troubleshooting](#)
- [7 Logitech K520 Wireless Keyboard User Manual](#)
- [8 Related Posts](#)




# Logitech K520 Wireless Keyboard User Manual






## WHATS IN BOX?



## INSTALLATION INSTRUCTION





Your Keyboard and mouse are now ready for use. You can download the Logitech® SetPoint™ Software if you want to customize your keyboard keys. [www.logitech.com/downloads](http://www.logitech.com/downloads)




### Keyboard features: F-key usage

User-friendly enhanced F-keys let you launch applications easily. To use the enhanced functions (yellow icons), first press and hold the key; second, press the F-key you want to use.

#### Tip

In the software settings, you can invert the FN mode if you prefer to access directly the enhanced functions without having to press the FN key.



### Keyboard features

1. Multimedia navigation
2. Volume adjustment
3. Application zone
  - + F1 Launches Internet browser
  - + F2 Launches e-mail application
  - + F3 Launches Windows Search\*
  - + F4 Launches media player
4. Windows view controls
  - + F5 Flip†
  - + F6 Shows Desktop
  - + F7 Minimizes window
  - + F8 Restores minimized windows
5. Convenience zone


- + F9 My Computer
- + F10 Locks PC
- + F11 Puts PC in standby mode
- + F12 Keyboard battery status check

6. Battery status indicator

7. Keyboard power switch

8. Internet navigation

- Internet back & forward navigation
- Internet favorites
- Launches calculator



One Touch Search if the SetPoint® software is installed. † Application Switcher if the SetPoint® software is installed.

## Mouse features

1. Battery LED
2. Vertical scrolling
3. On/Off slider
4. Battery-door release
5. Unifying receiver storage



## Battery management

Your keyboard has up to three years of battery life and your mouse has up to one.\*

### Battery sleep mode



Did you know that your keyboard and mouse go into sleep mode after you stop using them for a few minutes? This feature helps limit battery usage and eliminates the need to keep switching your devices on and off. Both your keyboard and mouse are up and running immediately once you begin using them again.

### How to check the battery level for the keyboard

Press and hold the FN key, then press the F12 key: If the LED glows green, the batteries are good. If the LED glows red, the battery level has dropped to 10% and you have only a few days of battery power left. You can also turn the keyboard off then back on using the On/Off switch on top of the keyboard.

### How to check the battery level for the mouse

Turn the mouse off then back on using the On/Off switch on the mouse bottom. If the LED on top of the mouse glows green for 10 seconds, the batteries are good. If the LED blinks red, the battery level has dropped to 10% and you have only a few days of battery power left.




Battery life varies with usage and computing conditions. Heavy usage usually results in shorter battery life.

**Plug it. Forget it. Add to it.**

You've got a Logitech® Unifying receiver. Now add a compatible wireless keyboard or mouse that uses the same receiver. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions. For more information and to download the software, visit [www.logitech.com/unifying](http://www.logitech.com/unifying)

Go to Start/All Programs/Logitech/Unifying/Logitech Unifying Software







## Troubleshooting

### Keyboard and mouse are not working


- **Check the USB connection.** Also, try changing USB ports.
- **Move closer?** Try moving the keyboard and mouse closer to the Unifying receiver, or plug the Unifying receiver into the receiver extender cable to bring it closer to the keyboard and mouse.



- **Check battery installation.** Also check the battery power of each device. (See Battery management for more information.)



On the mouse bottom, slide the On/Off switch right to turn on the mouse. The Battery LED on the mouse top case should light green for 10 seconds. (See Battery management for more information.)



- **Are you experiencing slow or jerky cursor movement?** Try the mouse on a different surface (e.g., deep, dark surfaces may affect how the cursor moves on the computer screen).
- **Is the keyboard turned on?** Slide the keyboard Off/On switch to the On position, as shown in the image below. The keyboard Status icons should light up.



- **Re-establish the connection.** Use the Unifying software to reset the connection between the keyboard/mouse and Unifying receiver. Refer to the Unifying section in this guide for more information (p. 15).

For additional help, refer to the Customer Support telephone numbers on page 58. Also visit [www.logitech.com/comfort](http://www.logitech.com/comfort) for more information about using your product, and for ergonomics.

© 2010 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-002463.004

## **Logitech K520 Wireless Keyboard User Manual**

**Download PDF:** [Logitech K520 Wireless Keyboard User Manual](#)

Manuals+.