

Logitech K845 Mechanical Illuminated Keyboard User Manual

[Home](#) » [Logitech](#) » Logitech K845 Mechanical Illuminated Keyboard User Manual 

Contents

- [1 Logitech K845 Mechanical Illuminated Keyboard](#)
- [2 K845 MECHANICAL ILLUMINATED CORDED ALUMINUM KEYBOARD](#)
- [3 INSTALLATIONS](#)
- [4 SHORTCUT KEYS](#)
- [5 CHANGE LIGHTING PATTERNS](#)
- [6 TO CHANGE SPEED OF LIGHTING EFFECTS](#)
- [7 Specs & Details](#)
 - [7.1 Dimensions](#)
 - [7.2 Technical Specifications](#)
 - [7.3 Warranty Information](#)
 - [7.4 Part Number](#)
- [8 Read More About:](#)
- [9 Download:](#)
- [10 FAQ – Frequently Asked Questions](#)
- [11 Related Posts](#)


Logitech K845 Mechanical Illuminated Keyboard

Logitech K845 Mechanical Illuminated Keyboard


User Manual

Meet the K845 Mechanical Illuminated, the corded keyboard that melds precise mechanics with a modern aluminum design. An adjustable angle, choice of mechanical switches, and 5 backlighting options let you work comfortably for hours.

K845 MECHANICAL ILLUMINATED CORDED ALUMINUM KEYBOARD




INSTALLATIONS




logitech.com/support/k845

SHORTCUT KEYS

+	F1 Decrease key brightness	F2 Increase key brightness	F3 Search	F4 Calculator	F5 Open Media	F6 Previous	F7 Play/Pause	F8 Next Media	F9 Mute	F10 Reduce Volume	F11 Increase Volume	F12 Change Lighting Pattern Five onboard patterns
FN												





CHANGE LIGHTING PATTERNS



1. Static max brightness
2. Serpent
3. Reactive
4. Random Lights
5. Breathing

TO CHANGE SPEED OF LIGHTING EFFECTS



© 2019 Logitech. Logitech, Logi and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

Specs & Details

Dimensions

Height: 5.00 in (127 mm)

Width: 17.13 in (435 mm)

Depth: 0.26 in (6.5 mm)

Weight: 27.51 oz (780 g)

Full-size with Numpad

- **Cable length:** 5.91 ft (1.8 m), PVC – free cable

Technical Specifications

Platform Compatibility

- **Windows 10 or later, Windows 8, Windows 7**
- **USB connection:** available USB port required.

Warranty Information

1-Year Limited Hardware Warranty

Part Number

- **BLUE / K845:** 920-009860
 - **BROWN / K845:** 920-009862
 - **RED / K845:** 920-009859
 - **CHERRY MX RED / K845ch:** 920-009863
 - **CHERRY MX BLUE / K845ch:** 920-009864
-

Read More About:

[Logitech K845 Mechanical Illuminated Keyboard User Manual](#)

Download:

Logitech K845 Mechanical Illuminated Keyboard User Manual – [[Download PDF](#)]

FAQ – Frequently Asked Questions

My NumPad/KeyPad is not working, what should I do?

– Make sure that the NumLock key is enabled. If pressing the key once doesn't enable NumLock, press and hold the key for five seconds.



– Verify that the correct keyboard layout is selected in Windows Settings and that the layout matches your keyboard.

– Try enabling and disabling other toggle keys such as Caps Lock, Scroll Lock, and Insert while checking if the number keys work on different apps or programs.

– Disable **Turn on Mouse Keys**:

1. Open the **Ease of Access Center** — click the **Start** key, then click **Control Panel > Ease of Access** and then **Ease of Access Center**.

2. Click **Make the mouse easier to use**.
3. Under **Control the mouse with the keyboard**, uncheck **Turn on Mouse Keys**.
 - Disable **Sticky Keys, Toggle Keys & Filter Keys** :
1. Open the **Ease of Access Center** — click the **Start** key, then click **Control Panel > Ease of Access** and then **Ease of Access Center**.
2. Click **Make the keyboard easier to use**.
3. Under **Make it easier to type**, make sure all checkboxes are unchecked.
 - Verify the product or receiver is connected directly to the computer and not to a hub, extender, switch, or something similar.
 - Make sure the keyboard drivers are updated. Click [here](#) to learn how to do this in Windows.
 - Try using the device with a new or different user profile.
 - Test to see if the mouse/keyboard or receiver on a different computer.

Logitech Options compatibility

The K845 mechanical keyboard is not supported in Logitech Options.

K845 keyboard functionality on Mac

While the keyboard is primarily designed to work with Windows, the keyboard shortcuts map to different keys in Mac. In particular, the primary key that is used for keyboard shortcuts in combination with other keys is frequently different. The following are the primary key substitutions on the Windows keyboard, and their Mac equivalents.

•

Windows	Mac
CONTROL	COMMAND (for most shortcuts) or CONTROL
ALT	OPTION
Windows/Start	COMMAND/Apple
BACKSPACE	DELETE
DELETE	DEL
SHIFT	SHIFT
ENTER	RETURN

This information can also be found in Microsoft website [here](#).

Fn key shortcuts

There are 12 shortcuts that use the Fn key:

Fn + F1	Decrease brightness	Fn + F7	Play/ Pause
Fn + F2	Increase brightness	Fn + F8	Next Track
Fn + F3	Search	Fn + F9	Mute
Fn + F4	Open calculator	Fn + F10	Decrease Volume
Fn + F5	Open media player	Fn + F11	Increase Volume
Fn + F6	Previous track	Fn + F12	Toggle light pattern

Increase or decrease K845 keyboard brightness

You can increase or decrease the brightness of the keyboard by simultaneously pressing Fn + F2 or Fn + F1 respectively.

Personalization of keys on K845

There is no support for key personalization on Logitech K845 keyboard.

Increase or decrease the K845 keyboard illumination pattern speed

You can increase and decrease the speed of the lighting patterns by simultaneously pressing Fn + the right arrow key or Fn + the left arrow key.

Change K845 keyboard illumination patterns

Press Fn + F12 simultaneously to toggle through the illumination patterns. There are five patterns on the keyboard: Static, Snakes, Breathing, Reactive, and Random.