



Logitech MK710 Wireless Keyboard and Mouse Combo User Manual

[Home](#) » [Logitech](#) » Logitech MK710 Wireless Keyboard and Mouse Combo User Manual 

Contents

- [1 Logitech MK710 Wireless Keyboard and Mouse Combo](#)
- [2 What's In the Box](#)
- [3 USB Plug-in](#)
- [4 Instructions Before Use](#)
- [5 Battery Installation](#)
- [6 Keyboard Features](#)
 - [6.1 F-key Usage](#)
 - [6.2 F-keys and More](#)
 - [6.3 Media Keys and Status Icons](#)
- [7 Mouse Features](#)
- [8 Battery Management](#)
- [9 Plug it. Forget it. Add to it](#)
- [10 Troubleshooting](#)
- [11 FAQ's](#)
- [12 References](#)




Logitech MK710 Wireless Keyboard and Mouse Combo




What's In the Box



USB Plug-in



Instructions Before Use



Battery Installation



Your Keyboard and mouse are now ready for use. Install the Logitech® SetPoint™ Software to do the following:


- Enable some of the F-keys and customize up to 14 keys on the keyboard
- Enable the Mute icon on the LCD
- Enable the tilt wheel and customize up to 6 buttons on the mouse

Keyboard Features


F-key Usage

[FN] User-friendly enhanced F-keys let you launch applications easily. To use the enhanced functions (yellow icons), first press and hold the **FN** key; second, press the F-key you want to use.

Tip: In the software settings, you can invert the FN mode if you prefer to access directly the enhanced functions without having to press the FN key.










F-keys and More




1. Internet zone
2. Convenience zone

	Launches Internet browser
	Launches e-mail application
	One Touch Search™*
	Launches instant message application*
	Launches application switcher*
	Zoom in*
	Zoom out*
	Windows Gadget or Settings*

3. Productivity zone
4. Context menu
5. PC sleep mode
6. Eject button*

	Launches media player
	Launches Photo Gallery*
	Launches document application*
	Launches spreadsheet application*
	Display contextual menu of selected item.
	Places your computer in energy-saving sleep mode.
	Opens CD/DVD-ROM drive drawer.

7. Multimedia navigation
8. LCD Dashboard icon status



9. Volume control

10. Keyboard off/on the switch


11. Launches calculator



Media Keys and Status Icons



Mouse Features



Zoom
Press scroll wheel to zoom.

MicroGear precision scroll wheel
Tilt wheel for side-to-side (horizontal) scrolling through spreadsheets or wide documents. The scroll wheel doubles as a middle button. Press down to use and press again to release.




Scroll toggle
With the flick of a switch, change between precision (click-to-click) scrolling and hyper-fast scrolling.

Precision scrolling



Use click-to-click mode to navigate lists or slides.

Hyper-fast scrolling



The wheel spins freely, allowing you to fly through long documents and Web pages.

1. **Back and Forward Buttons*** – Press to flip between web pages.
2. **Application Switch*** – Press the rubber grip to switch between applications.
3. **Battery Indicator Light** – Turns red when a couple of weeks of battery life remain.
4. **On/Off Switch** – Slide to turn the mouse on and off.
5. **Battery Door Release** – Press where indicated and slide the door off the mouse. Reduce weight by installing a single battery.
6. **Receiver Storage Space Inside the Mouse**

* Application Switcher and side-to-side scrolling require Logitech software. Depending on your operating system, the back, forward, and middle buttons may also require Logitech software.





Battery Management

Your keyboard and mouse have up to three years of battery life.*

- **Battery sleep mode**

Did you know that your keyboard and mouse go into sleep mode after you stop using them for a few minutes? This feature helps limit battery usage and eliminates the need to keep switching your devices on and off. Both your keyboard and mouse are up and running immediately once you begin using them again.

- **How to check the battery level for the keyboard**

The battery icon on the keyboard LCD shows the current battery level for the keyboard. As the battery level decreases, the battery icon shows how much battery power remains, as shown in the image to the right.



- **How to check the battery level for the mouse**


- **Option 1:** Turn the mouse off and then back on using the On/Off switch on the mouse bottom. If the LED on top of the mouse glows green for 10 seconds, the batteries are good. If the LED blinks red, the battery level has dropped to 10% and you have only a few days of battery power left.
- **Option 2:** Launch the SetPoint Software, and click the Mouse Battery tab to see the current battery level of the mouse.

* Battery life varies with usage and computing conditions. Heavy usage usually results in shorter battery life.



Plug it. Forget it. Add to it

You've got a Logitech® Unifying receiver. Now add a compatible wireless keyboard or mouse that uses the same receiver. It's easy. Just start the Logitech® Unifying software* and follow the onscreen instructions. For more information and to download the software, visit www.logitech.com/unifying




Troubleshooting

The keyboard and mouse are not working




- **Check the USB connection.** Also, try changing USB ports.
- **Move closer?** Try moving the keyboard and mouse closer to the Unifying receiver, or plug the Unifying receiver into the receiver extender cable to bring it closer to the keyboard and mouse.
- **Check battery installation.** Also, check the battery power of each device. (See Battery management for more information.)

On the mouse bottom, slide the On/Off switch right to turn on the mouse. The Battery LED on the mouse top case should light green for 10 seconds. (See Battery management for more information.)




- **Are you experiencing slow or jerky cursor movement?**

Try the mouse on a different surface (e.g., deep, dark surfaces may affect how the cursor moves on the computer screen).



- **Is the keyboard turned on?**

Slide the keyboard Off/On switch to the On position, as shown in the image below. The keyboard Status icons should light up.



- **Re-establish the connection.**

Use the Unifying software to reset the connection between the keyboard/mouse and the Unifying receiver. Refer to the Unifying section in this guide for more information.

- **Install Logitech SetPoint Software**

to customize your keyboard and mouse in order to fully take advantage of all features.

logitech.com/downloads

For additional help, refer to the Customer Support telephone numbers. Also visit www.logitech.com/comfort for more information about using your product, and for ergonomics.

FAQ's

Is the Logitech MK710 Wireless Keyboard and Mouse Combo compatible with both Windows and Mac operating systems?

Yes, the Logitech MK710 Combo is compatible with both Windows and Mac operating systems.

Does the Logitech MK710 Combo use a wireless connection?

Yes, the Logitech MK710 Combo uses a 2.4GHz wireless connection to connect the keyboard and mouse to your computer.

How far is the wireless range of the Logitech MK710 Combo?

The wireless range of the Logitech MK710 Combo is up to 10 meters (33 feet), allowing you to use the keyboard and mouse comfortably from a distance.

Is the Logitech MK710 Combo a full-size keyboard?

Yes, the Logitech MK710 Combo features a full-size keyboard with a standard layout, including a number pad.

Does the Logitech MK710 Combo have backlit keys?

No, the Logitech MK710 Combo does not have backlit keys. The keys are not illuminated.

How long does the battery life last on the Logitech MK710 Combo?

The Logitech MK710 Combo boasts an impressive battery life of up to three years for the keyboard and up to one year for the mouse, depending on usage.

Can I customize the function keys on the Logitech MK710 keyboard?

Yes, you can customize the function keys using the Logitech SetPoint software. This allows you to assign different functions or actions to the function keys.

Is the Logitech MK710 keyboard spill-resistant?

Yes, the Logitech MK710 keyboard has a spill-resistant design, which helps protect it from accidental spills. However, it is not completely waterproof, so it's still best to avoid liquid exposure.

Does the Logitech MK710 Combo support Bluetooth connectivity?

No, the Logitech MK710 Combo does not support Bluetooth connectivity. It uses a dedicated USB receiver for wireless communication.

Can I use the Logitech MK710 keyboard and mouse separately with different devices?

Yes, you can use the Logitech MK710 keyboard and mouse separately with different devices, as long as each device has a compatible USB port for the wireless receiver.

Does the Logitech MK710 Combo come with a palm rest?

Yes, the Logitech MK710 Combo includes a cushioned palm rest, providing extra comfort during extended typing sessions.

Is the Logitech MK710 Combo compatible with gaming?

While the Logitech MK710 Combo is primarily designed for general use and productivity, it can be used for casual gaming. However, for dedicated gaming purposes, a specialized gaming keyboard and mouse might be more suitable.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.