

Logitech POP Home Switch



Logitech POP Home Switch User Manual

[Home](#) » [Logitech](#) » Logitech POP Home Switch User Manual 

Contents

- [1 Logitech POP Home Switch User Manual](#)
- [2 THINGS YOU'LL NEED](#)
- [3 SETTING UP](#)
- [4 EASY INSTALL —NO TOOLS OR WIRES](#)
- [5 References](#)
- [6 Related Posts](#)



Logitech POP Home Switch User Manual



THINGS YOU'LL NEED

TO BEGIN

Logitech Pop Home Switch Starter Kit (sold separately) Wi-Fi internet connection iOS or Android™ phone:

- iPhone 5 or later and iPod 5th Gen or later with iOS 9 or higher
- Android phone with Android 4.4 or higher and Bluetooth® Smart

SETTING UP

YOUR POP-HOME SWITCH

Download the Logitech Pop app from the App Store or Google Play. Launch the app and log in. Tap the pencil icon in the upper right corner. Then tap the “+” sign on the bottom of the screen for a guided setup.

EASY INSTALL —NO TOOLS OR WIRES

Use your Pop Home Switch anywhere in your home. You can mount your Pop Home Switch to a wall or countertop. Just stick the double-sided mounting tape on a clean, smooth surface and then place your Pop Home Switch on the tape, hold it in place for 20 seconds, and you're done. It's easy to move your Pop Home Switch — just twist to pull the switch off the wall. To clean your Pop Home Switch, use a damp cloth with soap and water or rubbing alcohol.

For more information go to logi.com/support/pop. 2016 Logitech. All rights reserved. Logitech, Logi and other Logitech marks are owned by Logitech and may be registered. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. All other trademarks are the property of their respective owners.

Download PDF: [Logitech POP Home Switch User Manual](#)

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.