Manuals+ — User Manuals Simplified.

logitech

PRO X
SUPERLIGHT 2
DEX Wireless
Gaming Mouse

logitech PRO X SUPERLIGHT 2 DEX Wireless Gaming Mouse User Guide

Contents

logitech

**logitech PRO X SUPERLIGHT 2 DEX Wireless Gaming Mouse**

WHAT'S IN THE BOX

PACKAGE CONTENTS

1. Mouse
2. Optional grip tape
3. Receiver (installed in extension adapter) 4 USB charging and data cable
4. Surface preparation cloth
5. Optional POWERPLAY aperture door with PTFE foot

1 **2**

3 **4**

5 **6**

MOUSE FEATURES

1. Left Click
2. Right Click
3. Middle Click/Scroll
4. Browser Back
5. Browser Forward
6. Power LED
7. USB charging/data part 8 Power on/off
8. POWERPLAY Aperture door

SETUP

1. Plug charging/data cable into PC, then plug extension adapter and receiver into charging/data cable
2. Turn on mouse

3. To configure mouse settings like DPI or report rate, download G HUB software from **logitechG.com/GHUB**

optimal wireless

For optimal wireless performance, use a mouse within 20cm of the receiver and greater than 2m from sources of 2.4GHz interference (such as wifi routers).

install optional grip

To install optional grip tape, first clean the surface of mouse with the provided surface preparation cloth to remove any oil or dust. Then, carefully align grip tape to mouse surfaces.

USB receiver

The USB receiver can be stored inside the mouse by removing the POWERPLAY aperture door. This can prevent the receiver from being lost when using the mouse with the Logitech G POWERPLAY wireless charging system. Removing this door also allows the included, optional aperture door with PTFE foot to be installed instead of the default aperture door.

Documents / Resources

	logitech PRO X SUPERLIGHT 2 DEX Wireless Gaming Mouse [pdf] User Guide PRO X SUPERLIGHT 2 DEX Wireless Gaming Mouse, PRO X SUPERLIGHT 2 DEX, Wireless Gaming Mouse, Gaming Mouse, Mouse

References

- **User Manual**