

logitech R400 Wireless Presentation Remote User Guide

Home » Logitech » logitech R400 Wireless Presentation Remote User Guide 🖺

Contents

- 1 logitech R400 Wireless Presentation Remote
- 2 Product Diagram (PRESREMOTEG)
- **3 FCC Compliance Statement**
- **4 IC Radiation Exposure Statement**
- **5 Warranty Information**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts



logitech R400 Wireless Presentation Remote



Product Diagram (PRESREMOTEG)



	Button/LED	Function
		Indicates remote activity, lights up when buttons on the
		Remote are pressed.
1	LED Indicator	Notes: The USB Wireless Receiver must be removed from the remote for the L ED Indicator to work.
		The LED Indicator will flash when the batteries need to be replaced.
		Starts or ends the presentation within compatible software.
2	Play/ESC	Used as the Back button when in menus.
		Used as the zoom out function when zoomed in.
3	Last	Moves to the previous action. (animations, transitions, slides, etc.).

	Button/LED	Function
4	Tab	Cycles through on-screen elements. Note: When not presenting, the Tab Button cycles through screen elements on the screen the mouse indicator is located.
5	Laser	Activates the Laser Pointer. Note: The USB Wireless Receiver must be removed from the remote for the Laser Pointer to work.
6	USB Wireless Receiv er	Connects the Remote to the Host Computer.
7	Volume Up	Turns the Host Computer's volume up.
8	Volume Down	Turns the Host Computer's volume down
9	Blank	Turns the screen Off/On.
10	Next	Moves to the Next action (animations, transitions, slides, etc.).
11	Enter	Emulates the Enter/Return button on a keyboard.

Requirements

For the latest requirements, please visit <u>www.startech.com/PRESREMOTEG</u>.

• Host Computer with USB-A Port.

Battery Installation

- 1. Press down on the Battery Bay and slide the Battery Cover away to reveal the Battery Compartment.
- 2. Insert two AAA Batteries (included), aligning the positive (+) and negative (-) ends of the batteries with the indicators inside the Battery Compartment.
- 3. Align the Battery Cover on the back of the Remote and slide it back into place.

Connecting the Remote

- 1. Remove the USB Wireless Receiver from the Storage Slot on the bottom of the Remote.
- 2. Connect the USB Wireless Receiver to a USB-A Port on the Host Computer.

Note: The Remote will appear as 2.4G PRESENTER in system menus on the Host Computer.

To view manuals, FAQs, videos, drivers, downloads, technical drawings, and more, visit www.startech.com/support.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15, subpart C of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15, subpart C of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

FCC-ID: 2AAQO-R4002

• IC-ID: 11232A-PRESREMOTEG

IC Radiation Exposure Statement

This equipment complies with IC RSS-210 radiation exposure limit set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5cm between the radiator and your body.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads. For the latest drivers/software, please visit www.startech.com/downloads

Warranty Information

This product is backed by a one-year warranty. StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

• If product has an exposed circuit board, do not touch the product under power.

StarTech.com Ltd.

- 45 Artisans Crescent
- · London, Ontario
- N5V 5E9
- Canada

StarTech.com LLP

- 4490 South Hamilton
- Road
- · Groveport, Ohio
- 43125
- U.S.A.

StarTech.com Ltd.

- Unit B, Pinnacle 15
- Gowerton Road
- Brackmills,
- Northampton
- NN4 7BW

• United Kingdom

StarTech.com Ltd.

- Siriusdreef 17-27
- 2132 WT Hoofddorp
- The Netherlands

Documents / Resources



<u>logitech R400 Wireless Presentation Remote</u> [pdf] User Guide

R400, Wireless Presentation Remote, R400 Wireless Presentation Remote, Presentation Remote, Remote

References

- StarTech.com | IT Pro's Trusted Source for Connectivity Accessories
- **1** P65Warnings.ca.gov
- <u>Drivers & Downloads | StarTech.com Support</u>
- Presentation Remote Green Laser 90' Remotes
- StarTech.com Support

Manuals+,