



logitech RALLY Plus Video Conferencing Camera User Guide

[Home](#) » [Logitech](#) » logitech RALLY Plus Video Conferencing Camera User Guide 

Contents

- [1 logitech RALLY Plus Video Conferencing Camera](#)
- [2 WHAT'S WHAT](#)
- [3 REMOTE](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

logitech®

logitech RALLY Plus Video Conferencing Camera




Specifications

- RALLY System
 - Components: Table Hub, Display Hub, Camera, Remote Control
 - Connectivity: Bluetooth, USB, HDMI
 - Control: Remote control for camera settings

WHAT'S WHAT


TABLE HUB

1. Power
2. Mic Pod
3. Future Expansion
4. Connection To Display Hub
5. HDMI 1 In
6. HDMI 2 In
7. Meeting Room Computer USB
8. Future Expansion
9. Security Slot
10. Power LED




DISPLAY HUB

1. Speaker
2. Power
3. Connection To Table Hub
4. HDMI 1 Out
5. HDMI 2 Out
6. Meeting Room Computer USB
7. Camera
8. Security Slot
9. Remote Control Pairing
10. Power LED




CAMERA

1. Remote control pairing button
2. USB
3. Status LED
4. Security slot
5. MIPI
6. Tripod Thread
7. Expansion Slot



REMOTE

1. Bluetooth pairing
2. Call answer
3. Call end
4. Microphone mute
5. Zoom in/out
6. Volume up/down
7. Home
8. Camera pan/tilt
9. Camera presets



After completing the installation, the system can be checked by running the diagnostic application available at Logitech.com/support/Rally.

MAKE RALLY THE DEFAULT DEVICE

Ensure that RALLY is chosen as the camera, speaker and microphone in your video conferencing applications. Please consult the application documentation for further instructions on how to do this.

STARTING A VIDEO CALL

After installing RALLY and ensuring it is the default device in your video conferencing application, simply start the application in the normal manner and enjoy the benefits of improved audio and video.

PAIRING RALLY TO A BLUETOOTH DEVICE

You can use RALLY for audio calls when paired to a Bluetooth device. To pair your Bluetooth device to RALLY, follow these simple step:

1. Press and hold the Bluetooth button on the remote control until you see a flashing blue light on the camera and microphones.
2. Place your mobile device in Bluetooth pairing mode and select "Logitech Rally".
3. You are now ready to use RALLY for audio calls.

PAIRING A REMOTE CONTROL

TO RALLY

RALLY and the remote control are paired at the factory. You can pair up to 5 remote controls to RALLY to make it easier to control the system in larger rooms. Or, if you need to pair a remote to the camera, such as when replacing a lost remote, do the following:

1. Press and hold the button on the camera until the LED flashes.
2. Press and hold the button on the Display Hub until the LED flashes.
3. Press and hold the Bluetooth button on the remote control until the LEDs on both the camera and Display Hub stop flashing.
4. If the pairing fails, repeat from step 1..

CAMERA SETTINGS APPLICATION

Use this program to control the camera pan, tilt, zoom, focus, and image quality (like brightness and contrast) from your computer. The software can be downloaded from www.logitech.com/support/Rally.

ENHANCING RALLY

There are several optional accessories that ease installation and allow RALLY to be used in larger rooms:

1. Rally Mounting Kit: Mounting brackets for the Table Hub, Display Hub, Camera and Speakers.
2. Extra Mic Pods: RALLY can support up to 7 Mic Pods allowing great flexibility in room size and configuration.
3. Mic Pod Hub: Used to branch microphone routing and run most of the Mic Pod cabling is below the table. The Mic Pod Hub has 3 jacks that can be connected to a combination of Mic Pods or other Mic Pod Hubs.
4. TV mount: Works with one of either the Camera or Speaker mounting brackets. The TV Mount can be used in pairs to mount the Camera and Speaker above and below the TV.

FOR MORE INFORMATION

You can find additional information on RALLY including:

- FAQs
- Software to enable functions in various application
- How to order replacement parts and more at www.logitech.com/support/Rally

TRA

REGISTERED No:

V-R0009 ER67203/18

V-R0010 ER63945/18

V-R0011 ER67241/18

DEALER No:

DA0065887/11

Oman – TRA

D172338

V-R0009 TRA/TA-R/8103/19

V-R0011 TRA/TA-R/8106/19

V-R0010 TRA/TA-R/8109/19

© 2020 Logitech, Logi and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.


WEB-621-001375.003

FAQ

Q: How can I enhance my RALLY system?

A: There are optional accessories available to ease installation and enhance the performance of RALLY, especially in larger rooms. Refer to the product manual for more information on compatible accessories.

Documents / Resources

	<p>logitech RALLY Plus Video Conferencing Camera [pdf] User Guide</p> <p>RALLY Plus Video Conferencing Camera, RALLY, Plus Video Conferencing Camera, Video Conferencing Camera, Conferencing Camera</p>
---	--

References

-  [Logitech Rally & Rally Plus Product Support](#)
-  [Your Ultimate Resource for Millions of User Manuals](#)
-  [Logitech Australia](#)
-  [Logitech Rally & Rally Plus Product Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.