

logitech Z533 Speaker System with Subwoofer User Guide

Home » Logitech » logitech Z533 Speaker System with Subwoofer User Guide T

Contents


- 1 logitech Z533 Speaker System with Subwoofer
- **2 KNOW YOUR PRODUCT**
- **3 CONNECT THE SPEAKERS**
- **4 CONNECT TO AUDIO SOURCE**
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**

logitech

logitech Z533 Speaker System with Subwoofer





KNOW YOUR PRODUCT



CONNECT THE SPEAKERS

- 1. Plug the black RCA connector on the right satellite into the black subwoofer jack
- 2. Plug the blue RCA connector on the left satellite into the blue subwoofer jack
- 3. Plug the power plug into an electrical outlet





CONNECT TO AUDIO SOURCE

1. For 3 5 mm connection:


Connect one end of the provided 3 5 mm cable to the corresponding jack on the back of subwoofer or the 3 5 mm jack on the control pod Insert the other end of the 3 5 mm cable into the audio jack on your device (computer, smartphone, tablet, etc.)

2. For RCA connection:

Connect one end of the RCA cable to the corresponding RCA jack on the back of subwoofer Insert the other end of the RCA cable into the RCA outlet on your device (TV, gaming console, etc.)


Note: The RCA cable is not included in the box and must be purchased separately

- 3. Plug your headphones into the headphone jack on the control pod Adjust the volume either from the control pod or the audio source
- 4. Power speakers on/off by turning clockwise the volume knob on the control pod You will notice a "click" sound once the system is ON (the LED in front of the wired remote will also turn on)



CONNECT TO TWO DEVICES SIMULTANEOUSLY

- 1. Connect to two devices at the same time through the RCA connector and 3 5 mm input on the back of subwoofer
- 2. To switch between audio sources, just pause audio on one connected device and play audio from the other connected device





ADJUST THE VOLUME

1. Adjust the volume of Z533 with the knob on the control pod Turn the knob clockwise (to the right) to increase volume Turn the knob counter-clockwise (to the left) to decrease volume

ADJUST THE BASS

2. Adjust the bass level by moving the bass slider on the side of the control pod





www.logitech.com/support/Z533

© 2019 Logitech Logitech, Logi and other Logitech marks are owned by Logitech and may be registered All other trademarks are the property of their respective owners Logitech assumes no responsibility for any errors that may appear in this manual Information contained herein is subject to change without notice

Documents / Resources



<u>logitech Z533 Speaker System with Subwoofer</u> [pdf] User Guide Z533, Speaker System with Subwoofer, Z533 Speaker System with Subwoofer, Z533 Speaker System, Speaker System

References

• In the location of the locat

Manuals+, home privacy