



Lorelli Playmat Owner's Manual

[Home](#) » [lorelli](#) » Lorelli Playmat Owner's Manual

Contents [[hide](#)]

- [1 Lorelli Playmat](#)
- [2 Playmat](#)
- [3 Cleaning instructions](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



Lorelli Playmat



Playmat

Features: Archs with toys: 2 plastic rattles: hippopotamus and rhinoceros; 2 toys: butterfly and Flower; mirror
THIS PRODUCT IS SUITABLE FOR INFANTS 0+ MONTHs.

Baby can play by grasping, rotating, pressing, and shaking the toys. The various toys are suitable for the different stages of the baby's growth. Thanks to the hanging toys the children can easily pull them down, which can practice children's upper limbs strength and stimulate their athletic ability.

- **Stimulating visual development** – Bright colors can develop a baby's ability to identify different colors.
- **Develop touching ability** – Stimulate baby's touching ability by touching different parts of the product.
- **Hand-Eye coordination ability** – Baby can make it fun by kicking and shaking toys.
- **WARNING!**
- Where applicable, remove any plastic fasteners, threads and packaging from this playmat before giving it to a child.
- The activity arches and toys are not intended to be mounted by the baby and should be positioned clearly out of the baby's face and mouth.
- Remove activity arches from the playmat when baby begins to push up on his hands and knees.
- Do not add additional strings/ cords to the playmat.
- Do not modify the playmat-do not string it across a crib or a playpen.
- It is advisable to remove toys from a sleeping baby.
- Toy bar with toys: To prevent possible injury by entanglement, remove this toy when the child starts trying to get up on its hands and knees in a crawling position.
- Keep away from fire!
- To prevent entanglement injury, never place the gym in a crib/cot or playpen!
- Arches are under tension. Grasp carefully on both ends and set firmly to avoid any injury!
- Product should be used under adult supervision.

- Do not tie together with other toys.
- Do not use this product as a blanket.
- Use this product only on the floor.
- Do not leave the child unattended.
- Mount only by adults.
- Please retain the original packaging for future reference!
- Colors and content may vary from illustrations.


Cleaning instructions

- **Mat Care** – Remove the tubes and supports from the mat. Machine wash the mat inside a pillowcase in cold water on a gentle cycle. Do not use bleach. Line dry the mat at a low temperature. Do not iron.
Do not dry clean.
- **Tube, Support & Activity Toy Care** – Wipe with a clean cloth dampened with a mild soap and water solution. Do not immerse. Only surface wash. Do not use bleach. Do not dry clean.

Content:

- **Mat: 100% polyester; Arch: 100% polyester;**
- **Toys: ABS, TPE; Rattles:**
- **PP; Mirror: nonwoven fabric & PP;**
- **Hooks: PP**
- **Producer: Didis Ltd.,**
- **Bulgaria, Shumen, 6 Trakia-iztok Street**
- **Phone: +359 54 850 830**
- **e-mails: home.market@didis-ltd.com**
- **export@didis-ltd.com**
- **www.lorelli.eu**

Documents / Resources



[Lorelli Playmat](#) [pdf] Owner's Manual
Playmat, Play Mat, Mat