

Lorelli Twin Double Stroller Instruction Manual

Home » lorelli » Lorelli Twin Double Stroller Instruction Manual



Contents

- 1 Lorelli Twin Double Stroller
- **2 SAFETY REQUIREMENT**
- **3 MAINTENANCE AND CARE**
- 4 PARTS
- **5 UNFOLDING THE STROLLER**
- **6 INSTALLATION OF THE FRONT**
- **WHEELS**
- **7 USING THE BRAKES**
- **8 USING THE SAFETY BELTS**
- 9 CONTACT
- 10 Documents / Resources
 - 10.1 References



Lorelli Twin Double Stroller



IMPORTANT- READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

SAFETY REQUIREMENT

- 1. This vehicle is suitable for 2 children with a total weight of up to 30 kg.!This vehicle is suitable for twins-two babies with a maximum weight of each of the children up to 15 kg.
- 2. The height of the carried child in the stroller should not exceed 96 cm!
- 3. Use a parking device if you do not hold the stroller with your hand!
- 4. Do not leave the stroller on hills or inclined surfaces even if you have activated the parking system!
- 5. fo Parking device shall be engaged when placing and removing the children!
- 6. The shopping basket can take a maximum load of 2 kg!
- 7. Any load attached to the handle and/or on the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle! Maximum load of the accessory bag 1 kg. Do not hang any additional bags!
- 8. Regularly check for loose parts! Make routine inspection, regularly maintain, clean and/or wash the vehicle!
- 9. The vehicle shall be used only forup to 2 children!
- 10. Accessories that are not approved by the manufacturer shall not be used!
- 11. Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.
- 12. Always use the restraint system! Always use the crotch belt in combination with the waist belt! To prevent injury from a fall or a slip off always use the shoulder straps!
- 13. Make sure that the safety belts are placed properly!
- 14. The stroller should always be used under the supervision of an adult!
- 15. Do not allow children to suspend him/herself or play in the stroller!
- 16. Do not allow children to stand in the stroller!
- 17. Do not allow your child to stand on the seat and footrest!
- 18. Do not use the stroller on uneven surfaces near fire or other dangerous places!
- 19. Do not use the stroller on stairs and escalators!
- 20. Fold the stroller before go upstairs and downstairs. Mounting the stroller on stairs, pavements and others with the child in it and by pushing the handle causes deformation of the stroller and is out of warranty repair!
- 21. Adjusting of the backrest must be made only by a person who reads carefully the instruction rules for adjusting!

- 22. Any additional baggage left in the stroller may cause it to become unstable!
- 23. The person who assembles the stroller must be familiar with its functions!
- 24. No additional mattress I cushion shall be added.
- 25. The front bar can not be used as a carry handle.
- 26. This stroller is suitable for children up to 3 years old!

WARNING



- WARNING! Never leave the child unattended!
- WARNING! Ensure that all the locking devices are engaged before use
- WARNING! To avoid injury ensure that the child is kept away when unfolding and folding this product!
- WARNING! Do not let the child play with this product!
- **WARNING!** This pushchair is designed to be used from the baby's birth. You shall use the most reclined position for newborn babies. The newborn child is not able to sit and hold his/her head up unassisted. Therefore do not fix the backrest in sitting position for children under 6 months!
- WARNING! Always use the restraint system!
- WARNING! Check that the pram body seat unit or car seat attachment devices are correctly engaged before use
- WARNING! This product is not suitable for running or skating!
- WARNING! Keep away from fire!
- WARNING! Images on the title page and in the instruction manual are only illustrative and may differ from the real product.

EN 1888-1 :2018+A1 ·2022

MAINTENANCE AND CARE

- 1. To clean the metal parts, wipe with a moist and then dry towel until the stroller is all dry.
- 2. To clean the plastic parts, use a towel, water and a soft detergent.
- 3. To clean the textile parts, use a solution for cleaning tapestries.
- 4. When not in use, never place other objects in or on the stroller! This will damage it!
- 5. Always dry and air the stroller if it is not dry enough!
- 6. Run regular clean-ups over the wheel axes and the plastic elements.
- 7. Always clean the wheel axes and plastic elements after using the pram over sandy or dusty surfaces!
- 8. DO NOT LUBRICATE the wheel axes or other movable parts of the stroller! Just clean them!
- 9. Run regular checks for loose or damaged parts and if there are such, immediately replace them with a new one

PARTS



- 1. The metal frame of the stroller -1 pc.
- 2. Seat unit 1 pc.
- 3. Canopy 1 pc.
- 4. Fronbar 1 pc.
- 5. Front Wheels 2 pcs.
- 6. Rear Wheels 2 pcs.
- 7. Shopping Basket -1 pc.
- 8. Footcover 2 pcs.
- 9. Accessory bag -1 pc.

UNFOLDING THE STROLLER

- Release the lock clip on the right side of the frame.
- Unfold the stroller to the full open position.




INSTALLATION OF THE FRONT WHEELS

- Remove the plastic caps from the front wheel posts before assembling the wheels.
- Slide the front wheel assembly onto metal posts as shown until it clicks into place.
- Repeat the same steps for the other wheel.





INSTALLATION OF THE REAR WHEELS

- Remove and discard the protective plastic cap from the ends of the rear axle assembly.
- Position the rear axle assembly as shown with brake levers pointing towards the stroller handle.
- Push both brake assemblies and centre axle brake onto rear leg tubes at the same time.
- Make sure that plastic tabs on brake assemblies lock into openings on rear legs as shown.
- · Slide the wheel onto the axle.



- Snap the retainer washer onto the axle. Make sure that the larger end of the retainer is towards the wheel.
- Snap the retainer cap over the retainer washer.
- Line up tabs in each of the bub caps with slots in the wheel. Snap bub caps into place.
- Repeat the same operation for the other wheel.
- Assembling the footrest: Put the footrest in the right position and fix it on the frame. Then push the top of the footrest and fix it within a plastic part.






ATTACHING/REMOVING THE NAPPER BAR

CAUTION! If the stroller arrives with a clear plastic sleeve on the Napper Bar remove it before using the stroller so your child will not choke on the plastic!


ATTACHING THE NAPPER BAR


- Hold Napper Bar so that the curved part of the plastic ends face up.
- Place the Napper Bar on the stroller directly under the stroller locking mechanism.
- Snap tabs on each side of the Napper Bar and lock them.



REMOVING THE NAPPER BAR

- Unsnap tabs on each side of the Napper Bar.
- remove the Napper Bar.





Tab unsnapped


Tab snapped

WARNING

Do not lift the stroller by Napper Bar

USING THE BRAKES

- Push the levers on all wheel assemblies down to activate the brakes of the stroller.
- Pull the levers up to deactivate the brakes.



FIX THE FRONT WHEELS TO MOVE ONLY FORWARD

- Push the levers on the front wheels down to unlock the wheel to turn I n any direction.
- Pull the levers on the front wheels up to lock the wheel to move only forward.


NOTE: On rough surfaces lock the wheels to keep them moving only forward. On a smooth surface unlock the wheels to turn in any direction.



USING THE SAFETY BELTS


Adjusting





Unlocking


Locking




Tightening

ADJUSTING THE BACKREST

Lift the levers on both sides of the stroller up to recline the backrest.








FOLDING THE STROLLER

- Activate the brakes.
 - Push up the backrest.
- Fold the canopy.
 - Pull the locking levers up to fold the handle.
- Fold the stroller.

NOTE: Fold the stroller so the wheels straddle the frame. Do not allow wheels to press against the frame as this may damage the tires.







CONTACT

- Didis Ltd.
- Bulgaria, Shumen, 6 Trakia-iztok Street
- Phone: +359 54 850 830
- e-mails: home.market@didis-ltd.com
- export@didis-ltd.com



Scan the QR code to get more product information and manual instruction in more languages. Download the QR Scanner App onto your device. SDR/UP/ME/RIH

www.lorelli.eu

Documents / Resources



<u>Lorelli Twin Double Stroller</u> [pdf] Instruction Manual Twin Double Stroller, Double Stroller, Stroller

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.