




H512906- AI Two Light Linear



Lowes H512906-AI Two Light Linear Installation Guide


[Home](#) » [lowes](#) » **Lowes H512906-AI Two Light Linear Installation Guide** 

Contents

- [1 Lowes H512906-AI Two Light Linear](#)
- [2 Product Usage Instructions](#)
- [3 FAQ](#)
- [4 TOOLS REQUIRED](#)
- [5 PARTS TYPE](#)
- [6 ASSEMBLY & INSTALLATION INSTRUCTIONS](#)
- [7 ORDERING PARTS](#)
- [8 CLEANING](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



Lowes H512906-AI Two Light Linear



Product Usage Instructions

Preparation:

Before starting assembly and installation, prepare the following tools (NOT INCLUDED):

- Ladder
- Philips Head or Flat Blade Screwdriver
- Electrical Tape
- Pliers
- Wire Cutter/Stripper

Assembly & Installation:

1. Carefully remove the fixture from the carton and check that all parts and accessories are included.
2. Turn off power before starting the installation.
3. Remove the mounting plate (C).
4. Adjust tubes (H) as shown in the illustration.
5. Pass the fixture wires through the chosen tubes (H), the swivel joint (F), and the canopy (E).
6. Tighten all threaded tubes and screw them onto the swivel joint (F) and the top of connector (I). Hand tighten till snug.
7. Secure the fixture with mounting screws (B).
8. Connect wires as indicated in the provided charts. Never connect other wires to ground wires.

FAQ

- **Q: Can I use bulbs with wattage higher than 40W?**
 - A: No, the maximum wattage per bulb for this product is Type B, Max 40W. Using higher wattage bulbs can damage the product.
- **Q: How do I clean the lamp?**
 - A: To clean the lamp, switch it off, unplug it, and wait until it cools down. Use a soft, dry cloth to gently wipe the surface. Avoid using acidic or alkaline substances for cleaning.

Item Number: 6641218






WARNING (To reduce the risk of fire, electric shock, or personal

1. we suggest installation by a licensed electrician.
 2. Please read the instructions carefully and save it as you may need it at a later time.
 3. Before you start, NEVER attempt any work without shutting off the electricity until the work is done.
- Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the “OFF” position.
 - Place the wall switch in the “OFF” position.
1. The mounting surface should be clean, dry, flat, strong enough and 1/4” larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16” should be corrected as required.
 2. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
 3. Make sure the voltage you are using is 120V. The maximum wattage is Type B, Max 40W per bulb.
 4. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
 5. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
 6. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

TOOLS REQUIRED

TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture


				
Ladder	Philips Head or Flat Blade Screwdriver	Electrical Tape	Pliers	Wire Cutter/Stripper

PARTS TYPE

PARTS TYPE & QTY INCLUDED

- (C) Mounting plate (1)
- (D) Green ground screw (1)
- (E) Canopy (1)
- (F) Swivel joint (1)
- (G) Canopy nut (2)
- (H) Tube
- (I) Connector (1)
- (J) Arm (8)
- (K) Socket (8)

OUTLET BOX



ACCESSORIES & QTY ENCLOSED:

- (A) Plastic wire connector (3)
- (B) Mounting screw (2)


ASSEMBLY & INSTALLATION INSTRUCTIONS

1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
2. Turn off power
Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- Go to the main fuse, or circuit breaker, box in your home.
Place the main power switch in the “OFF” position.
- Place the wall switch in the “OFF” position.


3. Unscrew canopy nuts (G) from the canopy (E).

- Remove the mounting plate (C).



4. Adjust black arms (J) for a proper angle.


- * Adjust until they have shown as the illustration




5. According to your desired hanging height to choose and use tubes (H).

1. Then pass the fixture wires through the chosen tubes (H), the swivel joint (F) and the canopy (E).
2. Be sure that all the threaded tubes are tightened, then screw the chosen tubes (H) onto the swivel joint (F) and the top of connector (I).

- * Hand tighten till snug.




6. Attach mounting plate (C) to the outlet box with mounting screws (B).



7. Make wire connections

Connect wires as shown in the charts below. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES


Connect ground wires according to the chart below



Connect wires according to the chart below


Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire(other than green) with copper conductor	Insulated wire(other than green) with silver conductor

Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)




- Twist wires together with plastic wire connectors (A) until tightly joined.
 - Wrap each connector with approved electrical tape.
 - Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.
8. Raise canopy (E) to the ceiling and secure canopy (E) in place by tightening canopy nuts (G) onto the preassembled screws in mounting plate (C).
- Note: canopy (E) should be snug against the ceiling and canopy nuts (G).
- If not, adjust the threaded length on the mounting plate (C):
- Unscrew the preassembled hex nuts.

- Screw the preassembled screws in or out of mounting plate (C).
- When the secure length is achieved, tighten the hex nuts and back to step 8.



9. Install bulbs (not included) (Please do not exceed the maximum wattage recommended on the socket.)



10. Check that everything is installed properly, then you can turn on the light. We hope you enjoy your new lighting!


ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustrations when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Documents / Resources



[Lowes H512906-AI Two Light Linear](#) [pdf] Installation Guide

H512906-AI Two Light Linear, H512906-AI, Two Light Linear, Light Linear

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.