




Home » LowPowerLab » LowPowerLab ATX-RASPI-R2 Raspberry Pi Power Controller Instructions

LowPowerLab ATX-RASPI-R2 Raspberry Pi Power Controller



Contents [hide]

- 1 Important Information
- 2 Commercial Power Switches
- 3 Simple Pushbutton Or Switches
- 4 Customer Support
- 5 Documents / Resources
 - 5.1 References

Important Information

To keep the price down, the Raspberry Pi doesn't ship with a power button, yet it's easy to add your own! This guide will show you how to add a power button to your Raspberry Pi that can turn on/off your BATOCERA system.

This document is splitted in two part and with a short introduction of how to setup.

- Commercial Power Switches
 - provide real power cuts
 - costs are around 10-25 USD
 - o usually need some space to build in
- Simple Buttons or latching switches
 - very simple setup
 - low cost
 - no power cut possible

Why is a Raspberry Pi power button important?

You should never "yank" the power cord out of your Pi as this can lead to severe data corruption (and in some cases, physically damage your SD card). Even if BATOCERA is best prepared against file corruption it is recommended to safely shut down your Pi via BATOCERAs Quit Menu or even better, use a power button or switch.

Note: When we "shut down" the Pi, it will send it into a halt state, which still consumes a very small amount of power. This is similar to how all modern computers work. In this guide walk through the process of adding a power button that will both halt and wake the Pi up from a halted state.

Additionally, after your Pi has shut down, you can safely disconnect the power supply (should you desire) without the worry of data corruption.

Commercial Power Switches

Here are some commercial power devices that are currently supported. These offer a real power cut, that means the Raspberry is really switched off. Usually these small power devices are plugged on top of the Raspberry using it's 40 Pin header. For further

install instruction use the links provided.


Device Name	system. power. switc	Where to buy and additional help to i	Side N otes
ATXRas pi	ATX_RASPI_R2_6	http://lowpowerlab.com/atxraspi/#installation	
Mausber ry Circuit s	MAUSBERRY	http://mausberry-circuits.myshopify.com/pages/setup	
Pimorini OnOffShi m	ONOFFSHIM	https://shop.pimoroni.com/products/onof f-shim	
msldigita I PiBoard r2013	REMOTEPIBOARD_2 003	ttp://www.msldigital.com/pages/support- for-remotepi-board-2013	
msldigita I PiBoard r2015	REMOTEPIBOARD_2 005	http://www.msldigital.com/pages/support-for-remotepi-board-plus-2015	
UUGear Witty Pi	WITTYPI	http://www.msldigital.com/pages/support-for-remotepi-board-plus-2015	
Retroflag Cases	RETROFLAG	http://www.retroflag.com	enable UART i n confi g.txt fo r LED I action

Simple Pushbutton Or Switches

It is possible to add a button to turn on and turn off your BATOCERA console properly!

Which button to use?

You can add a power button to switch on/off BATOCERA. The button can be either a push button (momentary button) or a switch button (latching switch). Note on the push buttons: some GPIO have resistors pull-up built-in (resistors connected to the + 3.3V), so it is preferable to use switches normally open (abbreviated NO) with these pins.



fritzing

to connect the switch to the Raspberry Pi GPIO, plug a PIN on the GPIO3 (physical PIN 5 above on the left) and another on the mass located just to the right on the right (physical PIN 6):

Activation of the switch

Manual

so your switch is recognized account by BATOCERA, you need to enable this feature in it's settings.

Therefore edit batocera.config

 For a latching switch edit batocera.conf with your preferred text editor and add system.power.switch=PIN56ONOFF

- For a momentary button edit batocera. conf with your preferred OS editor and add system.power.switch=PIN56PUSH
- Reboot the system
- If you are logged in with SSH or you've a terminal open then enter

batocera-settings --command set --key system.power.switch --value

PIN56ONOFF


batocera-settings --command set --key system.power.switch --value

PIN56PUSH

your BATOCERA system can now be turned on/off with a button!

Menu Mode

Get a terminal window by quitting Emulation Station with a Keyboard or get a access to terminal by SSH. Now enter rpi_gpioswitch and you will see a terminal windows like in picture down. From there you can select and activate your power or switch device. The script will show you an already activated device (ONOFFSHIM in this case) and will later show you a small message box, if the value setup was successfully setted up. After this reboot the device and everything should work fine.



Customer Support

rom:

https://wiki.batocera.org/ - Batocera.linux - Wiki

Permanent link:

Last update: 2020/02/07 22:15



https://wiki.batocera.org/

Printed on 2025/06/28 02:48

Documents / Resources



LowPowerLab ATX-RASPI-R2 Raspberry Pi Power Controller [pdf] Instructions

ATX_RASPI_R2_6, MAUSBERRY, OnOffShim, ATX-RASPI-R2 Raspberry Pi Power Controller, ATX-RASPI-R2, Raspberry Pi Power Controller, Pi Power Controller, Power Controller

References

- User Manual
- LowPowerLab
- ◆ ATX_RASPI_R2_6, ATX-RASPI-R2, ATX-RASPI-R2 Raspberry Pi Power Controller, LowPowerLab, MAUSBERRY, OnOffShim, Pi Power Controller, Power Controller, Raspberry Pi Power Controller

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *			

Name
Email
Website
☐ Save my name, email, and website in this browser for the next time I comment.
Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.