



LTECH E1 E Series Touch Panel User Manual

[Home](#) » [LTECH](#) » LTECH E1 E Series Touch Panel User Manual 

Contents

1

LTECH E1 E Series Touch Panel

2

Installation Instructions

3

Product Size

4

Key Functions

5

RF Wireless Wiring

6

Wiring Diagram

7

Warranty Agreement

8

Documents / Resources

8.1

References

9

Related Posts




LTECH E1 E Series Touch Panel



System Diagram

L-BUS




Product Features

- 2 in 1 function: RF wireless control and PWM power output.
- Power output, lamps can be connected directly, easy and convenient.
- Touch keys with chord and LED indicator.
- Adopt capacitive touch control technology on the full color circle that makes LED dimming selection more user-friendly.
- Touch panel can be controlled by remote directly or smart phone if adding a gateway.

Technical Specs


Installation Instructions



Typical junction boxes are as follows:




European style




86 type



Product Size







E1 / E2



Key Functions

When blue indicator light of key is on, long press to turn on/off the buzzer. When white indicator light of key is on, long press to match code. E series touch panel's scene-mode keys are corresponding with WiFi gateway APP's scene-mode, the scenes of panel can be changed by APP or panel.






E4S Mode

- Static red
- Static cyan
- 7 color gradient
- Static green
- Static white
- Static blue
- Static black
- RGB jumping
- Close RGB only
- Static yellow
- 7 color jumping
- Static purple
- RGB gradient

Scene-mode




Mode



- Red-green jumping
- Red-green gradient
- Green-blue jumping
- Green-blue gradient
- Red blue jumping
- Red blue gradient
- RGB jumping
- RGB gradient
- 7 color jumping
- 7 color gradient




System Diagram

PS: No WiFi router is needed when gateway work with phones directly.



Applications

1.  + 
E series touch panel Lamps


2.  +  + 
E series touch panel Remote Lamps

3.  +  + 
E series touch panel WiFi master controller Lamps


4.  +  +  + 
E series touch panel WiFi master controller Remote Lamps

RF Wireless Wiring

Single Zone Control






Multiple Zone Control




Touch panels can be sync controlled by multi remotes, please refer to the manual of remote's usage.

Terminals




Wiring Diagram


E1: Connect with 12V strip. Max 48W/CH Connect with 24V strip. Max 96W/CH





E2: Connect with 12V strip. Max 48W for two routes. Connect with 24V strip. Max 96W for two routes.



E4/E4S: Connect with 12V strip. Max 36W/CH Connect with 24V strip. Max 72W/CH




E5S: Connect with 12V strip, RGB Max. 108W, CT Max. 36W Connect with 24V strip, RGB Max. 216W, CT Max. 72W



Match Code between Touch Panel & Remote

Please match/clear code when panel indicator light of On/Off is white.

1. Long press on touch panel until indicator lights flash.



2. Match code with F series remote: Single zone remote: long press ON/OFF key on remote, the indicator light stops flashing, match code successfully. Multi-zone remote: long press the matching zone's ON & OFF keys simultaneously, the indicator light stops flashing, match code successfully.




3. E1 touch panel match with F1/F5 remote, E2 match with F2/F6, E4/E4S match with F4/F8. Match code with Q series remote: long press the matching zone's "ON" key on remote, the indicator lights of touch panel stop flicking, match successfully.



Match Code between Touch Panel & Gateway

Please match/clear code when panel indicator light of On/Off is white.

1. Long press on touch panel until indicator lights flash.




2. Turn on APP, enter "zone set" interface, click the right top "MATCH" key, then operate the following prompts.



Clear Code

Please match/clear code when panel indicator light of On/Off is white.

Press the bottom two keys on touch panel simultaneously for 6 seconds, the indicator light flashes several times, clear code successfully.



Warranty Agreement

Warranty periods from the date of delivery: 5 years

Free repair or replacement services for quality problems are provided within warranty periods.

Warranty exclusions below:

- Beyond warranty periods.
- Any artificial damage caused by high voltage, overload, or improper operations. Products with severe physical damage.
- Damage caused by natural disasters and force majeure.
- Warranty labels and barcodes have been damaged.
- No any contract signed by LTECH.
- Repair or replacement provided is the only remedy for customers. LTECH is not liable for any incidental or consequential damage unless it is within the law.
- LTECH has the right to amend or adjust the terms of this warranty, and release in written form shall prevail.

Documents / Resources

	<p>LTECH E1 E Series Touch Panel [pdf] User Manual E1, E2, E4, E4S, E5S, E Series Touch Panel</p>
--	---

References

- [🌐 LED Controller | LED Dimmable Driver | LED Intelligent Lighting | Intelligent Home -LTECH](#)

Manuals+.