



# Lumberg HZ35 Tools and Harnessing Machines Instruction Manual

[Home](#) » [Lumberg](#) » Lumberg HZ35 Tools and Harnessing Machines Instruction Manual 

## Contents

- [1 Lumberg HZ35 Tools and Harnessing Machines](#)
- [2 Range of application](#)
- [3 Features](#)
- [4 Dimensions and supply data](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



## Lumberg HZ35 Tools and Harnessing Machines



Manual tongs for termination of RAST 2.5 connectors in insulation displacement technology (IDT)

### Range of application

1. **Connector** 351..., 351...-2, 351...-4, 3520, 3521, 3522, 3523, 352...-2
2. **Pole number** 2–10 (with pitch 2.5 mm)
3. **Pitch** 2,5/5,0 mm
4. **State of delivery of connectors** in the chain, to be detached before use of the manual tongs
5. **Processable conductor** discrete conductor notched flat cable 2.5/5.0 mm

### Features


1. **Application** laboratory and sample production, harness repair
2. **Stroke capacity** ca. 240/h
3. **Scope of functions and delivery**
  1. The harnessing of bus cables possible
  2. In transport case
  3. The handle color may vary during a period of transition.
4. **Options**
  1. Special press die, required for 351... with side P1 being closed

### Dimensions and supply data

- Dimensions (H x W x D) 50 mm x 60 mm x 240 mm
- Weight ca. 1 kg

Designation	Pole Number	PU (Pieces)	MDQ (Pieces)
HZ35	—		

Documents / Resources

	<p><a href="#">Lumberg HZ35 Tools and Harnessing Machines</a> [pdf] Instruction Manual HZ35 Tools and Harnessing Machines, HZ35, Tools and Harnessing Machines</p>
---	--

Manuals+.