



Lumens DC-F80 Document Camera User Guide

[Home](#) » [Lumens](#) » Lumens DC-F80 Document Camera User Guide 

Lumens DC-F80 Document Camera User Guide



Important

- Please activate your warranty: www.MyLumens.com/reg.
- To download the updated software, multilingual manuals, and Quick Start Guide, please visit Lumens™ website at: <https://www.MyLumens.com/support>.

Contents

1 Product Introduction

1.1 Product Overview

1.2 I/O Interface

2 Installation and Connections


3 Start Using

4 Documents / Resources

5 Related Posts


Product Introduction

Product Overview



- Please only operate in the extended as illustrated. Improper usage may damage the machine.


I/O Interface




1. Power LED Indicator
2. Kensington safety Lock
3. Reset Button
4. DIP Switch Setting
5. HDMI/USB mode switch button
6. HDMI output port
7. USB Type-B port

Installation and Connections

- Connect to a projector, monitor or TV(HDTV)





- Connecting to a computer and use TM Lumens software



Please download the relevant software from Lumens website.


Start Using



1. Place an object to be displayed under the camera.
2. Turn on the power .
3. Adjust the support arm and lens to the appropriate positions.
4. Press [AUTO TUNE]  button to optimize the image.
5. You are ready to teach/present.

Lumens[®]

Documents / Resources



[Lumens DC-F80 Document Camera](#) [pdf] User Guide
DC-F80, Document Camera