Manuals+ — User Manuals Simplified.

Lumens DC193 Zoom Document Camera User Guide

Lumens DC193 Zoom Document Camera User Guide

⚠ **Important**

Please activate your warranty at **www.MyLumens.com/reg**

Please visit our website **www.MyLumens.com/goto.htm** to download latest version of Software, Multilingual User Manual and Quick Start Guide.

Contents

User Condition

For the installation instruction, please refer to the 2.

Installation & Connection on the rear side.

Getting Started

1. Place an object to be displayed under the camera.

2. Turn the power on ⏻ .

3. Adjust the gooseneck and lens to appropriate position.

4. Press the [AUTO TUNE] button to optimize the image. You are ready to teach / present.

   Each time the camera head is moved, press the [FOCUS] button to refocus the lens.

Installation & Connection

- **Connect to a Projector or Monitor**

- **Connect to a Computer and Use Lumens' Software**

Driver and software can be downloaded from Lumens website.

- **Connect a Computer, Projector or Monitor simultaneously**

Press [SOURCE] button to switch the image source.

- **Connect to an Interactive Whiteboard (WB)**

- **Connect to an HDTV**

- **Connect to a Computer and FLASH Disk**

Lumens®

Documents / Resources

Lumens DC193 Zoom Document Camera [pdf] User Guide
DC193 Zoom Document Camera, DC193, Zoom Document Camera, Document Camera, Camera