

Lumens Deployment Tools Software User Manual

Home » Lumens Deployment Tools Software User Manual




Contents

- **1 Lumens Deployment Tools Software**
- **2 System Requirements**
- 3 Install software
- **4 Connecting to Internet**
- **5 Operation Interface Description**
- **6 Troubleshooting**
- **7 Copyright Information**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



Lumens Deployment Tools Software



System Requirements

Operating System Requirements

- Windows 7
- Windows 10 (after ver.1709)


System Hardware Requirements

| Item | Real-Time Monitoring Not In Use | Real-Time Monitoring In Use |
|--|---------------------------------|-----------------------------|
| СРИ | i7-7700 above i7-8700 above | |
| Memory | 8GB above | 16GB above |
| Mini Screen Resolution | 1024×768 | 1024×768 |
| HHD 500GB above 500GB above | | 500GB above |
| Free Disk Space 1GB 3GB | | 3GB |
| GPU NVIDIA GTX970 above NVIDIA GTX1050 above | | NVIDIA GTX1050 above |


Install software

Installation steps

- To get LumensDeployment Tools software, please go to the Lumens website, Service Support > Download Area
- Extract the file downloaded and then click [LumensDeployment Tools.msi] to install
- The installation wizard will guide you through the process. Please follow the on-screen instructions for the next step





· When the installation is completed, please press [Close] to close the window




Connecting to Internet

Make sure the computer and the Recording System are connected in the same network segment.





Device Management – Device List



| No | Item | Function Descriptions | |
|----|---|--|--|
| 1 | Search Devices | Search for the devices in the LAN | |
| 2 | Control Item | Control function: Please check the devices first, and then select the function to be executed Reboot Go to Standby / Wake Up Mute / Unmute Start / Stop recording Start / Stop streaming Synchronize time | |
| | | Export / import settings Restore the factory default Upgrade Firmware | |
| 3 | Action Items Execute actions Log in to the device account Delete the device: Only information of login and group will be deleted device can still be located | | |
| 4 | Checkbox | Please check the devices first, and then select the function to be executed | |
| 5 | SSID | Display the device name | |
| 6 | Group Name | Display the Group Name | |

| 7 | Device IP | Display the IP address of the product | |
|----------|--|---|--|
| | | Display the firmware version of the logged in device | |
| 8 | Firmware Version | × If it is not displayed, please go to Manage > Login > enter the account and | |
| | | password to log in to the device | |
| 9 Status | Display the current status of the logged in device (Please refer to 4.2.1 Status | | |
| | Status | Icon Description for icon description) | |
| | | × If it is not displayed, please go to Manage > Login > enter the account and | |
| | | password to log in to the device | |
| 10 | Management | Log in to the webpage of the Recording System | |
| 11 | Page Switch | After entering the page number, click Enter to go directly to the page | |
| 12 | Number of Lists Displayed | Number of devices to display per page | |
| 13 | Logout | Return to the login page | |


4.2.1 Status Icon Description

| Item | Function | Description |
|---------|-----------------------|---|
| Ů. | In use | |
| 「● REC」 | Recording in progress | |
| LIVE | Streaming | Streaming 1 ~ 3. This icon is displayed for any streaming status |
| 0 | Stand By | |
| | | During the firmware updating, the device will be removed from the device list under rebooting, and it will be displayed in the device list after startup is completed |



| No | Item | Function Descriptions | |
|----|-------------------------|---|--|
| 1 | Search Groups | Search Groups | |
| 2 | Add Groups | Add groups. The group will be displayed in the list after saving | |
| 3 | Group Name | Display the Group Name | |
| 4 | Devices of the Group | Display the number of devices | |
| 5 | Edit | Select the groups to be edited for editing a 100% Name PAddress Status LC200A 192.168.4.49 b Cancel Save | |
| | | a. Search Device: Display only the devices not in a groupb. Display devices not in the group | |
| | | c. Group Name: The group name can be changed | |
| | | d. Display the devices already added in the group | |
| | | e. Add the selected devices in the left list to the group | |
| | | f. Remove the selected devices in the right list from the group | |
| | | g. Save / cancel group editing setting | |
| 6 | Delete | Select the groups to be removed for removing | |


Device Management – Setting




Timeout in milliseconds -0 or negatives indicate infinte timeout.Leave blank for default(10000 ms)

Test Cancel Save

Device Management – User




Schedule Manager - Schedule



| No | Item | Function Descriptions | |
|----|------------------------------|--|--|
| 1 | Group | Select a group schedule | |
| 2 | Device | Select a device schedule | |
| 3 | Display Range of Calendar | Display range of calendar at a time | |
| 4 | Calendar | Display / edit the calendar <remark> Drag the mouse to select continuous time periods, and then click Add > Save the Schedule</remark> | |
| 5 | Add | Add > Save the Schedule Add the calendar manually Start | |
| 6 | Reset | Reset the calendar <remark> Only the schedule of a single group and a single device will be reset</remark> | |
| 7 | Export | Export the edited calendar | |
| 8 | Import | Import the edited calendar | |

Live image



| No | Item | Function Descriptions | |
|----|-------------------------|---|--|
| 1 | Add Group / Device | Add a group or multiple devices | |
| 2 | Live Image | Display the output image; up to 6 can be displayed in one page Remark> You may click the camera to be controlled from the live image, and | |
| | | the selected one will be marked with a red frame | |
| 3 | Zoom In the Window | Zoom in the window to access single view mode | |
| 4 | Recording/ Streaming | Recording / Streaming 1 ~ 3 | |
| 5 | Audio Source Setting | Mute / Unmute | |
| | Layout Setting | Scene / Layout / Macro | |
| 6 | | <remark> This parameter needs to be set in the webpage of the Recording</remark> | |
| | | System | |
| | Control the Camera | After selecting the camera to be controlled in the live image, you can control | |
| | | PTZ, save, and call the default position | |
| _ | | ■ Call preset: Click the default position directly | |
| , | | ■ Save preset: Click [Save Preset] and then click the default position | |
| | | ■ Pan / tilt PTZ control | |
| | | ■ Zooming in / out the image | |

About



Troubleshooting

This chapter describes problems you may encounter while using LumensDeployment Tools. If you have questions, please refer to related chapters and follow all the suggested solutions. If the problem still occurred, please contact your distributor or the service center.

| No. | Problems | Solutions |
|-----|--|---|
| 1. | Unable to search devices | Please make sure that the computer and the Recording System ar e connected in the same network segment. (Please refer to Chapt er 3 Connecting to Internet) |
| 2. | Forgot the software login account and password | Please go to Control Panel to uninstall the software and then dow nload it again on the Lumens official website |
| 3. | Live image delay | Please refer to Chapter 1 System Requirements to make sure the matched PC meets the specifications |
| | The operating steps in the man ual are not consistent with the | The software operation may be different from the description in the manual due to functional improvement. Please make sure you've updated your software to the latest version. ¡ For the latest version, please go to the Lumens official website > Service Support > Download Area. https://www.MyLumens.com/ |
| 4. | software operation | support > Download Area. https://www.myLumens.com/ |

Copyright Information

- Copyrights © Lumens Digital Optics Inc. All rights reserved.
- Lumens is a trademark that is currently being registered by Lumens Digital Optics Inc.
- Copying, reproducing or transmitting this file is not allowed if a license is not provided by Lumens Digital Optics Inc. unless copying this file is for the purpose of backup after purchasing this product.
- In order to keep improving the product, the information in this file is subject to change without prior notice.

 To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.
- Disclaimer of warranties: Lumens Digital Optics Inc. is neither responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.

Documents / Resources



<u>Lumens Deployment Tools Software</u> [pdf] User Manual Deployment Tools Software

References

• <u>Download | Lumens</u>

